

# JIFFYDOS

version 6.01

This document is a dump of JiffyDOS version 6.01. The parts concerning JiffyDOS have been commented by Magnus Nyman (magnus.q.nyman@telia.se), also known as Harlekin/FairLight. All new JiffyDOS routines are specified in the text. The comments to other parts of this document are partially rewritten from 'The Bible', Commodore Reference Manual. Some text has been added, to increment the knowledge of the original Commodore routines. Some errors have been corrected, and old routines have been removed. Also included are my own thoughts of what can be improved.

If you find any errors, feel free to contact me on the address above.

//Magnus

Document revision B. 1996-10-03

New Zeropage addresses in the JiffyDOS system.

\$26	; allflag/ysize	2
\$27	; comsav	2
\$9b	; AKTFLG, flags if jiffyDOS funktionkeys is ; aktivated. If 0, funktionkeys are enabled.	
\$9f	; CJLA, JiffyDOS default filenameumber.	
\$A3	; ldflg/qflag, Used in all disk access and LOAD routines.	
\$a6	; TFLAG, temp store of JiffyDOS command number.	
\$b0/\$b1	; KEYPTR, vector to table of JiffyDOS funktion keys.	
\$B0	; sprsav, Saved, then restored by LOAD routine (no other usage).	
\$B1	; rassav	1
\$B2	; regsav	1
\$be	; DRVBYT, JiffyDOS default device number.	

### DISK ACCESS

The 64'er access the serial devices through the CIA at \$DD00. The "bits" have the following connection! The JiffyDOS performs it's own timing and handshaking, allowing us to use both the data AND the clock lead to transfer data. This has two advantages. 1) We send/receive two bits at a time. 2) Because of the heavy timing that is done before the bits are sent, we don't need any timing for the next bytes, and we can send 4\*2 bits (ie. the entire byte) without any more timing!

adr \$DD00	56576
bit 7	Serial Bus Data Input
6	Serial Bus Clock Pulse Input
5	Serial Bus Data Output
4	Serial Bus Clock Pulse Output
3	Serial Bus ATN Signal Output

Bits used

; E000

```
    sta a56
    jsr ebc0f
    lda a61
    cmp #$88
    bcc ie00e
ie00b jsr ebad4
ie00e jsr ebccc
    lda a07
    clc
    adc #$81
    beq ie00b
    sec
    sbc #$01
    pha
    ldx #$05
ie01e lda f69,x
    ldy f61,x
    sta f61,x
    sty f69,x
    dex
    bpl ie01e
    lda a56
    sta a70
    jsr eb853
    jsr ebfbb4
    lda #$c4
    ldy #$bf
    jsr ie059
    lda #$00
    sta a6f
    pla
    jsr ebab9
    rts
ie043 sta a71
    sty a72
    jsr ebbca
    lda #$57
    jsr eba28
    jsr ie05d
    lda #$57
    ldy #$00
    jmp eba28
ie059 sta a71
    sty a72
ie05d jsr ebbc7
    lda (p71),y
    sta a67
    ldy a71
    iny
    tya
    bne ie06c
    inc a72
ie06c sta a71
```

```

        ldy a72
ie070   jsr eba28
        lda a71
        ldy a72
        clc
        adc #$05
        bcc ie07d
        iny
ie07d   sta a71
        sty a72
        jsr eb867
        lda #$5c
        ldy #$00
        dec a67
        bne ie070
        rts
        tya
        and f44,x
        ror $
        brk
        pla
        plp
        lda (p46),y
        brk
        jsr ebc2b
        bmi ie0d3
        bne ie0be
        jsr efff3
        stx a22
        sty a23
        ldy #$04
        lda (p22),y
        sta a62
        iny
        lda (p22),y
        sta a64
        ldy #$08
        lda (p22),y
        sta a63
        iny
        lda (p22),y
        sta a65
        jmp ie0e3
ie0be   lda #$8b
        ldy #$00
        jsr ebba2
        lda #$8d
        ldy #$e0
        jsr eba28
        lda #$92
        ldy #$e0
        jsr eb867
ie0d3   ldx a65
        lda a62
        sta a65
        stx a62
        ldx a63

```

```

        lda a64
        sta a63
        stx a64
ie0e3  lda #$00
        sta a66
        lda a61
        sta a70
        lda #$80
        sta a61
        jsr eb8d7
        ldx #$8b
        ldy #$00
ie0f6  jmp ebbd4

```

#### **E0F9 BIOERR: HANDLE I/O ERROR IN BASIC**

This routine is called whenever BASIC wishes to call one of the KERNAL I/O routines. It is also used to handle I/O errors in BASIC.

```

.e0f9  cmp #$f0          ; test error
        bne $e104
        sty $38          ; MEMSIZ, highest address in BASIC
        stx $37
        jmp $a663        ; do CLR without aborting I/O
.e104  tax              ; put error flag i (X)
        bne $e109        ; if error code $00, then set error code $1e
        ldx #$1e
.e109  jmp $a437        ; do error

```

#### **E10C BCHOUT: OUTPUT CHARACTER**

This routine uses the KERNAL routine CHROUT to output the character in (A) to an available output channel. A test is made for a possible I/O error.

```

.e10c  jsr $ffd2        ; output character in (A)
        bcs $e0f9        ; if carry set, handle I/O error
        rts             ; else return

```

#### **E112 BCHIN: INPUT CHARACTER**

This routine uses the KERNAL routine CHRIN to input a character to (A) from an available input channel. A test is made for a possible I/O error.

```

.e112  jsr $ffcf        ; input character from CHRIN
        bcs $e0f9        ; if carry set, handle I/O error
        rts             ; else return

```

#### **E118 BCKOUT: SET UP FOR OUTPUT**

This routine uses the KERNAL routine CHKOUT to open an output channel, and tests for possible I/O error. On entry (X) must hold the the logical file number as used in OPEN.

```

.e118  jsr $e4ad        ; open output channel via CHKOUT
        bcs $e0f9        ; if carry set, handle I/O error
        rts             ; else return

```

#### **E11E BCKIN: SET UP FOR INPUT**

This routine uses the KERNAL routine CHKIN to open an input channel. A test as made for possible I/O error.

```

.e11e jsr $ffc6      ; open input channel via CHKIN
      bcs $e0f9      ; if carry set, handle I/O error
      rts            ; else return

```

#### **E124 BGETIN: GET ONT CHARACTER**

This routine uses the KERNAL routine GETIN to get a character from the keyboard buffer into (A). A test is made for possible I/O error.

```

.e124 jsr $ffe4      ; GETIN, get character from keyboard buffer
      bcs $e0f9      ; if carry set, handle I/O error
      rts            ; else return

```

#### **E12A SYS: PERFORM SYS**

This routine enables machine language routines to be executed from BASIC. The routine evaluates the address and confirms that it is a numeric number. The return address is set up, and the user routine is executed.

```

.e12a jsr $ad8a      ; evaluate text & confirm numeric
      jsr $b7f7      ; convert fac#1 to integer in LINNUM
      lda #$e1       ; set return address on stack to $ea46
      pha
      lda #$46
      pha
      lda $030f      ; SPREG, user flag register
      pha
      lda $030c      ; SAREG, user (A) register
      ldx $030d      ; SXREG, user (X) register
      ldy $030e      ; SYREG, user (Y) register
      plp
      jmp ($14)      ; execute user routine, exit with rts
.e146 php
      sta $030c      ; store in SAREG, user (A) register
      stx $030d      ; store in SXREG, user (X) register
      sty $030e      ; store in SYREG, user (Y) register
      pla
      sta $030f      ; store in SPREG, user flag register
      rts            ; back

```

#### **E156 SAVET: PERFORM SAVE**

This routine is sets parameters for save, and calls the save routine. The start and end addresses are obtained from TXTTAB and VARTAB. Finally, a test is made if any errors ocured.

```

      jsr $e1d4      ; get SAVE paramerters from text
      ldx $2d        ; VARTAB, start of variables
      ldy $2e
      lda #$2b       ; <TXTTAB, start of BASIC text
      jsr $ffd8      ; execute SAVE
      bcs $e0f9      ; if carry is set, handle I/O errors
      rts

```

#### **E165 VERFYT: PERFORM LOAD/SAVE**

This routine is essentially the same for both LOAD and VERIFY. The entry point determins which is performed, by setting VERCK accordingly. The LOAD/VERIFY parameters, filename, device etc. are obtained from text before the KERNAL routine LOAD is called. A test is made for I/O errors. At this point, the two functios are distiguished. VERIFY reads the the status word and prints the

message OK or ?VERIFY error depending on the result of the test. LOAD reads the I/O status word for a possible ?LOAD error, then updates the pointers to text and variables, exiting via CLR.

```
.e165  lda #$01          ; flag verify
      bit $00a9         ; mask, will execute lda #$01 if address $e168
      sta $0a           ; store in VRECK, LOAD/VERIFY flag
      jsr $e1d4         ; get LOAD/VERIFY parameters from text
      lda $0a           ; get VRECK
      ldx $2b           ; TXTTAB, start of BASIC
      ldy $2c
      jsr $ffdb         ; execute LOAD, KERNAL routine
      bcs $e1d1         ; if carry set, handle error
      lda $0a           ; test VRECK for LOAD or VERIFY
      beq $e195         ; do LOAD
      ldx #$1c          ; set error $1c, VERIFY error
      jsr $fffb         ; do READST, get status I/O word
      and #$10          ; %00010000, test for mismatch
      bne $e19e         ; data mismatch, do error
      lda $7a           ; <TXTPTR
      cmp #$02
      beq $e194
      lda #$64          ; set address to text OK
      ldy #$a3          ; at $a364
      jmp $able         ; output string in (A/Y)
.e194  rts
.e195  jsr $fffb         ; do READST, get status I/O for LOAD
      and #$bf          ; %10111111, test all but EOI
      beq $e1a1         ; nope, no errors
      ldx #$1d          ; set error $1d, LOAD error
.e19e  jmp $a437         ; do error
.e1a1  lda $7b           ; >TXTPTR
      cmp #$02
      bne $e1b5
      stx $2d           ; set VARTAB, start of variables
      sty $2e
      lda #$76          ; set address to text READY
      ldy #$a3          ; at $a376
      jsr $able         ; output string in (A/Y)
      jmp $a52a         ; do CLR and restart BASIC
.e1b5  jsr $a68e         ; reset TXTPTR
      jsr $a533         ; rechain BASIC lines
      jmp $a677         ; do RESTORE and reset OLDTXT
```

#### **E1BE OPENT: PERFORM OPEN**

This routine extracts parameters from text and performs the OPEN routine in KERNAL. A test is made for I/O errors.

```
.e1be  jsr $e219         ; get parameters from text
      jsr $ffc0         ; execute OPEN
      bcs $e1d1         ; if carry set, handle error
      rts
```

#### **E1C7 CLOSET: PERFORM CLOSE**

The parameters for CLOSE are obtained from text, and the logical filename placed in (A), The KERNAL routine CLOSE is performed, and a test is made for I/O errors.



```

.elc7  jsr $e219      ; get parameters from text
      lda $49        ; logical file number
      jsr $ffc3      ; perform CLOSE
      bcc $e194      ; if carry set, handle error, else return
.eldd1 jmp $e0f9      ; jump to error routine

```

#### **E1D4 SLPARA: GET PARAMETERS FOR LOAD/SAVE**

This routine gets the filename, devicenumber and secondary address for LOAD/VERIFY and SAVE operations. The KERNAL routines SETNAM and SETLFS are used to do this. Default parameters are set up, and a new JiffyDOS routine is called at \$eldd. It jumps to \$f73a where the original SETLFS is performed, but also makes a test to find the first serial device number, and pokes it into FA. Then tests are made if any of the parameters were given. If so, these are set up as wanted.

```

.eldd4 lda #$00      ; clear length of filename
      jsr $ffbd      ; SETNAM
      ldx #$01      ; default FA, device number is #01
      ldy #$00      ; default SA, secondary address is #00
.eldd  jsr $f73a      ; SETLFS, and device number in new JiffyDOS routine
      jsr $e206      ; test if "end of line", if so end here
      jsr $e257      ; set up given filename and perform SETNAM
      jsr $e206      ; test if "end of line", if so end here
      jsr $e200      ; check for comma, and input one byte, FA, to (X)
      ldy #$00
      stx $49
      jsr $ffb8      ; perform new SETLFS with device number
      jsr $e206      ; test if "end of line", if so end here
      jsr $e200      ; check for comma, and input one byte, SA, to (X)
      txa            ; transfer (X) to (Y)
      tay
      ldx $49        ; get FA
      jmp $ffb8      ; perform SETLFS with both device number and secondary
                      ; address. Then exit

```

#### **E200 COMBYT: GET NEXT ONE-BYTE PARAMETER**

This routine checks if the next character of text is a comma, and then inputs the parameter following into (X).

```

.e200  jsr $e20e      ; check for comma
      jmp $b79e      ; input one byte parameter to (X)

```

#### **E206 DEFLT: CHECK DEFAULT PARAMETERS**

This routine tests CHRGOT to see if a optional parameter was included in the text. If it was, a normal exit is performed via RTS. If not, the return address on the stack is discarded, and the routine exits both this and the calling routine.

```

.e206  jsr $79        ; get CHRGOT
      bne $e20d      ; if last character is a character, do normal exit
      pla            ; else, remove return address
      pla            ; to exit this AND the calling routine.
.e20d  rts            ; exit

```

#### **E20E CMMERR: CHECK FOR COMMA**

This routine confirms that the next character in the text is a comma. It also test that the comma is not immediately followed by a terminator. If so, exit and do SYNTAX error.

```
.e20e jsr $aefd          ; confirm comma
.e211 jsr $79           ; get CHRGOT
      bne $e20d          ; else than null
      jmp $af08          ; execute SYNTAX error
```

#### **E219 OCPARA: GET PARAMETERS FOR OPEN/CLOSE**

This routine gets the logical file number, device number, secondary address and filename for OPEN/CLOSE. Initially the default filename is set to null, and the device number to #1. The logical filename is compulsory, and is obtained from text and placed in <FORPNT. The other parameters are optinal and are obtained if present. The device number is stored in >FORPNT. The parameters are set via the KERNAL routines SETNAM and SETLFS.

```
.e219 lda #$00          ; default filename is null
      jsr $ffbd          ; SETNAM
      jsr $e211          ; confirm TTXPNT is no terminator, if so - error
      jsr $b79e          ; input one byte character to (X)
      stx $49           ; store logical filename in <FORPNT
      txa               ; set default parameters to
      ldx #$01          ; device = #1
      ldy #$00          ; secondary address = #0
      jsr $ffba          ; SETLFS
      jsr $e206          ; test if "end of line", if so end here
      jsr $e200          ; check for comma, and input FA, device number
      stx $4a           ; store in >FORPNT
      ldy #$00          ; secondary address = #0
      lda $49           ; logical file number from temp store
      cpx #$03          ; test if serial device
      bcc $e23f          ; nope
      dey               ; if serial, set secondary address to $ff
.e23f jsr $ffba          ; SETLFS
      jsr $e206          ; test if "end of line", if so end here
      jsr $e200          ; check for comma, and input SA, secondary address
      txa               ; SA to (Y)
      tay               ;
      ldx $4a           ; FA
      lda $49           ; LA
      jsr $ffba          ; SETLFS
      jsr $e206          ; test if "end of line", if so end here
      jsr $e20e          ; check for comma only
.e257 jsr $ad9e          ; evaluate expression in text
      jsr $b6a3          ; do string housekeeping
      ldx $22           ; pointers to given filename
      ldy $23
      jmp $ffbd          ; SETNAM and exit
```

#### **E264 COS: PERFORM COS**

This routine manipulates the input COS to be calcuated with SIN.  $\text{COS}(X) = \text{SIN}(X + \pi/2)$ , where  $X$  is in radians. We use it as  $\text{Fac\#1} = \text{SIN}(\text{fac\#1} + \pi/2)$ , ie  $\pi/2$  is added to  $\text{fac\#1}$  and the following SIN is performed.

```
      lda #$e0          ; set address to pi/2
      ldy #$e2          ; at $e2e0
```

jsr \$b867 ; add fltp at (A/Y) to fac#1

**E26B SIN: PERFORM SIN**

```
ie26b  jsr ebc0c
        lda #$e5
        ldy #$e2
        ldx a6e
        jsr ebb07
        jsr ebc0c
        jsr ebccc
        lda #$00
        sta a6f
        jsr eb853
        lda #$ea
        ldy #$e2
        jsr eb850
        lda a66
        pha
        bpl ie29d
        jsr eb849
        lda a66
        bmi ie2a0
        lda a12
        eor #$ff
        sta a12
ie29d  jsr ebfb4
ie2a0  lda #$ea
        ldy #$e2
        jsr eb867
        pla
        bpl ie2ad
        jsr ebfb4
ie2ad  lda #$ef
        ldy #$e2
        jmp ie043
```

**E2B4 TAN: PERFORM TAN**

```
.e2b4  jsr ebbca
        lda #$00
        sta a12
        jsr ie26b
        ldx #$4e
        ldy #$00
        jsr ie0f6
        lda #$57
        ldy #$00
        jsr ebba2
        lda #$00
        sta a66
        lda a12
        jsr ie2dc
        lda #$4e
        ldy #$00
        jmp ebb0f
ie2dc  pha
```

jmp ie29d

#### **E2E0 PI2: TABLE OF TRIGONOMETRY CONSTANTS**

The following constants are held in 5 byte flpt for trigonometry evaluation.

```
.e2e0 81 49 0f da a2 ; 1.570796327 (pi/2)
.e2e5 83 49 0f da a2 ; 6.28318531 (pi*2)
.e2ea 7f 00 00 00 00 ; 0.25
.e2ef 05 ; 5 (one byte counter for SIN series)
.e2f0 84 e6 1a 2d 1b ; -14.3813907 (SIN constant 1)
.e2f5 86 28 07 fb f8 ; 42.0077971 (SIN constant 2)
.e2fa 87 99 68 89 01 ; -76.7041703 (SIN constant 3)
.e2ff 87 23 35 df e1 ; 81.6052237 (SIN constant 4)
.e304 86 a5 5d e7 28 ; -41.3417021 (SIN constant 5)
.e309 83 49 0f ds a2 ; 6.28318531 (SIN constant 6, pi*2)
```

#### **E30E ATN: PERFORM ATN**

```
.e30e lda $66
      pha
      bpl ie316
      jsr ebf4
ie316 lda a61
      pha
      cmp #$81
      bcc ie324
      lda #$bc
      ldy #$b9
      jsr ebb0f
ie324 lda #$3e
      ldy #$e3
      jsr ie043
      pla
      cmp #$81
      bcc ie337
      lda #$e0
      ldy #$e2
      jsr eb850
ie337 pla
      bpl ie33d
      jmp ebf4
ie33d rts
```

#### **E33E ATNCON: TABLE OF ATN CONSTANTS**

The table holds a 1 byte counter and the following 5 byte flpt constants.

```
.e33e 0b ; 13 (one byte counter for ATN series)
.e33f 76 b3 83 bd d3 ; -0.000684793912 (ATN constant 1)
.e344 79 1e f4 a6 f5 ; 0.00485094216 (ATN constant 2)
.e349 7b 83 fc b0 10 ; -0.161117018 (ATN constant 3)
.e34e 7c 0c 1f 67 ca ; 0.034209638 (ATN constant 5)
.e353 7c de 53 cb c1 ; -0.0542791328 (ATN constant 6)
.e358 7d 14 64 70 4c ; 0.0724571965 (ATN constant 7)
.e35d 7d b7 ea 51 7a ; -0.0898023954 (ATN constant 8)
.e362 7d 63 30 88 7e ; 0.110932413 (ATN constant 9)
.e367 7e 92 44 99 3a ; -0.14283908 (ATN constant 10)
.e36c 7e 4c cc 91 c7 ; 0.19999912 (ATN constant 11)
```

```
.e371 7f aa aa aa 13      ; -0.333333316      (ATN constant 12)
.e376 81 00 00 00 00      ; 1                (ATN constant 13)
```

#### **E37B BASSFT: BASIC WARM START**

This is the BASIC warm start routine that is vectored at the very start of the BASIC ROM. The routine is called by the 6510 BRK instruction, or STOP/RESTORE being pressed. It outputs the READY prompt via the IERROR vector at \$0300. The original IERROR vector points to \$e38b, but JiffyDOS uses the error routine as an input to check new commands. If the error code, in (X) is larger than \$80, then only the READY text will be displayed.

```
.e37b jsr $ffcc          ; CLRCHN, close all I/O channels
      lda #$00
      sta $13           ; input prompt flag
      jsr $a67a         ; do CLR
      cli              ; enable IRQ
.e386 ldx #$80          ; error code #$80
      jmp ($0300)       ; perform error, JiffyDOS at $f763
.e38b txa              ; error number
      bmi $e391         ; larger than $80
      jmp $a43a         ; nope, print error
.e391 jmp $a474         ; print READY
```

#### **E394 INIT: BASIC COLD START**

This is the BASIC cold start routine that is vectored at the very start of the BASIC ROM. BASIC vectors and variables are set up, and power-up message is output, and BASIC is restarted.

```
.e394 jsr $e4b7         ; Init JiffyDOS commands & funktionkeys
      jsr $e3bf         ; Initialize BASIC
      jsr $e422         ; output power-up message
      ldx #$fb         ; reset stack
      txs
      bne $e386         ; output READY, and restart BASIC
```

#### **E3A2 INITAT: CHRGET FOR ZEROPAGE**

This is the CHRGET routine which is transferred to RAM starting at \$0073 on power-up or reset.

```
.e3a2 inc $7a           ; .0073 inc $7a          ; increment <TXTPTR
      bne $e3a8         ;          bne $0079      ; skip high byte
      inc $7b           ;          inc $7b        ; increment >TXTPTR
.e3a8 lda $ea60         ; .0079 lda $ea60        ; CHRGOT entry, read TXTPTR
      cmp #$3a         ;          cmp #$3a        ; colon (terminator), sets
(Z)                                     (Z)
      bcs $e3b9         ;          bcs $008a
      cmp #$20         ;          cmp #$20        ; space, get next character
      beq $e3a2         ;          bne $0073
      sec              ;          sec
      sbc #$30         ;          sbc #$30        ; zero
      sec              ;          sec
      sbc #$d0         ;          sbc #$d0
.e3b9 rts              ; .008a rts
```

#### **E3BA RNDSED: RANDOM SEED FOR ZEROPAGE**

This is the initial value of the seed for the random number function. It is copied into RAM from \$008b-\$008f. Its fltp value is 0.811635157.

.e3ba 80 4f c7 52 58

### **E3BF INITCZ: INITIALISE BASIC RAM**

This routine sets the USR jump instruction to point to ?ILLIGAL QUANTITY error, sets ADRAY1 and ADRAY2, copies CHRGET and RNDSED to zeropage, sets up the start and end locations for BASIC text and sets the first text byte to zero.

```
.e3bf  lda #$4c          ; opcode for JMP
      sta $54          ; store in JMPER
      sta $0310        ; USRPOK, set USR JMP instruction
      lda #$48
      ldy #$b2         ; vector to $b248, ?ILLIGAL QUANTITY
      sta $0311
      sty $0312        ; store in USRADD
      lda #$91
      ldy #$b3         ; vector to $b391
      sta $05
      sty $06          ; store in ADRAY2
      lda #$aa
      ldy #$b1         ; vector to $b1aa
      sta $03
      sty $04          ; store in ADRAY1
      ldx #$1c         ; copy the CHRGET routine and RNDSED to RAM
.e3e2  lda $e3a2,x      ; source address
      sta $73,x        ; destination address
      dex              ; next byte
      bpl $e3e2        ; till ready
      lda #$03
      sta $53          ; store #3 in FOUR6, garbage collection
      lda #$00
      sta $68          ; init BITS, fac#1 overflow
      sta $13          ; init input prompt flag
      sta $18          ; init LASTPT
      ldx #$01
      stx $01fd
      stx $01fc
      ldx #$19
      stx $16          ; TEMPPT, pointer to descriptor stack
      sec              ; set carry to indicate read mode
      jsr $ff9c        ; read MEMBOT
      stx $2b          ; set TXTTAB, bottom of RAM
      sty $2c
      sec              ; set carry to indicate read mode
      jsr $ff99        ; read MEMTOP
      stx $37          ; set MEMSIZ, top of RAM
      sty $38
      stx $33          ; set FRETOP = MEMTOP
      sty $34
      ldy #$00
      tya
      sta ($2b),y      ; store zero at start of BASIC
      inc $2b          ; increment TXTTAB to next memory position
      bne $e421        ; skip msb
      inc $2c
.e421  rts              ; return
```

#### **E422 INITMS: OUTPUT POWER-UP MESSAGE**

This routine outputs the startup message. It then calculates the number of BASIC bytes free by subtracting the TXTTAB from MEMSIZ, and outputs this number. The routine exits via NEW.

```
.e422  lda $2b          ; read TXTTAB, start of BASIC
      ldy $2c
      jsr $a408        ; check for memory overlap
      lda #$73         ; $e473, startup message
      ldy #$e4
      jsr $able        ; output (A/Y)
      lda $37          ; MEMSIZ, highest address in BASIC
      sec              ; prepare for subtract
      sbc $2b          ; subtract TXTTAB
      tax              ; move to (X)
      lda $38          ; and highbyte
      sbc $2c
      jsr $bdcd        ; output number in (A/X)
      lda #$60         ; $e460
      ldy #$e4         ; pointer to 'BASIC BYTES FREE'
      jsr $able        ; output (A/Y)
      jmp $a644        ; perform NEW
```

#### **E447 JIFFYDOS VECTORS**

This table contains jump vectors that are transferred to \$0300-\$030b. Some vectors are standard Commodore, but some are modified for JiffyDOS.

```
.e447  63 f7          ; IERROR VEC, print basic error message ($f763)
                        ; Original IERROR VEC points to $e38b
.e449  83 4a          ; IMAIN VECTOR, basic warm start ($a483)
.e44b  64 ea          ; ICRNCH VECTOR, tokenise basic text ($ea64)
                        ; Original ICRNCH VECTOR points to $a57c
.e44d  a1 a7          ; IQPLOP VECTOR, list basic text ($a7a1)
.e44f  e4 a7          ; IGONE VEXTOR, basic character dispatch ($a7ea)
.e451  86 ea          ; IEVAL VECTOR, evaluate basic token ($ae86)
```

#### **E453 INIT JIFFYDOS COMMANDS**

This routine transfers the vectors \$0300-\$030b to set up the JiffyDOS commands.

```
.e453  ldx #$0b        ; 6 vectors to be copied
.e455  lda $e447,x
      sta $0300,x
      dex              ; next byte
      bpl $e455        ; ready
      rts              ; return
```

#### **E45F WORDS: POWER UP MESSAGE**

This is the power up message displayed on the screen when the 'Commie' is switched on or reset. The strings are seperated by a zero byte.

jiffydos v6.01 (c)1989 cmd

c-64 basic v2   xxxxx basic bytes free

```

.e45f  00 20 42 41 53 49 43 20 ; basic
.e467  42 59 54 45 53 20 46 52 ; bytes fr
.e46f  45 45 0d 00 93 0d 20 20 ; ee
.e477  20 20 20 20 20 4a 49 46 ; jif
.e47f  46 59 44 4f 53 20 56 36 ; fydos v6
.e487  2e 30 31 20 28 43 29 31 ; .01 (c)l
.e48f  39 38 39 20 43 4d 44 20 ; 989 cmd
.e497  20 0d 0d 20 43 2d 36 34 ; c-64
.e49f  20 42 41 53 49 43 20 56 ; basic v
.e4a7  32 20 20 20 00 81 ; 2

```

#### **E4AD PATCH FOR BASIC CHKOUT CALL**

This is a short patch added for the KERNAL ROM to preserv (A) when there was no error returned from BASIC calling the CHKOUT routine. This corrects a bug in the early versions of PRINT# and CMD.

```

.e4ad  pha ; temp store (A)
      jsr $ffc9 ; CHKOUT
      tax
      pla ; retrieve (A)
      bcc $e4b6
      txa
.e4b6  rts

```

#### **E4B7 INIT JIFFYDOS COMMANDS AND FUNKTIONKEYS**

This routine initialises the JiffyDOS commands by jumping to \$e453 where the \$0300-vectors are set up. Then it sets up the vectors at \$b0 to point to the funktionkey table at \$f672. The entry at \$e4c2 disables the funktionkeys after a @f command.

```

.e4b7  jsr $e453 ; init JiffyDOS command vectors
      lda #$72 ; Set up JiffyDOS function key vector
      sta $b0 ; to $f672
      lda #$f6
      sta $b1
.e4c2  inx ; (X)=0
      stx $9b ; AKTFLT, aktivieren/deaktivieren funktion keys
      rts

.e4c6  lda #$6f ; #$6f=command channel
      jsr $f0e4 ; prepare for input
      jsr $ffcf ; input byte from command channel
      cmp #$35 ; equal to #$35 (#)
      rts

      tax ; free byte
      tax ; free byte

```

#### **E4D3 RS232 PATCH**

This patch has been added to the RS232 input routine in KERNAL v.3. It initialises the RS232 parity byte, RIPRTY, on reception of a start bit.

```

.e4d3  sta $a9 ; RINONE, check for start bit
      lda #$01

```



```

        sta $ab          ; RIPRTY, RS232 input parity
        rts

```

#### **E4DA RESET CHARACTER COLOUR**

This routine is a patch in KERNAL version 3 to fix a bug with the colour code. The routine is called by 'clear a screen line', and sets the character colour to COLOR.

```

.e4da  lda $0286          ; get COLOR
        sta ($f3),y       ; and store in current screen position
        rts

```

#### **E4E0 PAUSE AFTER FINDING TAPE FILE????????????**

This routine would continue tape loading without pressing C= when a file was found. This could probably be removed, since JiffyDOS not uses tape junk.

```

.e4e0  adc #$02
.e4e2  ldy $91
        iny
        bne $e4eb
        cmp $a1
        bne $e4e2
.e4eb  rts

```

#### **E4EC RS232 TIMING TABLE - PAL**

Timingtable for RS232 NMI for use with PAL machines. This table contains the prescaler values for setting up the RS232 baudrates. The table contains 10 entries which corresponds to one of the fixed RS232 rates, starting with lowest (50 baud) and finishing with the highest (2400 baud). Since the clock frequency is different between NTSC and PAL systems, there is another table for NTSC machines at \$fec2.

```

.e4ec  19 29              ; 50 baud
.e4ee  44 19              ; 75 baud
.e4f0  1a 11              ; 110 baud
.e4f2  e8 0d              ; 134.5 baud
.e4f4  70 0c              ; 150 baud
.e4f6  06 06              ; 300 baud
.e4f8  d1 02              ; 600 baud
.e4fa  37 01              ; 1200 baud
.e4fc  ae 00              ; (1800) 2400 baud
.e4fe  69 00              ; 2400 baud

```

#### **E500 IOBASE: GET I/O ADDRESS**

The KERNAL routine IOBASE (\$fff3) jumps to this routine. It returns the base address \$dc00 in (X/Y)

```

.e500  ldx #$00           ; set (X/Y) to $dc00
        ldy #$dc
        rts

```

#### **E505 SCREEN: GET SCREEN SIZE**

The KERNAL routine SCREEN (\$ffd) jumps to this routine. It returns the screen size; columns in (X) and rows in (Y).

```

.e505  ldx #$28           ; 40 columns
        ldy #$19           ; 25 rows

```

rts

#### **E50A PLOT: PUT/GET ROW AND COLUMN**

The KERNAL routine PLOT (\$fff0) jumps to this routine. The option taken depends on the state of carry on entry. If it is set, the column is placed in (Y) and the row placed in (X). If carry is clear, the cursor position is read from (X/Y) and the screen pointers are set.

```
.e50a  bcs $e513          ; if carry set, jump
        stx $d6          ; store TBLX, current row
        sty $d3          ; store PNTR, current column
        jsr $e56c        ; set screen pointers
.e513  ldx $d6          ; read TBLX
        ldy $d3          ; read PNTR
        rts
```

#### **E518 CINT1: INITIALISE I/O**

This routine is part of the KERNAL CINT init routine. I/O default values are set, <shift+cbm> keys are disabled, and cursor is switched off. The vector to the keyboard table is set up, and the length of the keyboardbuffer is set to 10 characters. The cursor color is set to lightblue, and the key-repeat parameters are set up.

```
.e518  jsr $e5a0          ; set I/O defaults
        lda #$00
        sta $0291        ; disable <SHIFT + CBM> by writing zero into MODE
        sta $cf          ; the cursor blink flag, set BLNON on
        lda #$48
        sta $028f
        lda #$eb          ; set the KEYLOG vector to point at $eb48
        sta $0290
        lda #$0a          ; set max number of character is keyboard buffer to 10
        sta $0289        ; XMAX
        sta $028c        ; How many 1/60 of a second to wait before key is
                        ; repeated. Used together with $028b
        lda #$0e          ; set character colour to light blue
        sta $0286        ; COLOR
        lda #$04          ; How many $028c before a new entry is
        sta $028b        ; put in the keyboard buffer, KOUNT
        lda #$0c
        sta $cd          ; store in BLCNT, cursor toggle timer
        sta $cc          ; store in BLNSW, cursor enable
```

#### **E544 CLEAR SCREEN**

This routine sets up the screen line link table (\$d9 - \$f2), LDTB1, which is used to point out the address to the screen. The later part of the routine performs the screen clear, line by line, starting at the bottom line. It continues to the next routine which is used to home the cursor.

```
.e544  lda $0288          ; get HIBASE, top of screen memory
        ora #$80          ; fool around
        tay
        lda #$00
        tax
.e54d  sty $d9,x          ; store in screen line link table, LDTB1
        clc
        adc #$28          ; add #40 to next line
```

```

        bcc $e555
        iny                ; inc page number
.e555   inx                ; next
        cpx #$1a          ; till all 26?? is done
        bne $e54d
        lda #$ff
        sta $d9,x         ; last pointer is $ff
        ldx #$18          ; start clear screen with line $18 (bottom line)
.e560   jsr $e9ff         ; erase line (X)
        dex                ; next
        bpl $e560         ; till screen is empty

```

#### **E566 HOME CURSOR**

This routine puts the cursor in the top left corner by writing its column and line to zero.

```

.e566   ldy #$00
        sty $d3           ; write to PNTR, cursor column
        sty $d6           ; write to TBLX, line number

```

#### **E56C SET SCREEN POINTRES**

This routine positions the cursor on the screen and sets up the screen pointers. On entry, TBLX must hold the line number, and PNTR the column number of the cursor position. A major bug has been removed from the original commodore KERNAL. It sometimes caused the computer to crash, when deleting characters from the bottom line.

```

.e56c   ldx $d6           ; read TBLX
        lda $d3           ; read PNTR
.e570   ldy $d9,x         ; read value from screen line link table, LDTB1
        bmi $e57c         ; heavy calcuations??? jump when ready
        clc
        adc #$28
        sta $d3           ; PNTR
        dex
        bpl $e570
.e57c   jsr $e9f0         ; set start of line (X)
        lda #$27
        inx
.e582   ldy $d9,x         ; LDTB1
        bmi $e58c
        clc
        adc #$28
        inx
        bpl $e582
.e58c   sta $d5           ; store in LMNX, physical screen line length
        jmp $ea24         ; sync color pointer
.e591   cpx $c9           ; read LXSP, check cursor at start of input
        beq $e598
        jmp $e6ed         ; retreat cursor
.e598   rts

        nop                ; A free byte!!! (own serial number haha)

```

#### **E59A SET I/O DEFAULTS**

The default output device is set to 3 (screen), and the default input device is set to 0 (keyboard). The VIC chip registers are set from the video chip setup table. The cursor is then set to the home position.

```
.e59a  jsr $e5a0          ; set I/O defaults
      jmp $e566          ; home cursor and exit routine
.e5a0  lda #$03
      sta $9a            ; DFLT0, default output device - screen
      lda #$00
      sta $99            ; DFLTn, default input device - keyboard
      ldx #$2f
.e5aa  lda $ecb8,x        ; VIC chip setup table
      sta $cfff,x        ; VIC chip I/O registers
      dex                ; next
      bne $e5aa          ; till ready
      rts
```

#### **E5B4 LP2: GET CHARACTER FROM KEYBOARD BUFFER**

It is assumed that there is at least one character in the keyboard buffer. This character is obtained and the rest of the queue is moved up one by one to overwrite it. On exit, the character is in (A).

```
.e5b4  ldy $0277          ; read KEYD, first character in keyboard buffer queue
      ldx #$00
.e5b9  lda $0278,x        ; overwrite with next in queue
      sta $0277,x
      inx
      cpx $c6            ; compare with NDX, number of characters in queue
      bne $e5b9          ; till all characters are moved
      dec $c6            ; decrement NDX
      tya                ; transfer read character to (A)
      cli                ; enable interrupt
      clc
      rts
```

#### **E5CA INPUT FROM KEYBOARD**

This routine uses the previous routine to get characters from the keyboard buffer. Each character is output to the screen, unless it is <shift/RUN>. If so, the contents of the keyboard buffer is replaced with LOAD <CR> RUN <CR>. The routine ends when a carriage routine is encountered. The JSR at \$e5e7 is a patch in JiffyDOS to test if the F-keys or other valid JiffyDOS keys are pressed. If not, this routine continues as normal.

```
.e5ca  jsr $e716          ; output to screen
.e5cd  lda $c6            ; read NDX, number of characters in keyboard queue
      sta $cc            ; BLNSW, cursor blink enable
      sta $0292          ; AUTODN, auto scroll down flag
      beq $e5cd          ; loop till key is pressed
      sei                ; disable interrupt
      lda $cf            ; BLNON, last cursor blink (on/off)
      beq $e5e7
      lda $ce            ; GDBLN, character under cursor
      ldx $0287          ; GDCOL, background color under cursor
      ldy #$00
      sty $cf            ; clear BLNON
      jsr $ea13          ; print to screen
.e5e7  jsr $f9e5          ; Get character from keyboard buffer. JiffyDOS fixxx
```

```

        cmp #$83          ; test if <shift/RUN> is pressed
        bne $e5fe         ; nope
        ldx #$09          ; transfer 'LOAD <CR> RUN <CR>' to keyboard buffer
        sei
        stx $c6           ; store #9 in NDX, characters in buffer
.e5f3   lda $e6,x          ; 'LOAD <CR> RUN <CR>' message in ROM
        sta $0276,x       ; store in keyboard buffer
        dex
        bne $e5f3         ; all nine characters
        beq $e5cd         ; allways jump
.e5fe   cmp #$0d          ; carriage return pressed?
        bne $e5ca         ; nope, go to start
        ldy $d5           ; get LNMx, screen line length
        sty $d0           ; CRSV, flag input/get from keyboard
.e606   lda ($d1),y       ; PNTR, screen address
        cmp #$20          ; space?
        bne $e60f         ; nope
        dey
        bne $e606         ; next
.e60f   iny
        sty $c8           ; store in INDx, end of logical line for input
        ldy #$00
        sty $0292         ; AUTODN
        sty $d3           ; PNTR, cursor column
        sty $d4           ; QTSW, reset quote mode
        lda $c9           ; LXSP, corsor X/Y position
        bmi $e63a
        ldx $d6           ; TBLX, cursor line number
        jsr $e591         ; retreat cursor
        cpx $c9           ; LXSP
        bne $e63a
        lda $ca
        sta $d3           ; PNTR
        cmp $c8           ; INDx
        bcc $e63a
        bcs $e65d

```

#### **E632 INPUT FROM SCREEN OR KEYBOARD**

This routine is used by INPUT to input data from devices not on the serial bus, ie. from screen or keyboard. On entry (X) and (Y) registers are preserved. A test is made to determine which device the input is to be from. If it is the screen, then quotes and <RVS> are tested for and the character is echoed on the screen. Keyboard inputs make use of the previous routine.

```

.e632   tya              ; preserve (X) and (Y) registers
        pha
        txa
        pha
        lda $d0          ; CRSW, INPUT/GET from keyboard or screen
        beq $e5cd         ; input from keyboard
.e63a   ldy $d3           ; PNTR, cursor column
        lda ($d1),y       ; read from current screen address
        sta $d7           ; temp store
        and #$3f
        asl $d7
        bit $d7
        bpl $e64a

```

```

        ora #$80
.e64a  bcc $e650
        ldx $d4          ; QTSW, editor in quotes mode
        bne $e654        ; yepp
.e650  bvs $e654
        ora #$40
.e654  inc $d3          ; PNTR
        jsr $e684        ; do quotes test
        cpy $c8          ; INDX, end of logical line for input
        bne $e674
.e65d  lda #$00
        sta $d0          ; CRSW
        lda #$0d
        ldx $99          ; DFLTn, default input device
        cpx #$03          ; screen
        beq $e66f        ; yes
        ldx $9a          ; DFLT0, default output device
        cpx #$03          ; screen
        beq $e672        ; yes
.e66f  jsr $e716        ; output to screen
.e672  lda #$0d
.e674  sta $d7
        pla
        tax              ; restore (X) and (Y) registers
        pla
        tay
        lda $d7
        cmp #$de
        bne $e682
        lda #$ff
.e682  clc
        rts

```

#### **E684 QUOTES TSET**

On entry, (A) holds the character to be tested. If (A) holds ASCII quotes, then the quotes flag is toggled.

```

.e684  cmp #$22          ; ASCII quotes (")
        bne $e690        ; nope, return
        lda $d4          ; QTSW, quotes mode flag
        eor #$01        ; toggle on/off
        sta $d4          ; store
        lda #$22        ; restore (A) to #$22
.e690  rts

```

#### **E691 SET UP SCREEN PRINT**

The RVS flag is tested to see if reversed characters are to be printed. If insert mode is on, the insert counter is decremented by one. When in insert mode, all characters will be displayd, ie. DEL RVS etc. The character colour is placed in (X) and the character is printed to the scrren and the cursor advanced.

```

.e691  ora #$40
.e693  ldx $c7          ; test RVS, flag for reversed characters
        beq $e699        ; nope
.e697  ora #$80          ; set bit 7 to reverse character
.e699  ldx $d8          ; test INSRT, flag for insert mode

```

```

        beq $e69f          ; nope
        dec $d8            ; decrement number of characters left to insert
.e69f   ldx $0286          ; get COLOR, current character colour code
        jsr $ea13          ; print to screen
        jsr $e6b6          ; advance cursor
.e6a8   pla
        tay
        lda $d8            ; INSRT
        beq $e6b0
        lsr $d4
.e6b0   pla
        tax
        pla
        clc
        cli
        rts

```

#### **E6B6 ADVANCE CURSOR**

The cursor is advanced one position on the screen. If this puts it beyond the 40th column, then it is placed at the beginning of the next line. If the length of that line is less than 80, then this new line is linked to the previous one. A space is opened if data already exists on the new line. If the cursor has reached the bottom of the screen, then the screen is scrolled down.

```

.e6b6   jsr $e8b3          ; check line increment
        inc $d3            ; increment PNTR, cursor column on current line
        lda $d5            ; LNMx, physical screen line length
        cmp $d3            ; compare to PNTR
        bcs $e700          ; not beyond end of line, exit
        cmp #$4f           ; $4f = 79
        beq $e6f7          ; put cursor on new logical line
        lda $0292          ; AUTODN, auto scroll down flag
        beq $e6cd          ; auto scroll is on
        jmp $e967          ; open a space on the screen
.e6cd   ldx $d6            ; read TBLX, current line number
        cpx #$19           ; $19 = 25
        bcc $e6da          ; less than 25
        jsr $e8ea          ; scroll down
        dec $d6            ; place cursor on line 24
        ldx $d6
.e6da   asl $d9,x          ; clear bit7 in LDTB1 to indicate that it is line 2
        lsr $d9,x          ; in the logical line
        inx                ; next line
        lda $d9,x          ; set bit7 in LDTB1 to indicate that it is line 1
        ora #$80           ; in the logical line
        sta $d9,x
        dex
        lda $d5            ; add $28 (40) to LNMx to allow 80 characters
        clc                ; on the logical line
        adc #$28
        sta $d5

```

#### **E6ED RETREAT CURSOR**

The screen line link table is searched, and then the start of line is set. The rest of the routine sets the cursor onto the next line for the previous routine.

```

.e6ed  lda $d9,x          ; LDTB1, screen line link table
      bmi $e6f4          ; test bit7
      dex                ; next line
      bne $e6ed          ; till all are done
.e6f4  jmp $e9f0          ; set start of line
.e6f7  dec $d6            ; decrement TBLX, cursor line
      jsr $e87c          ; goto next line
      lda #$00
      sta $d3            ; set PNTR, the cursor column, to zero
.e700  rts

```

#### **E701 BACK ON TO PREVIOUS LINE**

This routine is called when using <DEL> and <cursor LEFT>. The line number is tested, and if the cursor is already on the top line, then no further action is taken. The screen pointers are set up and the cursor placed at the end of the previous line.

```

.e701  ldx $d6            ; test TBLX, physical line number
      bne $e70b          ; if not on top line, branch
      stx $d3            ; set PNTR to zero as well
      pla
      pla
      bne $e6a8          ; always jump
.e70b  dex                ; decrement TBLX
      stx $d6            ; and store
      jsr $e56c          ; set screen pointers
      ldy $d5            ; get LNMX
      sty $d3            ; and store in PNTR
      rts

```

#### **E716 OUTPUT TO SCREEN**

This routine is part of the main KERNAL CHROUT routine. It prints CBM ASCII characters to the screen and takes care of all the screen editing characters. The cursor is automatically updated and scrolling occurs if necessary. On entry, (A) must hold the character to be output. On entry all registers are stored on the stack. For convinience, the routine is slpit into sections showing the processing of both shifted and unshifted character.

```

.e716  pha                ; store (A), (X) and (Y) on stack
      sta $d7            ; temp store
      txa
      pha
      tya
      pha
      lda #$00
      sta $d0            ; store in CRSW
      ldy $d3            ; PNTR, cursor positions on line
      lda $d7            ; retrieve from temp store
      bpl $e72a          ; do unshifted characters
      jmp $e7d4          ; do shifted characters

```

UNSHIFTED CHARACTERS. Ordinary unshifted ASCII characters and PET graphics are output directly to the screen. The following control codes are trapped and precessed: <RETURN>, <DEL>, <CRSR RIGHT>, <CRSR DOWN>. If either insert mode is on or quotes are open (except for <DEL>) then the control characters are not processed, but output as reversed ASCII literals.



```

.e72a  cmp #$0d          ; <RETURN>?
      bne $e731         ; nope
      jmp $e891         ; execute return
.e731  cmp #$20          ; <SPACE>?
      bcc $e745
      cmp #$60          ; #$60, first PET graphic character?
      bcc $e73d
      and #$df          ; %11011111
      bne $e73f
.e73d  and #$3f          ; %00111111
.e73f  jsr $e684         ; do quotes test
      jmp $e693         ; setup screen print
.e745  ldx $d8           ; INSRT, insert mode flag
      beq $e74c         ; mode not set
      jmp $e697         ; output reversed character
.e74c  cmp #$14         ; <DEL>?
      bne $e77e         ; nope
      tya               ; (Y) holds cursor column
      bne $e759         ; not start of line
      jsr $e701         ; back on previous line
      jmp $e773
.e759  jsr $e8a1         ; check line decrement
      dey               ; decrement cursor column
      sty $d3           ; and store in PNTR
      jsr $ea24         ; synchronise colour pointer
.e762  iny               ; copy character at cursor position (Y+1) to (Y)
      lda ($d1),y       ; read character
      dey
      sta ($d1),y       ; and store it one position back
      iny
      lda ($f3),y       ; read character colour
      dey
      sta ($f3),y       ; and store it one position back
      iny               ; more characters to move
      cpy $d5           ; compare with LNMx, length of physical screen line
      bne $e762         ; if not equal, move more characters
.e773  lda #$20          ; store <SPACE> at end of line
      sta ($d1),y
      lda $0286         ; COLOR, current character colour
      sta ($f3),y       ; store colour at end of line
      bpl $e7cb         ; allways jump
.e77e  ldx $d4           ; QTSW, editor in quotes mode
      beq $e785         ; no
      jmp $e697         ; output reversed character
.e785  cmp #$12         ; <RVS>?
      bne $e78b         ; no
      sta $c7           ; RVS, reversed character output flag
.e78b  cmp #$13         ; <HOME>?
      bne $e792         ; no
      jsr $e566         ; home cursor
.e792  cmp #$1d         ; <CRSR RIGHT>?
      bne $e7ad         ; nope
      iny               ; increment (Y), internal counter for column
      jsr $e8b3         ; check line increment
      sty $d3           ; store (Y) in PNTR
      dey               ; decrement (Y)
      cpy $d5           ; and compare to LNMx

```

```

        bcc $e7aa          ; not exceeded line length
        dec $d6            ; TBLX, current physical line number
        jsr $e87c          ; goto next line
        ldy #$00
.e7a8   sty $d3            ; set PNTR to zero, cursor to the left
.e7aa   jmp $e6a8          ; finish screen print
.e7ad   cmp #$11           ; <CRSR DOWN>?
        bne $e7ce          ; no
        clc                ; prepare for add
        tya                ; (Y) holds cursor column
        adc #$28           ; add 40 to next line
        tay                ; to (Y)
        inc $d6            ; increment TBLX, physical line number
        cmp $d5            ; compare to LNMX
        bcc $e7a8          ; finish screen print
        beq $e7a8          ; finish screen print
        dec $d6            ; restore TBLX
.e7c0   sbc #$28
        bcc $e7c8
        sta $d3            ; store PNTR
        bne $e7c0
.e7c8   jsr $e87c          ; go to next line
.e7cb   jmp $e6a8          ; finish screen print
.e7ce   jsr $e8cb          ; set colour code
        jmp $ec44          ; do graphics/text control

```

SHIFTED CHARACTERS. These are dealt with in the following order: Shifted ordinar ASCII and PET graphics characters, <shift RETURN>, <INST>, <CRSR UP>, <RVS OFF>, <CRSR LEFT>, <CLR>. If either insert mode is on, or quotes are open, then the control character is not processed but reversed ASCII literal is printed.

```

.e7d4   and #$7f           ; clear bit7
        cmp #$7f           ; compare to #$7f
        bne $e7dc          ; not equal
        lda #$5e           ; if #$7f, load #$5e
.e7dc   cmp #$20           ; ASCII <SPACE>?
        bcc $e7e3
        jmp $e691          ; set up screen print
.e7e3   cmp #$0d           ; <RETURN>?
        bne $e7ea          ; nope
        jmp $e891          ; do return
.e7ea   ldx $d4            ; read QTSW
        bne $e82d          ; if quotes mode, jump
        cmp #$14           ; <INST>?
        bne $e829          ; nope
        ldy $d5            ; LNMX
        lda ($d1),y        ; get screen character
        cmp #$20           ; space?
        bne $e7fe          ; nope
        cpy $d3            ; PNTR equal to LNMX
        bne $e805          ; nope
.e7fe   cpy #$4f           ; #$4f=79, last character
        beq $e826          ; end of logical line, can not insert
        jsr $e965          ; open space on line
.e805   ldy $d5            ; LNMX
        jsr $ea24          ; synchronise colour pointer

```

```

.e80a  dey                ; prepare for move
      lda ($d1),y        ; read character at pos (Y)
      iny
      sta ($d1),y        ; and move one step to the right
      dey
      lda ($f3),y        ; read character colour
      iny
      sta ($f3),y        ; move one step to the right
      dey                ; decrement counter
      cpy $d3            ; compare with PNTR
      bne $e80a          ; till all characters right of cursor are moved
      lda #$20            ; <SPACE>, ASCII #$20
      sta ($d1),y        ; store at new character position
      lda $0286           ; COLOR, current character colour
      sta ($f3),y        ; store at new colour position
      inc $d8             ; INSRT FLAG
.e826  jmp $e6a8          ; finish screen print
.e829  ldx $d8            ; INSRT FLAG
      beq $e832          ; insert mode is off
.e82d  ora #$40
      jmp $e697          ; set up screen print
.e832  cmp #$11           ; <CRSR UP>?
      bne $e84c          ; nope
      ldx $d6            ; read TBLX
      beq $e871          ; at topline, do nothing
      dec $d6            ; else decrement TBLX
      lda $d3            ; PNTR
      sec                ; prepare for subtract
      sbc #$28           ; back 40 columns for double line
      bcc $e847          ; skip
      sta $d3            ; store PNTR
      bpl $e871          ; finish screen print
.e847  jsr $e56c          ; set screen pointer
      bne $e871          ; finish screen print
.e84c  cmp #$12           ; <RVS OFF>?
      bne $e854          ; nope
      lda #$00
      sta $c7            ; RVS, disable reverse print
.e854  cmp #$1d           ; <CRSR LEFT>?
      bne $e86a          ; nope
      tya                ; (Y) holds cursor column
      beq $e864          ; at first position
      jsr $e8a1          ; check line decrement
      dey                ; one position left
      sty $d3            ; store in PNTR
      jmp $e6a8          ; finish screen print
.e864  jsr $e701          ; back to previous line
      jmp $e6a8          ; finish screen print
.e86a  cmp #$13           ; <CLR>?
      bne $e874          ; nope
      jsr $e544          ; clear screen
.e871  jmp $e6a8          ; finish screen print
.e874  ora #$80
      jsr $e8cb          ; set colour code
      jmp $ec4f          ; set graphics/text mode

```

**E87C GO TO NEXT LINE**

The cursor is placed at the start of the next logical screen line. This involves moving down two lines for a linked line. If this places the cursor below the bottom of the screen, then the screen is scrolled.

```
.e87c  lsr $c9          ; LXSP, cursor X-Y position
      ldx $d6          ; TBLX, current line number
.e880  inx              ; next line
      cpx #$19          ; 26th line
      bne $e888          ; nope, scroll is not needed
      jsr $e8ea          ; scroll down
.e888  lda $d9,x        ; test LTDB1, screen line link table if first of two
      bpl $e880          ; yes, jump down another line
      stx $d6          ; store in TBLX
      jmp $e56c          ; set screen pointers
```

#### **E891 OUTPUT <CARRIAGE RETURN>**

All editor modes are swithed off and the cursor placed at the start of the next line.

```
.e891  ldx #$00
      stx $d8          ; INSRT, disable insert mode
      stx $c7          ; RVS, disable reversed mode
      stx $d4          ; QTSW, disable quotes mode
      stx $d3          ; PNTR, put cursor at first column
      jsr $e87c          ; go to next line
      jmp $e6a8          ; finish screen print
```

#### **E8A1 CHECK LINE DECREMENT**

When the cursor is at the beginning of a screen line, if it is moved backwards, this routine places the cursor at the end of the line above. It tests both column 0 and column 40.

```
.e8a1  ldx #$02
      lda #$00
.e8a5  cmp $d3          ; test if PNTR is at the first column
      beq $e8b0          ; yepp
      clc              ; add $28 (40)
      adc #$28          ; to test if cursor is at line two in the logical line
      dex
      bne $e8a5          ; test two lines
      rts
.e8b0  dec $d6          ; decrement line number
      rts
```

#### **E8B3 CHECK LINE INCREMENT**

When the cursor is at the end of the screen, if it is moved forward, this routine places the cursor at the start of the line below.

```
.e8b3  ldx #$02
      lda #$27          ; start by testing position $27 (39)
.e8b7  cmp $d3          ; compare with PNTR
      beq $e8c2          ; brach if equal, and move cursor down
      clc              ; else, add $28 to test next physical line
      adc #$28
      dex              ; two lines to test
      bne $e8b7
      rts              ; return here without moving cursor down
```

```

.e8c2  ldx $d6          ; get TBLX
       cpx #$19        ; and test if at the 25th line
       beq $e8ca       ; yepp, return without moving down
       inc $d6         ; increment TBLX
.e8ca  rts

```

#### **E8CB SET COLOUR CODE**

This routine is called by the output to screen routine. The Commodore ASCII code in (A) is compared with the ASCII colout code table. If a match is found, then the table offset (and hence the colour value) is stored in COLOR.

```

.e8cb  ldx #$0f          ; 16 values to be tested
.e8cd  cmp $e8da,x      ; compare with colour code table
       beq $e8d6       ; found, jump
       dex             ; next colour in table
       bpl $e8cd       ; till all 16 are tested
       rts             ; if not found, return
.e8d6  stx $0286        ; if found, store code in COLOR
       rts

```

#### **E8DA COLOUR CODE TABLE**

This is a table containing 16 Commodore ASCII codes representing the 16 available colours. Thus red is represented as \$1c in the table, and would be obtained by PRINT CHR\$(28), or poke 646,2.

```

.e8da  90              ; color0, black
.e8db  05              ; color1, white
.e8dc  1c              ; color2, red
.e8dd  9f              ; color3, cyan
.e8de  9c              ; color4, purple
.e8df  1e              ; color5, green
.e8e0  1f              ; color6, blue
.e8e1  9e              ; color7, yellow
.e8e2  81              ; color8, orange
.e8e3  95              ; color9, brown
.e8e4  96              ; colorA, pink
.e8e5  97              ; colorB, grey1
.e8e6  98              ; colorC, grey2
.e8e7  99              ; colorD, light green
.e8e8  9a              ; colorE, light blue
.e8e9  9b              ; colorF, grey3

```

#### **E8EA SCROLL SCREEN**

This routine scrolls the screen down by one line. If the top two lines are linked together, then the scroll down is repeated. The screen line link pointers are updated, each screen line is cleared and the line below is moved up. The keyboard is directly read from CIA#1, and the routine tests if <CTRL> is pressed. A JiffyDOS feature is the <CTRL S> option, which freezes the scroll till another key is pressed.

```

.e8ea  lda $ac          ; temp store SAL on stack
       pha
       lda $ad
       pha
       lda $ae          ; temp store EAL on stack
       pha
       lda $af

```

```

pha
.e8f6  ldx #$ff
      dec $d6          ; decrement TBLX
      dec $c9          ; decrement LXSP
      dec $02a5        ; temp store for line index
.e8ff  inx
      jsr $e9f0        ; set start of line (X)
      cpx #$18
      bcs $e913
      lda $ecf1,x      ; read low-byte screen addresses
      sta $ac
      lda $da,x
      jsr $e9c8        ; move a screen line
      bmi $e8ff
.e913  jsr $e9ff        ; clear a screen line
      ldx #$00
.e918  lda $d9,x        ; calculate new screen line link table
      and #$7f         ; clear bit7
      ldy $da,x
      bpl $e922
      ora #$80         ; set bit7
.e922  sta $d9,x        ; store new value in table
      inx              ; next line
      cpx #$18        ; till all 25 are done
      bne $e918
      lda $f1          ; bottom line link
      ora #$80         ; unlink it
      sta $f1          ; and store back
      lda $d9          ; test top line link
      bpl $e8f6        ; line is linked, scroll again
      inc $d6          ; increment TBLX
      inc $02a5
.e938  jsr $eb42        ; lda #$7f, sta $dc00, rts
      lda $dc01        ; read keyboard decode column
      cmp #$fb         ; <CTRL> pressed
      bne $e956        ; nope, exit
      ldx $c6          ; NDX, number of characters in keyboard buffer
      beq $e938        ; freeze scroll as long as <CTRL> is pressed
      lda $0276,x      ; read character from keyboard buffer
      sbc #$13         ; subtract $13, "S"
      bne $e956        ; nope, did not press "S"
      sta $c6          ; clear NDX
.e94f  cli              ; allow interrupts
      cmp $c6          ; any new character in buffer
      beq $e94f        ; nope, still freeze
      sta $c6          ; clear NDX
.e956  ldx $d6          ; read TBLX
.e958  pla              ; retrieve EAL
      sta $af
      pla
      sta $ae
      pla              ; retrieve SAL
      sta $ad
      pla
      sta $ac
      rts              ; exit

```

#### **E965 OPEN A SPACE ON THE SCREEN**

This routine opens a space on the screen for use with <INST>. If needed, the screen is then scrolled down, otherwise the screen line is moved and cleared. Finally the screen line link table is adjusted and updated.

```
.e965  ldx $d6          ; TBLX, current cursor line number
.e967  inx             ; test next
      lda $d9,x       ; LDTB1, screen line link table
      bpl $e967
      stx $02a5       ; temp line for index
      cpx #$18        ; bottom of screen
      beq $e981       ; yes
      bcc $e981       ; above bottom line
      jsr $e8ea       ; scroll screen down
      ldx $02a5       ; temp line for index
      dex
      dec $d6         ; TBLX
      jmp $e6da       ; adjust link table and end
.e981  lda $ac         ; push SAL, scrolling pointer
      pha
      lda $ad
      pha
      lda $ae         ; push EAL, end of program
      pha
      lda $af
      pha
      ldx #$19
.e98f  dex
      jsr $e9f0       ; set start of line
      cpx $02a5       ; temp line for index
      bcc $e9a6
      beq $e9a6
      lda $ecef,x     ; screen line address table
      sta $ac         ; SAL
      lda $d8,x       ; LDTB1
      jsr $e9c8       ; move screen line
      bmi $e98f
.e9a6  jsr $e9ff       ; clear screen line
      ldx #$17        ; fix screen line link table
.e9ab  cpx $02a5       ; temp line for index
      bcc $e9bf
      lda $da,x       ; LDTB1+1
      and #$7f
      ldy $d9,x       ; LDTB1
      bpl $e9ba
      ora #$80
.e9ba  sta $da,x
      dex             ; next line
      bne $e9ab       ; till line zero
.e9bf  ldx $02a5       ; temp line for index
      jsr $e6da       ; adjust link table
      jmp $e958       ; pull SAL and EAL
```

#### **E9C8 MOVE A SCREEN LINE**

This routine synchronises colour transfer, and then moves the screen line pointed to down, character by character. The colour codes for each character are also moved in the same way.

```

.e9c8  and #$03
      ora $0288          ; HIBASE, top of screen page
      sta $ad            ; store >SAL, screen scroll pointer
      jsr $e9e0          ; synchronise colour transfer
      ldy #$27           ; offset for character on screen line
.e9d4  lda ($ac),y        ; move screen character
      sta ($d1),y
      lda ($ae),y        ; move character colour
      sta ($f3),y
      dey                ; next character
      bpl $e9d4          ; till all 40 are done
      rts

```

#### **E9E0 SYNCHRONISE COLOUR TRANSFER**

This routine setd up a temporary pointer in EAL to the colour RAM address that corresponsts to the temporary screen address held in EAL.

```

.e9e0  jsr $ea24          ; synchronise colour pointer
      lda $ac             ; SAL, pointer for screen scroll
      sta $ae             ; EAL
      lda $ad
      and #$03
      ora #$d8            ; setup colour ram to $d800
      sta $af
      rts

```

#### **E9F0 SET START OF LINE**

On entry, (X) holds the line number. The low byte of the address is set from the ROM table, and the highbyte derived from the screen link and HIBASE.

```

.e9f0  lda $ecf0,x        ; table of screen line to bytes
      sta $d1             ; <PNT, current screen line address
      lda $d9,x           ; LDTB1, screen line link table
      and #$03
      ora $0288           ; HIBASE, page of top screen
      sta $d2             ; >PNT
      rts

```

#### **E9FF CLEAR SCREEN LINE**

The start of line is set and the screen line is cleared by filloing it with ASCII spaces. The corresponding line of colour RAM is also cleared to the value held in COLOR.

```

.e9ff  ldy #$27
      jsr $e9f0          ; set start of line
      jsr $ea24          ; synchronise colour pointer
.ea07  jsr $e4da          ; reset character colour, to COLOR
      lda #$20           ; ASCII space
      sta ($d1),y        ; store character on screen
      dey                ; next
      bpl $ea07          ; till hole line is done
      rts

      nop                ; free byte

```

#### **EA13 PRINT TO SCREEN**



The colour pointer is synchronised, and the character in (A) directly stored in the screen RAM. The character colour in (X) is stored at the equivalent point in the colour RAM.

```
.ea13  tay                ; put print character in (Y)
        lda #$02
        sta $cd           ; store in BLNCT, timer to toggle cursor
        jsr $ea24         ; synchronise colour pointer
        tya               ; print character back to (A)
.ea1c  ldy $d3            ; PNTR, cursor column on line
        sta ($d1),y       ; store character on screen
        txa
        sta ($f3),y       ; stor character colour
        rts
```

#### **EA24 SYNCHRONISE COLOUR POINTER**

The pointer to the colour RAM is set up according to the current screen line address. This is done by reading the current screen line address and modefying it to colour RAM pointers and write it to USER at \$f3/\$f4

```
.ea24  lda $d1            ; copy screen line low byte
        sta $f3           ; to colour RAM low byte
        lda $d2           ; read'n modify the hi byte
        and #$03
        ora #$d8
        sta $f4           ; to suite the colour RAM
        rts
```

#### **EA31 MAIN IRQ ENTRY POINT**

This routine services the normal IRQ that jumps through the hardware vector to \$ff48, and then continues to the CINV vector at \$0314. First it checks if the <STOP> key was pressed and updates the realtime clock. Next, the cursor is updated (if it is enabled, BLNSW). The blink counter, BLNCT, is decremented. When this reaches zero, the cursor is toggled (blink on/off). Finally it scans the keyboard. The processor registers are then restored on exit. Area from \$ea64 to \$ea7b has been changed in the JiffyDOS system. Some routintes to handle the casetterecorder has been removed.

```
.ea31  jsr $ffea          ; update realtime clock, routine UDTIM
        lda $cc           ; read BLNSW to see if cursor is enabled
        bne $ea61         ; nope
        dec $cd           ; read BLNCT
        bne $ea61         ; if zero, toggle cursor - else jump
        lda #$14          ; blink speed
        sta $cd           ; restore BLCNT
        ldy $d3           ; get PNTR, cursor column
        lsr $cf           ; BLNON, flag last cursor blink on/off
        ldx $0287         ; get background colour under cursor, GDCOL
        lda ($d1),y       ; get screen character
        bcs $ea5c         ; ?
        inc $cf           ; increment BLNON
        sta $ce           ; temporary store character under cursor
        jsr $ea24         ; synchronise colour pointer
        lda ($f3),y       ; get colour under character
        sta $0287         ; store in GDCOL
        ldx $0286         ; get current COLOR
        lda $ce           ; retrieve character under cursor
```

```
.ea5c eor #$80          ; toggle cursor by inverting character
      jsr $ea1c        ; print to screen by using part of 'print to screen'
.ea61 jmp $ea7b        ; skip
```

#### **EA64 JIFFYDOS CRNCH**

The ICRNCH VECTOR points to this routine after the JiffyDOS init.

```
.ea64 pla              ; get last stack entry
      pha              ; put back
      cmp #$98         ; equal to #$98
      beq $ea6d        ; yepp, do JiffyDOS CRNCH
.ea6a jmp $a57c        ; jump to original CRNCH
.ea6d jsr $f72c        ; test if key in buffer is a JiffyDOS command
      bne $ea6a        ; no command
      ldx $7a          ; position i keyboardbuffer
      ldy #$04         ; setup values for old routine
      tya
      jmp $a5e3        ; back into old CRNCH
```

```
byte .xxx              ; free byte?? serialnumber!!
```

#### **EA7B QUICK IRQ ENTRY POINT**

If you dont want the screenupdate, of if you take care of it yourself, you can use this quick exit, specially \$ea81.

```
.ea7b jsr $ea87        ; scan keyboard
      lda $dc0d        ; clear CIA#1 I.C.R to enable next IRQ
.ea81 pla              ; restore (Y), (X), (A)
      tay
      pla
      tax
      pla
      rti              ; back to normal
```

#### **EA87 SCNKEY: SCAN KEYBOARD**

The KERNAL routine SCNKEY (\$ff9f) jumps to this routine. First, the shift-flag, SHFLAG, is cleared, and the keyboard tested for nokey. The keyboard is set up as a 8 \* 8 matrix, and is read one row at a time. \$ff indicates that no key has been pressed, and a zerobit, that one key has been pressed.

```
.ea87 lda #$00
      sta $028d        ; clear SHFLAG
      ldy #$40
      sty $cb
      sta $dc00        ; store in keyboard write register
      ldx $dc01        ; keyboard read register
      cpx #$ff        ; no key pressed
      beq $eafb        ; skip
      tay
      lda #$81        ; point KEYTAB vector to $eb81
      sta $f5
      lda #$eb
      sta $f6
      lda #$fe        ; bit0 = 0
      sta $dc00        ; will test first row in matrix
.eaa8 ldx #$08        ; scan 8 rows in matrix
      pha              ; temp store
```

```

.eaab  lda $dc01          ; read
      cmp $dc01          ; wait for value to settle (key bouncing)
      bne $eaab
.eab3  lsr a              ; test bit0
      bcs $eacc          ; no key pressed
      pha
.eab7  lda ($f5),y        ; get key from KEYTAB
      cmp #$05          ; value less than 5
      bcs $eac9          ; nope
      cmp #$03          ; value = 3
      beq $eac9          ; nope
      ora $028d
      sta $028d          ; store in SHFLAG
      bpl $eacb
.eac9  sty $cb            ; store keynumber we pressed in SFDX
.eacb  pla
.eacc  iny              ; key counter
      cpy #$41          ; all 64 keys (8*8)
      bcs $eadc          ; jump if ready
      dex              ; next key in row
      bne $eab3          ; row ready
      sec              ; prepare for rol
      pla
      rol a              ; next row
      sta $dc00          ; store bit
      bne $eaa8          ; always jump
.eadc  pla              ; clean up

```

#### **EADD PROCESS KEY IMAGE**

This routine decodes the pressed key, and calculates its ASCII value, by use of the four tables. If the pressed key is the same key as in the former interrupt, then the key-repeat-section is entered. The routine tests the RPTFLG if the key shall repeat. The new key is stored in the keyboard buffer, and all pointers are updated.

```

.eadd  jmp ($028f)        ; jump through KEYLOG vector, points to $eae0
.eae0  ldy $cb            ; SFDX, number of the key we pressed
      lda ($f5),y        ; get ASCII value from decode table
      tax              ; temp store
      cpy $c5            ; same key as former interrupt
      beq $eaf0          ; yepp
      ldy #$10           ; restore the repeat delay counter
      sty $028c          ; DELAY
      bne $eb26          ; always jump
.eaf0  and #$7f
      bit $028a          ; RPTFLG, test repeat mode
      bmi $eb0d          ; repeat all keys
      bvs $eb42          ; repeat none - exit routine
      cmp #$7f
.eafb  beq $eb26
      cmp #$14           ; <DEL> key pressed
      beq $eb0d          ; yepp...
      cmp #$20           ; <space> key pressed
      beq $eb0d          ; yepp...
      cmp #$1d           ; <CRSR LEFT/RIGHT>
      beq $eb0d          ; yepp..
      cmp #$11           ; <CRSRS DOWN/UP>

```

```

        bne $eb42          ; yepp..
.eb0d   ldy $028c          ; DELAY
        beq $eb17          ; skip
        dec $028c          ; decrement DELAY
        bne $eb42          ; end
.eb17   dec $028b          ; decremant KOUNT, repeat speed counter
        bne $eb42          ; end
        ldy #$04
        sty $028b          ; init KOUNT
        ldy $c6            ; read NDX, number of keys in keyboard queue
        dey
        bpl $eb42          ; end
.eb26   ldy $cb            ; read SFDX
        sty $c5            ; store in LSTX
        ldy $028d          ; read SHFLAG
        sty $028e          ; store in LSTSHF, last keyboard shift pattern
        cpx #$ff           ; no valid key pressed
        beq $eb42          ; end
        txa
        ldx $c6            ; NDX, number of keys in buffer
        cpx $0289          ; compare to XMAX, max numbers oc characters in buffer
        bcs $eb42          ; buffer is full, end
        sta $0277,x        ; store new character in keyboard buffer
        inx                ; increment counter
        stx $c6            ; and store in NDX
.eb42   lda #$7f
        sta $dc00          ; keyboard write register
        rts                ; exit

.eb48   lda $028d          ; SHFLAG
        cmp #$03           ; <SHIFT> and <CBM> at the same time
        bne $eb64          ; nope
        cmp $028e          ; same as LSTSHF
        beq $eb42          ; if so, end
        lda $0291          ; read MODE, shift key enable flag
        bmi $eb76          ; end
        lda $d018          ; VIC memory control register
        eor #$02           ; toggle character set, upper/lower case
        sta $d018          ; and store
        jmp $eb76          ; process key image
.eb64   asl a
        cmp #$08           ; test <CTRL>
        bcc $eb6b          ; nope
        lda #$06           ; set offset for ctrl
.eb6b   tax                ; to (X)
        lda $eb79,x        ; read keyboard select vectors, low byte
        sta $f5            ; store in KEYTAB, decode table vector
        lda $eb7a,x        ; read keyboard select vectors, high byte
        sta $f6            ; KEYTAB+1
.eb76   jmp $eae0          ; process key image

```

#### **EB79 KEYBOARD SELECT VECTORS**

This is a table of vectors pointing to the start of the four keyboard decode tables.

```

.eb79   81 eb              ; vector to unshifted keyboard, $eb81
.eb7b   c2 eb              ; vector to shifted keyboard, $ebc2

```

```
.eb7d 03 ec          ; vector to cbm keyboard, $ec03
.eb7f 78 ec          ; vector to ctrl keyboard, $ec78
```

#### **EB81 KEYBOARD 1 - UNSHIFTED**

This is the first of four keyboard decode tables. The ASCII code for the key pressed is at the intersection of the row (written to \$dc00) and the column (read from \$dc01). The matrix values are shown below. Note that left and right shift keys are seperated.

```
.eb81 14 0d 1d 88 85 86 87 11
.eb89 33 57 41 34 5a 53 45 01
.eb91 35 52 44 36 43 46 54 58
.eb99 37 59 47 38 42 48 55 56
.eba1 39 49 4a 30 4d 4b 4f 4e
.eba9 2b 50 4c 2d 2e 3a 40 2c
.ebb1 5c 2a 3b 13 01 3d 5e 2f
.ebb9 31 5f 04 32 20 02 51 03
.ebc1 ff          ; free byte
```

DEL	RETURN	CRSR RI	F7	F1	F3	F5	CRSR DO
3	w	a	4	z	s	e	LE SHIFT
5	r	d	6	c	f	t	x
6	y	g	8	b	h	u	v
9	i	j	0	m	k	o	n
+	p	l	-	.	:	@	,
£	*	;	HOME	RI SHIFT	=	^	/
1	<-	CTRL	2	SPACE	CBM	q	STOP

#### **EBC2 KEYBOARD 2 - SHIFTED**

This is the second of four keyboard decode tables. The ASCII code for the key pressed is at the intersection of the row (written to \$dc00) and the column (read from \$dc01). The matrix values are shown below.

```
.ebc2 94 8d 9d 8c 89 8a 8b 91
.ebca 23 d7 c1 24 da d3 c5 01
.ebd2 25 d2 c4 26 c3 c6 d4 d8
.ebda 27 d9 c7 28 c2 c8 d5 d6
.ebe2 29 c9 ca 30 cd cb cf ce
.ebea db d0 cc dd 3e 5b ba 3c
.ebf2 a9 c0 5d 93 01 3d de 3f
.ebfa 21 5f 04 22 a0 02 d1 83
.ec02 ff          ; free byte
```

INST	RRETURN	CRSR LE	F8	F2	F4	F6	CRSR UP
#	W	A	\$	Z	S	E	LE SHIFT
%	R	D	&	C	F	T	X
'	Y	G	(	B	H	U	V
)	I	J	0	M	K	O	N
cbm gr	P	L	cbm gr	>	[	cbm gr	<
cbm gr	cbm gr	[	CLR	RI SHIFT	=	pi	?
!	<-	CTRL	"	SPACE	CBM	Q	RUN

#### **EC03 KEYBOARD 3 - COMMODORE**

This is the third of four keyboard decode tables. The ASCII code for the key pressed is at the intersection of the ro (written to \$dc00) and hte column (read from \$dc01). The matrix values are shown below.

```
.ec03  94 8d 9d 8c 89 8a 8b 91
.ec0b  96 b3 b0 97 ad ae b1 01
.ec13  98 b2 ac 99 bc bb a3 bd
.ec1b  9a b7 a5 9b bf b4 b8 be
.ec23  29 a2 b5 30 a7 a1 b9 aa
.ec2b  a6 af b6 dc 3e 5b a4 3c
.ec33  a8 df 5d 93 01 3d de 3f
.ec3b  81 5f 04 95 a0 02 ab 83
.ec43  ff                ; free byte
```

INST	RETURN	CRSR LE	F8	F2	F4	F6	CRSR UP
pink	cbm gr	cbm gr	grey 1	cbm gr	cbm gr	cbm gr	LE SHIFT
grey 2	cbm gr	cbm gr	li green	cbm gr	cbm gr	cbm gr	cbm gr
li blue	cbm gr	cbm gr	grey 3	cbm gr	cbm gr	cbm gr	cbm gr
)	cbm gr	cbm gr	0	cbm gr	cbm gr	cbm gr	cbm gr
cbm gr	cbm gr	cbm gr	cbm gr	>	[	cbm gr	<
cbm gr	cbm gr	]	CLR	RI SHIFT	=	pi	?
orange	<-	CTRL	brown	SPACE	CBM	cbm gr	RUN

#### **EC44 GRAPHICS / TEXT CONTROL**

This routine is used to toggle between text and graphics character set, and to enable/disable the <shift-CBM> keys. The routine is called by the main 'output to screen' routine, and (A) holds a CBM ASCII code on entry.

```
.ec44  cmp #$0e                ; <switch to lower case>
      bne $ec4f                ; nope
      lda $d018                ; VIC memory control register
      ora #$02                 ; set bit1
      bne $ec58                ; allways branch
.ec4f  cmp #$8e                ; <switch to upper case>
      bne $ec5e                ; nope
      lda $d018                ; VIC memory control register
      and #$fd                 ; clear bit1
.ec58  sta $d018                ; and store
.ec5b  jmp $e6a8                ; finish screen print
.ec5e  cmp #$08                ; <disable <shift-CBM>>
      bne $ec69                ; nope
      lda #$80
      ora $0291                ; disable MODE
      bmi $ec72                ; allways jump
.ec69  cmp #$09                ; <enable <shift-CBM>>
      bne $ec5b                ; nope, exit
      lda #$7f
      and $0291                ; enable MODE
.ec72  sta $0291                ; store MODE, enable/disable shift keys
      jmp $e6a8                ; finish screen print
```

#### **EC78 KEYBOARD 4 - CONTROL**

This is the last keyboard decode table. The ASCII code for the key pressed is at the intersection of the row (written to \$dc00) and the column (read from \$dc01). The matrix values are shown below.

A few special funktion are found in this table ie.

<ctrl H> - disables the upper/lower case switch

<ctrl I> - enables the upper/lower case switch

<ctrl S> - homes the cursor

<ctrl T> - deletes character

Note that the italic keys only represent a ASCII code, and not a CBM character.

Future implementations: Change some of the \$ff values which represents 'no key' to a valid ASCII code. ESC (\$1b) and why not use the F-keys for something useful.

```
.ec78  ff ff ff ff ff ff ff ff
.ec80  1c 17 01 9f 1a 13 05 ff
.ec88  9c 12 04 1e 03 06 14 18
.ec90  1f 19 07 9e 02 08 15 16
.ec98  12 09 0a 92 0d 0b 0f 0e
.eca0  ff 10 0c ff ff 1b 00 ff
.eca8  1c ff 1d ff ff 1f 1e ff
.ecb0  90 06 ff 05 ff ff 11 ff
.ecb8  ff                ; free byte
```

red	<i>W</i>	<i>A</i>	cyan	<i>Z</i>	HOME	white	
purple	RVS ON	<i>D</i>	green	STOP	<i>F</i>	DEL	<i>X</i>
blue	<i>Y</i>	<i>G</i>	yellow	CBM	DISABLE	<i>U</i>	<i>V</i>
RVS ON	ENABLE	<i>J</i>	RVS OFF	RETURN	<i>K</i>	<i>O</i>	LOWER
	<i>P</i>	<i>L</i>			<i>]</i>	<i>@</i>	
red		CRSR RI			blue	green	
	<-		white			CRSR DO	

#### **ECB9 VIDEO CHIP SET UP TABLE**

This is a table of the initial values for the VIC chip registers at start up.

```
.ecb9  00 00                ; $d000/1, sprite0 - x,y cordinate
.ecbb  00 00                ; $d002/3, spritel - x,y cordinate
.ecbd  00 00                ; $d004/5, sprite2 - x,y cordinate
.ecbf  00 00                ; $d006/7, sprite3 - x,y cordinate
.ecc1  00 00                ; $d008/9, sprite4 - x,y cordinate
.ecc3  00 00                ; $d00a/b, sprite5 - x,y cordinate
.ecc5  00 00                ; $d00c/d, sprite6 - x,y cordinate
.ecc7  00 00                ; $d00e/f, sprite7 - x,y cordinate
.ecc9  00                  ; $d010, sprite MSB
.ecca  9b                  ; $d011, VIC control register
.eccb  37                  ; $d012,
.eccc  00 00                ; $d013/4, light pen x/y position
.ecce  00                  ; $d015, sprite enable
.eccf  08                  ; $d016, VIC control register 2
.ecd0  00                  ; $d017, sprite y-expansion
.ecd1  14                  ; $d018, VIC memory control register
.ecd2  0f                  ; $d019, VIC irq flag register
.ecd3  00                  ; $d01a, VIC irq mask register
.ecd4  00                  ; $d01b, sprite/background priority
.ecd5  00                  ; $d01c, sprite multicolour mode
.ecd6  00                  ; $d01d, sprite x-expansion
```

```

.ecd7  00          ; $d01e, sprite/sprite collision
.ecd8  00          ; $d01f, sprite/background collision
.ecd9  0e          ; $d020, border colour (light blue)
.ecda  06          ; $d021, background colour 0 (blue)
.ecdb  01          ; $d022, background colour 1
.ecdc  02          ; $d023, background colour 2
.ecdd  03          ; $d024, background colour 3
.ecde  04          ; $d025, sprite multicolour register 0
.ecdf  00          ; $d026, sprite multicolour register 1
.ece0  01          ; $d027, sprite0 colour
.ece1  02          ; $d028, sprite1 colour
.ece2  03          ; $d029, sprite2 colour
.ece3  04          ; $d02a, sprite3 colour
.ece4  05          ; $d02b, sprite4 colour
.ece5  06          ; $d02c, sprite5 colour
.ece6  07          ; $d02d, sprite6 colour

```

#### **ECE7 SHIFT-RUN EQUIVALENT**

This is the message LOAD <CR> RUN <CR>, which is placed in the keyboard buffer when <shift-RUN> is pressed.

```

.ece7  4c 4f 41 44 0d    ; LOAD <CR>
.ecec  52 55 4e 0d      ; RUN <CR>

```

#### **ECF0 LOW BYTE SCREEN LINE ADDRESSES**

This is a table of the low bytes of screen line addresses. The high byte of the addresses is obtained by derivation from the page on which the screen starts. There was an additional table of high byte addresses on the fixed screen PETs.

```

.ecf0  00 28 50 78 a0
.ecf5  c8 f0 18 40 68
.ecfa  90 b8 e0 08 30
.ecff  58 80 a8 d0 f8
.ed04  20 48 70 98 c0

```

#### **ED09 TALK: SEND 'TALK' / 'LISTEN'**

The KERNAL routine TALK (\$ffb4) and LISTEN (\$ffb1) are vectored here. The routine sends the command 'TALK' or 'LISTEN' on the serial bus. On entry (A) must hold the device number to which the command will be sent. The two entry points differ only in that to TALK, (A) is ORed with #\$40, and to LISTEN, (A) is ORed with #\$20. The UNTALK (\$#3f) and UNLISTEN (\$#5f) are also sent via this routine, but their values are set on entry. If there is a character waiting to go out on the bus, then this is output. Handshaking is performed, and ATN (attention) is set low so that the byte is interpreted as a command. The routine drops through to the next one to output the byte on the serial bus. Note that on conclusion, ATN must be set high.

```

.ed09  ora #$40          ; set TALK flag
      .byte $2c          ; bit $2009, mask ORA command
      ora #$20          ; set LISTEN flag
      jsr $f0a4         ; check serial bus idle
.ed11  pha
      bit $94           ; C3PO, character in serial buffer
      bpl $ed20         ; nope
      sec              ; prepare for ROR
      ror $a3          ; temp data area

```



```

        jsr $fbfe          ; JiffyDOS, send data to serial bus
        lsr $94            ; 3CPO
        lsr $a3
.ed20   pla
        sta $95            ; BSOUR, buffered character for bus
        sei
        jsr $f0ed          ; JiffyDOS, set data 1, and clear serial bit count
        cmp #$3f           ; UNTALK?
        bne $ed2e          ; nope
        jsr $ee85          ; set CLK 1
.ed2e   lda $dd00          ; serial bus I/O port
        ora #$08           ; clear ATN, prepare for command
        sta $dd00          ; store
.ed36   sei               ; disable interrupts
        jsr $ee8e          ; set CLK 1
        jsr $ee97          ; set data 1
        jsr $eeb3          ; delay 1 ms

```

#### **ED40 SEND DATA ON SERIAL BUS**

The byte of data to be output on the serial bus must have been previously stored in the serial buffer, BSOUR. An initial test is made for bus activity, and if none is detected then ST is set to #\$80, ie. ?DEVICE NOT PRESENT. The byte is output by rotating it right and sending the state of the carry flag. This is done eight times until the whole byte was sent. The CIA timer is set to 65 ms and the bus is checked for 'data accepted'. If timeout occurs before this happens then ST is set to #\$03, ie. write timeout. The routine is modified with a jump to \$f8ea where a test is done to see if this device is a JiffyDOS device. The result is stored in \$a3.

```

        sei               ; disable interrupts
        jsr $ee97          ; set data 1
        jsr $eea9          ; get serial in and clock
        bcs $edad          ; no activity, device not present.
        jsr $ee85          ; set CLK 1
        bit $a3            ; temp data area
        bpl $ed5a
.ed50   jsr $eea9          ; get serial in and clock
        bcc $ed50          ; wait for indata = 0
.ed55   jsr $eea9          ; get serial in and clock
.ed58   bcs $ed55          ; wait for indata = 1
.ed5a   jsr $eea9          ; get serial in and clock
        bcc $ed5a          ; wait for indata = 0
        jsr $ee8e          ; set CLK 0

        txa                ; transfer (X) to (A)
        pha                ; store (A) on stack
        ldx #$08           ; output 8 bits
.ed66   pha
        pla
        bit $dd00          ; serial bus I/O port
        bmi $ed72          ; no timeout
        pla                ; retrieve (A)
        tax                ; and restore (X)
        jmp $edb0          ; exit with flag write timeout
.ed72   jsr $ee97          ; serial output 1
        ror $95            ; BSOUR, buffered character for bus
        bcs $ed7c          ; prepare to output 1

```

```

        jsr $eea0          ; else, serial output 0
.ed7c   jsr $ee85          ; set CLK 1
        lda $dd00          ; serial bus I/O port
        and #$df           ; set data 1
        ora #$10           ; set CLK 0
        php
        pha
        jsr $f8ea          ; test if device on serial bus is a JiffyDOS device
        pla
        plp
        dex                ; decrement bit counter
        bne $ed66          ; next bit till all 8 are done
        pla
        tax
        lda #$04
        sta $dc07          ; CIA timer B, high byte
        lda #$19
        sta $dc0f          ; set 1 shot, load and start CIA timer B
        lda $dc0d          ; CIA ICR
.ed9f   lda $dc0d
        and #$02           ; timeout
        bne $edb0          ; yep, flag write timeout
        jsr $eea9          ; get serial in and clock
        bcs $ed9f
        cli                ; enable interrupts
        rts

```

#### **EDAD FLAG ERRORS**

(A) is loaded with one of the two error flags, depending on the entry point. #\$80 signifies the device was not present, and #\$03 signifies a write timeout. The value is then set into the I/O status word, ST. The routine exits by clearing ATN and giving the final handshake.

```

.edad   lda #$80           ; flag ?DEVICE NOT PRESENT
        .byte $2c          ; mask LDA #$03
.edb0   lda #$03           ; flag write timeout
.edb2   jsr $felc          ; set I/O status word
        cli
        clc
        bcc $ee03          ; always jump, do final handshake

```

#### **EDB9 SECOND: SEND LISTEN SA**

The KERNAL routine SECOND (\$ff93) is vectored here. On entry, (A) holds the secondary address. This is placed in the serial buffer and sent to the serial bus "under attension". Finally the routine drops through to the next routine to set ATN false.

```

.edb9   sta $95            ; store (A) in BSOUT, buffer for the serial bus
        jsr $ed36          ; handshake and send byte.

```

#### **EDBE CLEAR ATN**

The ATN, attension, line on the serial bus is set to 1, ie. ATN is now false and data sent on the serial bus will not be interpreted as a command.

```

.edbe   lda $dd00          ; serial bus I/O port
        and #$f7           ; clear bit4, ie. ATN 1
        sta $dd00          ; store to port

```

rts

#### **EDC7 TKSA: SEND TALK SA**

The KERNAL routine TKSA (\$ff96) is vectored here. On entry, (A) holds the secondary address. This is placed in the serial buffer and sent out to the serial bus "under attension". The routine drops through to the next routine to wait for CLK and clear ATN.

```
sta $95          ; BSOUR, the serial bus buffer
jsr $ed36        ; handshake and send byte to the bus
```

#### **EDCC WAIT FOR CLOCK**

This routine sets data = 0, ATN = 1 and CLK = 1. It then waits to recieve CLK = 0 from the serial bus.

```
sei              ; disable interrupts
jsr $eea0        ; set data 0
jsr $edbe        ; set ATN 1
jsr $ee85        ; set CLK 1
.edd6 bit $dd00   ; read serial bus I/O port
bvs $edd6        ; test bit6, and wait for CLK = 0
cli              ; enable interrupt
rts
```

#### **EDDD CIOUT: SEND SERIAL DEFERRED**

The KERNAL routine CIOUT (\$ffa8) jumps to this routine. If there is a character awaiting output in the buffer, then it is sent on the bus to the new JiffyDOS send routine. The output flag, C3PO is set (ie. bit 7 = 1) and the contents of (A) is placed in the serial buffer.

```
.eddd bit $94     ; C3PO flag, character in serial buffer
bmi $ede6        ; yes
sec              ; prepare for ROR
ror $94          ; set C3PO
bne $edeb        ; always jump
.ede6 pha        ; temp store
jsr $fbfe        ; JiffyDOS send data to serial bus
pla
.edeb sta $95     ; store character in BSOUR
clc              ; clear carry to indicate no errors
rts
```

#### **EDEF UNTLK: SEND 'UNTALK'/'UNLISTEN'**

The KERNAL routine UNTALK (\$ffab) and UNLISTEN (\$ffae) are vectored here. ATN is set to 0, and CLK is set to 0. (A) is loaded with #\$5f for 'UNTALK' and #\$3f for 'UNLISTEN'. The command is sent to the serial bus via the 'send TALK/LISTEN' routine. Finally ATN is set to 1, and after a short delay, CLK and data are both set to 1.

```
.edef sei         ; disable interrupts
lda $dd00         ; serial bus I/O
ora #$08          ; set bit4
sta $dd00         ; and store, set ATN 0
jsr $ee8e        ; set CLK 0
lda #$5f         ; flag UNTALK
.byte $2c        ; mask LDA #$3f with BIT $3fa9
lda #$3f         ; flag UNLISTEN
```

```

        jsr $ed11          ; send command to serial bus
.ee03  jsr $edbe          ; clear ATN
.ee06  txa
        ldx #$0a          ; init delay
.ee09  dex               ; decrement counter
        bne $ee09         ; till ready
        tax
        jsr $ee85         ; set CLK 1
        jmp $ee97         ; set data 1

```

### **EE13 ACPTR: RECIEVE FROM SERIAL BUS**

The KERNAL routine ACPTR (\$ffa5) points to this routine in the original Commodore KERNAL. JiffyDOS uses a routine at \$fbaa, which is the new ACPTR pointer. This routine is used when a device is not JiffyDOS equipped. A timing loop is entered using the CIA timer, and if a byte is not received in 65 ms, ST is set to #\$02, ie. a read timeout. A test is made for EOI and if this occurs, ST is set to #\$40, indicating end of file. The byte is then received from the serial bus and built up bit by bit in the temporary stora at #\$a4. This is transfered to (A) on exit, unless EOI has occured.

```

.ee13  jmp $fbaa          ; Jump to JiffyDOS ACPTR, return if no JiffyDOS device
        sta $a5           ; CNTDN, counter
        jsr $ee85         ; set CLK 1
.ee1b  jsr $eea9          ; get serial in and clock
        bpl $ee1b         ; wait for CLK = 1
.ee20  lda #$01
        sta $dc07         ; setup CIA#1 timer B, high byte
        lda #$19
        sta $dc0f         ; set 1 shot, load and start CIA timer B
        jsr $ee97         ; set data 1
        lda $dc0d
.ee30  lda $dc0d         ; read CIA#1 ICR
        and #$02         ; test if timer B reaches zero
        bne $ee3e         ; timeout
        jsr $eea9         ; get serial in and clock
        bmi $ee30         ; CLK 1
        bpl $ee56         ; CLK 0
.ee3e  lda $a5           ; CNTDN
        beq $ee47
        lda #$02         ; flag read timeout
        jmp $edb2         ; set I/O status word
.ee47  jsr $eea0         ; set data 1
        jsr $ee85         ; set CLK 1
        lda #$40         ; flag EOI
        jsr $felc         ; set I/O status word
        inc $a5           ; increment CNTDN, counter
        bne $ee20         ; again
.ee56  lda #$08         ; set up CNTDN to receive 8 bits
        sta $a5
.ee5a  lda $dd00         ; serial bus I/O port
        cmp $dd00         ; compare
        bne $ee5a         ; wait for serial bus to settle
        asl
        bpl $ee5a         ; wait for data in =1
        ror $a4           ; roll in received bit in temp data area
.ee67  lda $dd00         ; serial bus I/O port
        cmp $dd00         ; compare

```

```

        bne $ee67          ; wait for bus to settle
        asl
        bmi $ee67          ; wait for data in =0
        dec $a5            ; one bit received
        bne $ee5a          ; repeat for all 8 bits
        jsr $eea0          ; set data 1
        bit $90            ; STATUS, I/O status word
        bvc $ee80          ; not EOI
        jsr $ee06          ; handshake and exit without byte
.ee80   lda $a4            ; read received byte
        cli               ; enable interrupts
        clc               ; clear carry, no errors
        rts

```

#### **EE85 SERIAL CLOCK ON**

This routine sets the clock outline on the serial bus to 1. This means writing a 0 to the port. This value is reversed by hardware on the bus.

```

.ee85   lda $dd00          ; serial port I/O register
        and #$ef          ; clear bit4, ie. CLK out =1
        sta $dd00          ; store
        rts

```

#### **EE8E SERIAL CLOCK OFF**

This routine sets the clock outline on the serial bus to 0. This means writing a 1 to the port. This value is reversed by hardware on the bus.

```

.ee8e   lda $dd00          ; serial port I/O register
        ora #$10          ; set bit4, ie. CLK out =0
        sta $dd00          ; store
        rts

```

#### **EE97 SERIAL OUTPUT 1**

This routine sets the data out line on the serial bus to 1. This means writing a 0 to the port. This value is reversed by hardware on the bus.

```

.ee97   lda $dd00          ; serial bus I/O register
        and #$df          ; clear bit5
        sta $dd00          ; store
        rts

```

#### **EEA0 SERIAL OUTPUT 0**

This routine sets the data out line on the serial bus to 0. This means writing a 1 to the port. This value is reversed by hardware on the bus.

```

.eea0   lda $dd00          ; serial bus I/O resister
        ora #$20          ; set bit 5
        sta $dd00          ; store
        rts

```

#### **EEA9 GET SERIAL DATA AND CLOCK IN**

The serial port I/O register is stabilised and read. The data is shifted into carry and CLK into bit 7. This way, both the data and clock can be determined by flags in the processor status register. Note that the values read are true, and do not need to be reversed in the same way as the output line do.

```

.eea9   lda $dd00          ; serial port I/O register

```

```

        cmp $dd00          ; compare
        bne $eea9          ; wait for bus to settle
        asl                 ; shift data into carry, and CLK into bit 7
        rts

```

### **EEB3 DELAY 1 MS**

This routine is a software delay loop where (X) is used as counter, and are decremented for a period of 1 millisecond. The original (X) is stored on entry and (A) is messed up.

```

.eeb3  txa                 ; move (X) to (A)
        ldx #$b8           ; start value
.eeb6  dex                 ; decrement
        bne $eeb6          ; untill zero
        tax                ; (A) to (X)
        rts

```

### **EEBB RS232 SEND**

This routine is concerned with sending a byte on the RS232 port. The data is actually written to the port under NMI interrupt control. The CTS line generates an NMI when the port is ready for data. If all the bits in the byte have been sent, then a new RS232 byte is set up. Otherwise, this routine calculates parity and number of stop bits set up in the OPEN command. These bits are added to the end of the byte being sent.

```

.eebb  lda $b4             ; BITTS, RS232 out bit count
        beq $ef06          ; send new RS232 byte
        bmi $ef00
        lsr $b6            ; RODATA, RS232 out byte buffer
        ldx #$00
        bcc $eec8
        dex
.eec8  txa
        eor $bd            ; ROPRTY, RS232 out parity
        sta $bd
        dec $b4            ; BITTS
        beq $eed7
.eed1  txa
        and #$04
        sta $b5            ; NXTBIT, next RS232 bit to send
        rts
.eed7  lda #$20
        bit $0294          ; M51CDR, 6551 command register image
        beq $eef2          ; no patity
        bmi $eefc          ; mark/space transmit
        bvs $eef6          ; even parity
        lda $bd            ; ROPRTY, out parity
        bne $eee7
.eee6  dex
.eee7  dec $b4             ; BITTS, out bit count
        lda $0293          ; M51CTR, 6551 control register image
        bpl $eed1          ; one stop bit only
        dec $b4            ; BITTS
        bne $eed1
.eef2  inc $b4             ; BITTS
        bne $eee6
.eef6  lda $bd            ; ROPRTY

```

```

        beq $eee7
        bne $eee6
.eefc   bvs $eee7
        bvc $eee6
.ef00   inc $b4          ; BITTS
        ldx #$ff
        bne $eed1

```

#### **EF06 SEND NEW RS232 BYTE**

This routine sets up the system variables ready to send a new byte to the RS232 port. A test is made for 3-line or X-line modus. In X-line mode, DSR and CTS are checked.

```

.ef06   lda $0294        ; M51CDR, 6551 command register
        lsr a            ; test handshake mode
        bcc $ef13        ; 3-line mode (no handshake)
        bit $dd01        ; RS232 port
        bpl $ef2e        ; no DSR, error
        bvc $ef31        ; no CTS, error
.ef13   lda #$00
        sta $bd          ; ROPRTY, RS232 out parity
        sta $b5          ; NXTBIT, next bit to send
        ldx $0298        ; BITNUM, number of bits left to send
        stx $b4          ; BITTS, RS232 out bit count
        ldy $029d        ; RODBS, start page of out buffer
        cpy $029e        ; RODBE, index to end of out buffer
        beq $ef39        ; disable timer
        lda ($f9),y      ; RS232 out buffer
        sta $b6          ; RODATA, RS232 out byte buffer
        inc $029d        ; RODBS
        rts

```

#### **EF2E NO DSR / CTS ERROR**

(A) is loaded with the error flag - \$40 for no DSR, and \$10 for no CTS. This is then ORed with 6551 status image and stored in RSSTAT.

```

.ef2e   lda #$40          ; entrypoint for 'NO DSR'
        .byte $2c         ; mask next LDA-command
.ef31   lda #$10          ; entrypoint for 'NO CTS'
        ora $0297        ; RSSTAT, 6551 status register image
        sta $0297

```

#### **EF39 DISABLE TIMER**

This routine set the interrupt mask on CIA#2 timer B. It also clears the NMI flag.

```

.ef39   lda #$01
.ef3b   sta $dd0d         ; CIA#2 interrupt control register
        eor $02a1        ; ENABL, RS232 enables
        ora #$80
        sta $02a1        ; ENABL
        sta $dd0d        ; CIA#2 interrupt control register
        rts

```

#### **EF4A COMPUTE BIT COUNT**

This routine computes the number of bits in the word to be sent. The word length information is held in bits 5 & 6 of M51CTR. Bit 7 of this register indicates the number of stop bits. On exit, the number of bits is held in (X).

```
.ef4a  ldx #$09
      lda #$20
      bit $0293          ; M51CTR, 6551 control register image
      beq $ef54
      dex
.ef54  bvc $ef58
      dex
      dex
.ef58  rts
```

#### **EF59 RS232 RECEIVE**

This routine builds up the input byte from the RS232 port in RIDATA. Each bit is input from the port under NMI interrupt control. The bit is placed in INBIT before being passed to this routine, where it is shifted into the carry flag and then rotated into RIDATA. The bit count is decremented and parity updated.

```
.ef59  ldx $a9          ; RINONE, check for start bit?
      bne $ef90
      dec $a8          ; BITC1, RS232 in bit count
      beq $ef97        ; process received byte
      bmi $ef70
      lda $a7          ; INBIT, RS232 in bits
      eor $ab          ; RIPRTY, RS232 in parity
      sta $ab
      lsr $a7          ; INBIT, put input bit into carry
      ror $aa          ; RIDATA,
.ef6d  rts
.ef6e  dec $a8          ; BITC1
.ef70  lda $a7          ; INBIT
      beq $efdb
      lda $0293        ; M51CTR, 6551 control register image
      asl a
      lda #$01
      adc $a8          ; BITC1
      bne $ef6d        ; end
```

#### **EF7E SET UP TO RECEIVE**

This routine sets up the I.C.R. to wait for the receiver edge, and flags this into ENABL. It then flags the check for a start bit.

```
.ef7e  lda #$90
      sta $dd0d        ; CIA#2 I.C.R.
      ora $02a1        ; ENABL, RS232 enables
      sta $02a1
      sta $a9          ; RINONE, check for start bit
      lda #$02
      jmp $ef3b        ; disable timer and exit
```

#### **EF90 PROCESS RS232 BYTE**

The byte recieved from the RS232 port is checked against parity. This involves checking the input parity options selected, and then verifying the parity bit calculated against that input. If the test is passed, then the byte is stored in the in-buffer. Otherwise an error is flagged into RSSTAT.



A patch in KERNAL version 3, has been added to the input routine at \$ef94 to initialise the RS232 parity byte, RIPRTY, on reception of a start bit.

```
.ef90  lda $a7          ; INBIT, RS232 in bits
      bne $ef7e        ; set up to receive
      jmp $e4d3        ; patch, init parity byte
.ef97  ldy $029b        ; RIDBE, index to the end of in buffer
      iny
      cpy $029c        ; RIDBS, start page of in buffer
      beq $efca        ; receive overflow error
      sty $029b        ; RIDBE
      dey
      lda $aa          ; RIDATA, RS232 in byte buffer
      ldx $0298        ; BITNUM, number of bits left to send
.ef99  cpx #$09         ; full word to come?
      beq $efb1        ; yes
      lsr a
      inx
      bne $efa9
.efb1  sta ($f7),y      ; RIBUF, RS232 in buffer
      lda #$20
      bit $0294        ; M51CDR, 6551 command register image
      beq $ef6e        ; parity disabled
      bmi $ef6d        ; parity check disabled, TRS
      lda $a7          ; INBIT, parity check
      eor $ab          ; RIPRTY, RS232 in parity
      beq $efc5        ; receive parity error
      bvs $ef6d
      .byte $2c        ; mask
.efc5  bvc $ef6d
      lda #$01         ; receive parity error
      .byte $2c        ; mask
.efca  lda #$04         ; receive overflow
      .byte $2c        ; mask
.efcd  lda #$80         ; framing break
      .byte $2c        ; mask
.efd0  lda #$02         ; framing error
      ora $0297        ; RSSTAT, 6551 status register image
      sta $0297
      jmp $ef7e        ; set up to receive
.efdb  lda $aa          ; RIDATA
      bne $efd0        ; framing error
      beq $efcd        ; receive break
```

#### **EFE1 SUBMIT TO RS232**

This routine is called when data is required from the RS232 port. Its function is to perform the handshaking on the poort needed to receive the data. If 3 line mode is used, then no handshaking is implemented and the routine exits.

```
.efef  sta $9a          ; DFLTO, default output device
      lda $0294        ; M51CDR, 6551 command register image
      lsr a
      bcc $f012        ; 3 line mode, no handshaking, exit
      lda #$02
      bit $dd01        ; RS232 I/O port
      bpl $f00d        ; no DRS, error
      bne $f012
```

```

.eff2  lda $02a1          ; ENABL, RS232 enables
        and #$02
        bne $eff2
.eff9  bit $dd01          ; RS232 I/O port
        bvs $eff9        ; wait for no CTS
        lda $dd01
        ora #$02
        sta $dd01        ; set RTS
.f006  bit $dd01
        bvs $f012        ; CTS set
        bmi $f006        ; wait for no DSR

```

#### **F00D NO DSR ERROR**

This routine sets the 6551 status register image to #40 when a no DSR error has occurred.

```

.f00d  lda #$40
        sta $0297        ; RSSTAT, 6551 status register image
.f012  clc
        rts

```

#### **F014 SEND TO RS232 BUFFER**

Note: The entry point to the routine is at

```

if014  jsr if028
if017  ldy a029e
        iny
        cpy a029d
        beq if014
        sty a029e
        dey
        lda a9e
        sta (pf9),y
if028  lda a02a1
        lsr a
        bcs if04c
        lda #$10
        sta add0e
        lda a0299
        sta add04
        lda a029a
        sta add05
        lda #$81
        jsr eef3b
        jsr eef06
        lda #$11
        sta add0e
if04c  rts

```

#### **F04D INPUT FROM RS232**

```

if04d  sta a99
        lda a0294
        lsr a
        bcc if07d
        and #$08
        beq if07d
        lda #$02

```

```

        bit add01
        bpl if00d
        beq if084
if062   lda a02a1
        lsr a
        bcs if062
        lda add01
        and #$fd
        sta add01
if070   lda add01
        and #$04
        beq if070
if077   lda #$90
        clc
        jmp eef3b
if07d   lda a02a1
        and #$12
        beq if077
if084   clc
        rts

```

#### **F086 GET FROM RS232**

```

if086   lda a0297
        ldy a029c
        cpy a029b
        beq if09c
        and #$f7
        sta a0297
        lda (pf7),y
        inc a029c
        rts
if09c   ora #$08
        sta a0297
        lda #$00
        rts

```

#### **F0A4 SERIAL BUS IDLE**

This routine checks the RS232 bus for data transmission/reception. The routine waits for any activity on the bus to end before setting I.C.R. The routine is called by serial bus routines, since these devices use IRQ generated timing, and conflicts may occur if they are all used at once.

```

.f0a4   pha                ; store (A)
        lda $02a1          ; ENABL, RS232 enables
        beq $f0bb          ; bus not in use
.f0aa   lda $02a1          ; ENABL
        and #$03           ; test RS232
        bne $f0aa          ; yes, wait for port to clear
        lda #$10
        sta $dd0d          ; set up CIA#2 I.C.R
        lda #$00           ; clear
        sta $02a1          ; ENABL
.f0bb   pla                ; retrieve (A)
        rts

```

#### **F0BD TABLE OF KERNAL I/O MESSAGES 1**

This is a table of messages used by the KERNAL in conjunction with its I/O routines. Bit 7 is set in the last character in each message as a terminator. The table is split into two parts in the JiffyDOS kernal, since the tape messages have been removed, and being substituted by new routines.

```
.f0bd  0d 49 2f 4f 20 45 52 52 4f 52 20 a3      ; i/o error #
.f0c9  0d 53 45 41 52 43 48 49 4e 47 a0        ; searching
.f0d4  46 4f 52 a0                             ; for
```

#### **F0D8 JIFFYDOS CLEAR SPRITES**

This routine is called by JiffyDOS before executing timecritical routines that might be messed up by sprites on the screen. A loop is performed afterwards that lets sprites currently being displayd on the screen, to be finished.

```
.f0d8  lda #$00
        sta $d015      ; clear sprites
.f0dd  adc #$01         ; perform loop
        bne $f0dd      ; 256 times
        rts
```

#### **F0E2 JIFFYDOS SET CHKIN**

This routine is a new JiffyDOS routine which clears all I/O and sets up the current JiffyDOS filenameumber as default inputdevice by calling CHKIN.

```
.f0e2  lda $9f         ; JiffyDOS Logical Filenameumber
.f0e4  pha             ; store (A)
        jsr $ffcc      ; CLRCHN
        pla           ; retrieve (A)
        tax           ; (A) to (X)
        jmp $ffc6      ; CHKIN, open channel for input
```

#### **F0ED JIFFYDOS SERIAL OUTPUT 1**

This is a patch to the original Commodore KERNAL, that clears the flag that indicates a JiffyDOS device, (\$a3), before setting the serial output to 1.

```
.f0ed  lda #$00        ; clear JiffyDOS device flag
        sta $a3
        jmp $ee97      ; serial output 1
```

#### **F0F4 JIFFYDOS SEND DRIVE COMMAND**

This routine uses the values in (X) and (Y) to send a command to the drive. (X) contains a offset to the command, and (Y) contains the length of the command.

```
.f0f4  txa             ; temp store (X)
        pha
        jsr $f7a2      ; open command channel for output
        pla
        tax           ; retrieve (X)
.f0fb  lda $f398,x      ; read command from table
        jsr $ffd2      ; output character to drive
        inx           ; next character
        dey           ; decrement counter
        bne $f0fb      ; till ready
        rts
```

#### **F106 TABLE OF KERNAL I/O MESSAGES 2**

This is the second part of the KERNAL I/O message table. Part 1 is to be found at address \$f0bd.

```
.f106 0d 4c 4f 41 44 49 4e c7      ; loading
.f10e 0d 53 41 56 49 4e 47 a0      ; saving
.f116 0d 56 45 52 49 46 59 49 4e c7 ; verifying
.f120 0d 46 4f 55 4e 44 a0         ; found
.f127 0d 4f 4b 9d                  ; ok
```

#### **F12B PRINT MESSAGE IF DIRECT**

This is a routine to output a message from the I/O messages table at \$f0bd. On entry, (Y) holds the offset to control which message is printed. The routine tests if we are in program mode or direct mode. If in program mode, the routine exits. Else, the routine prints character after character untill it reaches a character with bit7 set.

```
.f12b bit $9d          ; MSGFLG, test if direct or program mode
      bpl $f13c        ; program mode, don't print message
.f12f lda $f0bd,y      ; get output character from table
      php              ; store processor registers
      and #$7f         ; clear bit7
      jsr $ffd2        ; output character using CHROUT
      iny              ; increment pointer to next character
      plp              ; retrieve message
      bpl $f12f        ; untill bit7 was set
.f13c clc              ; clear carry to indicate no error
      rts
```

#### **F13E GETIN: GET a BYTE**

The KERNAL routine GETIN (\$ffe4) is vectored to this routine. It load a character into fac#1 from the external device indicated by DFLTN. Thus, if device = 0, GET is from the keyboard buffer. If device = 2, GET is from the RS232 port. If niether of these devices then GET is further handled by the next routine, INPUT.

```
.f13e lda $99          ; DFLTN, default input device.
      bne $f14a        ; not keyboard
      lda $c6          ; NDX, number of keys in keyboard queue
      beq $f155        ; buffer empty, exit
      sei              ; disable interrupts
      jmp $e5b4        ; get character from keyboard buffer, and exit
.f14a cmp #$02         ; RS232
      bne $f166        ; nope, try next device
.f14e sty $97          ; temp store
      jsr $f086        ; get character from RS232
      ldy $97          ; retrieve (Y)
.f155 clc
      rts
```

#### **F157 CHRIN: INPUT A BYTE**

The KERNAL routine CHRIN (\$ffcf) is vectored to this routine. It is similar in function to the GET routine above, and also provides a continuation to that routine. If the input device is 0 or 3, ie. keyboard or screen, then input takes place from the screen. INPUT/GET from other devices are performed by calls to the next routine. Two bytes are input from the device so that end of file can be set if necessary (ie. ST = #40)

```

.f157  lda $99          ; DFLTn, default input
      bne $f1a9        ; not keyboard, next device
      lda $d3          ; PNTR, cursor column on screen
      sta $ca          ; >LXSP, cursor position at start
      lda $d6          ; TBLX, cursor line number
      sta $c9          ; <LXSP
      jmp $e632        ; input from screen or keyboard
.f166  cmp #$03         ; screen
      bne $f173        ; nope, next device
      sta $d0          ; CRSW, flag INPUT/GET from keyboard
      lda $d5          ; LNMx, physical screen line length
      sta $c8          ; INDx, end of logical line for input
      jmp $e632        ; input from screen of keyboard
.f173  bcs $f1ad
      cmp #$02         ; RS232
      beq $f1b8        ; yes, get data from RS232 port
.f179  jsr $fbaa        ; JiffyDOS ACPTR, get byte from serial bus
      pha              ; temp store on stack
      bit $a3          ; test bit6, if serial device is a JiffyDOS device
      bvc $f19c        ; no JiffyDOS device
      cpx #$00
      bne $f187
      lda $c4          ; ??????
.f187  cmp #$04
      bcc $f19c
      ldy #$00         ; clear offset
      lda ($bb),y      ; FNADR, pointer to current filename
      cmp #$24         ; first character is $, ie. directory
      beq $f19c        ; yes, exit
      inc $b9          ; increment SA
      jsr $f38b        ; execute TALK, and TKSA
      dec $b9          ; decrement SA
      asl $a3
.f19c  pla
      rts

.f19e  lda #$10        ; set bit4
      jmp $felc        ; write to STATUS

```

### **F1A3 VECTOR TABLE**

The following table contains three vectors that is copied to \$0300 when the @X command is executed.

```

.f1a3  eb e3          ; IERROR vector
.f1a5  83 a4          ; IMAIN vector
.f1a7  7c a5          ; ICRNCH vector

```

```

      lda
      sed a90
ifl1ad =*+01
      lda f90a5,y

```

### **F1AD GET FROM SERIAL/RS232**

These routines, actually two different, is entered from the previous routine. The serial section checks the state of ST. If zero, then the data is recieved

from the bus, otherwise carriage return (#0d) is returned in (A). In the second section, the recieved byte is read from the RS232 port.

```
.flad  lda $90          ; STATUS, I/O status word
      beq $flb5        ; status OK
.flb1  lda #$0d        ; else return <CR> and exit
.flb3  clc
.flb4  rts
.flb5  jmp $fbaa        ; JiffyDOS ACPTR, get byte from serial bus
.flb8  jsr $f14e        ; receive from RS232
      bcs $flb4        ; end with carry set
      cmp #$00
      bne $flb3        ; end with carry clear
      lda $0297        ; RSSTAT, 6551 status register
      and #$6         ; mask
      bne $flb1        ; return with <CR>
      beq $flb8        ; get from RS232
```

#### **F1CA CHROUT: OUTPUT ONE CHARACTER**

The KERNAL routine CHROUT (\$ffd2) is vectored to this routine. On entry, (A) must hold the character to be output. The default output device number is examined, and output directed to relevant device. The screen, serial bus and RS232 all use previously described routines for their output. Some old taperoutines have been removed in the middle of this routine, and been changed to a JiffyDOS routine.

```
.flca  pha            ; temp store on stack
      lda $9a        ; DFLT0, default output device
      cmp #$03       ; screen?
      bne $fld5      ; nope, test next device
      pla            ; retrieve (A)
      jmp $e716      ; output to screen
.flb5  bcc $fldb      ; device <3
      pla            ; retrieve (A)
      jmp $eddd      ; send serial deferred
.flb8  lsr a
      pla
      sta $9e        ; PTR1, some tape junk left in the code
      txa
      pha
      tya
      pha
      bcc $f208      ; RS232
      jmp $f3f1      ; output device not present

.fle8  jsr $f8bf
      jsr $e4c6
      cmp #$30
      rts
```

#### **F1F1 JIFFYDOS DEFAULT DEVICE**

The following routine sets the default device number. It uses the GTBYTC procedure to read the specified device number.

```
.flf1  jsr $b79b      ; GTBYTC, read device number from keyboardbuffer
      stx $ba        ; store in FA, current device number
      jsr $f75c      ; test if device FA is present.
```

```

    stx $be          ; If OK, store
    rts

```

#### **F1FC CHROUT: PART 2**

This is the second part of the CHROUT routine. It contains the last parts of the RS232 output routine.

```

.f1fc  clc
      pla
      tay
      pla
      tax
      lda $9e          ; PTR1
      bcc $f207
      lda #$00
.f207  rts
.f208  jsr $f017        ; send to RS232
      jmp $f1fc        ; end output

```

#### **F20E CHKIN: SET INPUT DEVICE**

The KERNAL routine CHKIN (\$ffc6) is vectored to this routine. On entry, (X) must hold the logical file number. A test is made to see if the file is open, or ?FILE NOT OPEN. If the file is not an input file then ?NOT INPUT FILE. If the device is on the serial bus then it is commanded to TALK and secondary address is sent. ST is then checked, and if non-zero, ?DEVICE NOT PRESENT. Finally, the device number is stored in DFLTN.

```

.f20e  jsr $f30f        ; find file number
      beq $f216        ; ok, skip next command
      jmp $f701        ; I/O error #3, file not open
.f216  jsr $f31f        ; set file variables
      lda $ba          ; FA, current device number
      beq $f233        ; keyboard
      cmp #$03         ; screen
      beq $f233        ; yes
      bcs $f237        ; larger than 3, serial bus device
      cmp #$02         ; RS232
      bne $f22a        ; nope
      jmp $f04d        ; input from RS232
.f22a  ldx $b9          ; SA, current secondart address
      cpx #$60
      beq $f233
      jmp $f70a        ; I/O error #6, not output file
.f233  sta $99          ; DFLTN, default input device
      clc
      rts
.f237  tax
      jsr $ed09        ; send TALK to serial device
      lda $b9          ; SA
      bpl $f245        ; send SA
      jsr $edcc        ; wait for clock
      jmp $f248
.f245  jsr $edc7        ; send talk secondary address
.f248  txa
      bit $90          ; STATUS, I/O status word
      bpl $f233        ; store DFLTN, and exit
      jmp $f707        ; I/O error #5, device not present

```



#### **F250 CHKOUT: SET OUTPUT DEVICE**

The KERNAL routine CHKOUT (\$ffc9) is vectored to this routine. On entry (X) must hold the logical filename. A test is made to see if the file is open, or ?FILE NOT OPEN error. If the device is 0, ie. the keyboard, or the file is not an output file, then ?FILE OUTPUT FILE error is generated. If the device is on the serial bus, then it is commanded to LISTEN and the secondary address is sent. ST is then checked and if non-zero, then ?DEVICE NOT PRESENT error. Finally, the device number is stored in DFLT0.

```
.f350  jsr $f30f          ; fine file number (X)
      beq $f258          ; OK
      jmp $f701          ; I/O error #3, file not open
.f258  jsr $f31f          ; set file values
      lda $ba            ; FA, current device number
      bne $f262          ; not keyboard
.f25f  jmp $f70d          ; I/O error #7, not output file
.f262  cmp #$03          ; screen?
      beq $f275          ; yes
      bcs $f279          ; serial bus device
      cmp #$02          ; RS232
      bne $f26f          ; nope
      jmp $efef          ; submit to RS232
.f26f  ldx $b9            ; SA, current secondary address
      cpx #$60
      beq $f25f          ; not output file error
.f275  sta $9a            ; DFLT0, default output device
      clc                ; clear carry to indicate no errors
      rts
.f279  tax                ; file (X) to (A)
      jsr $ed0c          ; send LISTEN to serial device
      lda $b9            ; SA
      bpl $f286          ; send SA
      jsr $edbe          ; clear ATN
      bne $f289
.f286  jsr $edb9          ; send listen secondary address
.f289  txa
      bit $90            ; STATUS, I/O status word
      bpl $f275          ; OK, set output device
      jmp $f707          ; I/O error #5, device not present
```

#### **F291 CLOSE: CLOSE FILE, PART 1**

The KERNAL routine CLOSE (\$ff3c) is vectored here. The file parameters are fetched, and if not found, the routine exits without any action. It checks the device number associated with the file. If it is RS232, then the RS232 port is reset. If it is a serial device, the device is UNTALKed, or UNLISTENed. Finally the number of open logical files are decremented, and the table of active file numbers are updated. On entry (A) holds the file number to close. Old tape routines (\$f2cc-\$f2e1) has been removed for new JiffyDOS routines.

```
.f291  jsr $f314          ; find logical file, (X) holds location i table
      beq $f298          ; OK
      clc                ; file not found
      rts                ; and exit
.f298  jsr $f31f          ; get file values from table, position (X)
      txa
```

```

        pha                ; temp store
        lda $ba            ; FA, current device number
        beq $f2f1          ; keyboard?, update file table
        cmp #$03           ; screen
        beq $f2f1          ; yepp, update file table
        bcs $f2ee          ; Serial bus
        cmp #$02           ; RS232
        bne $f2c8          ; nope, serial
        pla                ; retriev (A)
        jsr $f2f2          ; remove entry (A) from file table
        jsr $f483          ; init RS232 port by using part of RS232OPEN
        jsr $fe27          ; MEMTOP, read top of memory (X/Y)
        lda $f8            ; >RIBUF, RS232 input buffer
        beq $f2ba          ;
        iny
.f2ba   lda $fa            ; >ROBUF, RS232 output buffer
        beq $f2bf          ;
        iny
.f2bf   lda #$0            ; Clear RS232 input/output buffers
        sta $f8
        sta $fa
        jmp $f47d          ; Set new ROBOF values and set new MEMTOP
.f2c8   pla                ; retriev (A)
        jmp $f713
.f2cc   jsr $ffcc          ; CLRCHN, close all channels
.f2cf   lda #$6f
        jsr $f314          ; FIND FILE, test if file number #$6f is open.
        bne $f30e          ; file not open, return
        jmp $f2f3          ; close file #$6f

```

#### **F2D9 JIFFYDOS TEST DEVICE**

The following routine tests if a device is present. On entry (X) holds the device to be tested. Open to the device is performed, and afterwards the statusword can be read for result.

```

.f2d9   stx $ba            ; store (X) in FA
.f2db   tya
        pha
        jsr $f8b2          ; open 15,x,15
        jsr $f7a2          ; set command channel (15) as output
        php
        jsr $f2cc          ; close command channel
        plp
        pla
        tay
        ldx $ba
        rts
        sed $

```

#### **F2e CLOSE: CLOSE FILE, PART 2**

```

.f2ee   jsr $f642          ; UNTALK/UNLISTEN serial device
.f2f1   pla
.f2f2   tax
.f2f3   dec $98            ; decrement LDTND, number of open files

```

```

        cpx $98          ; compare LDTND to (X)
        beq $f30d        ; equal, closed file = last file in table
        ldy $98          ; else, move last entry to position of closed entry
        lda $0259,y      ; LAT, active filenames
        sta $0259,x
        lda $0263,y      ; FAT, active device numbers
        sta $0263,x
        lda $026d,y      ; SAT, active secondary addresses
        sta $026d,x
.f30d   clc
.f30e   rts              ; return

```

### **F30F FIND FILE**

This routine finds a logical file from it's file number. On entry, (X) must hold the logical file number to be found. LAT, the table of file numbers is searched, and if found (X) contains the offset to the position of the file in the table, and the Z flag is set. If not found, Z=0.

```

.f30f   lda #$00
        sta $90          ; clear STATUS
        txa              ; file number to search for
.f314   ldx $98          ; LDTND, number of open files
.f316   dex
        bmi $f32e        ; end of table, return
        cmp $0259,x      ; compare file number with LAT, table of open files
        bne $f316        ; not equal, try next
        rts              ; back with Z flag set

```

### **F31F SEET FILE VALUES**

This routine sets the current logical file number, device number and secondary address from the file parameter tables. On entry (X) must hold the offset to the position of the file in the table.

```

.f31f   lda $0259,x      ; LAT, table of active logical files
        sta $b8          ; store in LA
        lda $0263,x      ; FAT, table of active device numbers
        sta $ba          ; store in FA
        lda $026d,x      ; SAT, table of active secondary addresses
        sta $b9          ; store in SAT
.f32e   rts              ; return

```

### **F32F CLALL: ABORT ALL FILES**

The KERNAL routine CLALL (\$ffe7) is vectored here. The number of open files are set to zero, and the next routine is performed.

```

.f32f   lda #$00
        sta $98          ; clear LDTND, no open files

```

### **F333 CLRCHN: RESTORE TO DEFAULT I/O**

The KERNAL routine CLRCHN (\$ffc) is vectored here. The default output device is UNLISTENed, if it is on the serial bus, and the default output is set to the screen. The default input device is UNTALKed, if it is on the serial bus, and the default input device is set to keyboard.

```

.f333   ldx #$03         ; check if device > 3 (serial bus is 4,5...)
        cpx $9a          ; test DFLTO, default output device
        bcs $f33c        ; nope, no serial device

```

```

        jsr $edfe          ; send UNLISTEN to serial bus
.f33c   cpx $99            ; test DFLTI, default input device
        bcs $f343          ; nope, no serial device
        jsr $edef          ; send UNTALK to serial bus
.f343   stx $9a            ; store screen as DFLTO
        lda #$00
        sta $99            ; store keyboard as DFLTI
        rts

```

#### **F34A OPEN: OPEN FILE**

The KERNAL routine OPEN (\$ffc0) is vectored here. The file parameters must be set before entry. The routine reads the LAT, to see if file already exists, which will result in I/O error #2, ?FILE OPEN. A test is made to see if more than 10 files are open. If so, I/O error #1, ?TOO MANY FILES, will occur. The file parameters are set, and put in their respective tables. The device number is checked, and each kind of device jumps to their own routine. Keyboard and screen will exit here with no further actions. RS232 is opened via a separate routine. SA, secondary address, and filename will be sent on the serial bus. Some tape routines are removed, and replaced with JiffyDOS code.

```

.f34a   ldx $b8            ; LA, current logical number
        bne $f351
        jmp $f70a          ; I/O error #6, not input file
.f351   jsr $f30f          ; find file (X)
        bne $f359
        jmp $f6fe          ; I/O error #2, file exists
.f359   ldx $98            ; LDTND, number of open files
        cpx #$0a           ; more than ten
        bcc $f362          ; nope
        jmp $f6fb          ; I/O error #1, too many files
.f362   inc $98            ; increment LDTND
        lda $b8            ; LA
        sta $0259,x        ; store in LAT, table of active file numbers
        lda $b9            ; SA
        ora #$60           ; fixx
        sta $b9            ; store in SA
        sta $026d,x        ; store in SAT, table of active secondary addresses
        lda $ba            ; FA
        sta $0263,x        ; store in FAT, table of active device numbers
        beq $f3d3          ; keyboard, end
        cmp #$03           ; screen
        beq $f3d3          ; yep, end
        bcc $f384          ; less than 3, not serial bus
        jsr $f3d5          ; send SA
        bcc $f3d3          ; end
.f384   cmp #$01           ; TAPE
        beq $f3f3          ; I/O error #5, device not present
        jmp $f409          ; open RS232 file

```

#### **F38B JIFFYDOS TALK & TKSA**

This is a routine used by JiffyDOS to untalk device (A), then TALK and TKSA is executed to current device with current secondary address.

```

.f38b   jsr $ffab          ; UNTALK
        lda $ba            ; FA, current device number
        jsr $ffb4          ; TALK
        lda $b9            ; SA, current secondary address

```

```
jmp $ff96          ; TKSA, send SA after TALK
```

### **F398 JIFFYDOS DIRECT DRIVE COMMANDS**

The following text/code is used to transfer, and is transferred to a selected drive. The first section is a \$22 byte long block used by the lock/unlock a file. The second section is code to execute a drive program at \$0600. The third section sets a byte in the drive memory to control the interleave. The fourth section sets a byte in the drive memory to control the 1541 head rattle.

```
.f398  4d 2d 57 00 06 1c  ; M-W 00 06 1c, ie. write $1c bytes to $0600
        lda $0261          ; the following code is transfered to the drive
        sta $07            ; at $0600
        lda #$12
        sta $06
        ldx #$00
        stx $f9
        jsr $d586
        ldy $0267
        lda ($30),y
        eor #$40
        sta ($30),y
        jmp $d58a

.f3b0  4d 2d 45 00 06      ; M-E 00 06, ie. a memory execute at $0600
.f3b6  4d 2d 57 6a 00 01  ; M-W 6a 00 01, ie. memory write one byte at $006a
.f3bc  4d 2d 57 69 00 01  ; M-W 69 00 01, ie. memory write one byte at $0069

        ora (p50,x)
        ror a01
        sed $
        rol $
        sta aa6

if3d3  clc
        rts
```

### **F3D5 SEND SA**

This routine exits if there is no secondary address or filename specified. The I/O status word, ST, is reset, and the serial device is commanded to LISTEN. A check is made for a possible ?DEVICE NOT PRESENT error. Finally, the filename is sent to the device.

```
.f3d5  lda $b9              ; SA, current secondary address
        bmi $f3d3          ; exit
        ldy $b7            ; FNLEN, length of filename
        beq $f3d3          ; exit
        lda #$00
        sta $90            ; clear STATUS, I/O status word
        lda $ba            ; FA, current device number
        jsr $ed0c          ; send LISTEN to serial bus
        lda $b9            ; SA
        ora #$f0
        jsr $edb9          ; send LISTEN SA
        lda $90            ; STATUS
        bpl $f3f6          ; ok
.f3f1  pla                  ; remove two stack entries for RTS command
        pla
```

```

.f3f3  jmp $f707          ; I/O error #5, device not present
.f3f6  lda $b7            ; FNLEN
      beq $f406          ; unlisten and exit
      ldy #$00           ; clear offset
.f3fc  lda ($bb),y        ; FNADR, pointer to filename
      jsr $eddd          ; send byte on serial bus
      iny                ; next character
      cpy $b7            ; until entire filename is sent
      bne $f3fc          ; again
.f406  jmp $f654          ; unlisten and exit

```

#### **F409 OPEN RS232**

```

.f409  jsr $f483
      sty a0297
.f40f  cpy ab7
      beq if41d
      lda (pbb),y
      sta f0293,y
      iny
      cpy #$04
      bne if40f
if41d  jsr eef4a
      stx a0298
      lda a0293
      and #$0f
      beq if446
      asl a
      tax
      lda a02a6
      bne if43a
      ldy ffec1,x
      lda ffec0,x
      jmp if440
if43a  ldy fe4eb,x
      lda fe4ea,x
if440  sty a0296
      sta a0295
if446  lda a0295
      asl a
      jsr eff2e
      lda a0294
      lsr a
      bcc if45c
      lda add01
      asl a
      bcs if45c
      jsr if00d
if45c  lda a029b
      sta a029c
      lda a029e
      sta a029d
      jsr efe27
      lda af8
      bne if474
      dey
      sty af8

```

```

        stx af7
if474   lda afa
        bne if47d
        dey
        sty afa
        stx af9
if47d   sec
        lda #$f0
        jmp efe2d
if483   lda #$7f
        sta add0d
        lda #$06
        sta add03
        sta add01
        lda #$04
        ora add00
        sta add00
        ldy #$00
        sty a02a1
        rts

```

#### **F49E LOAD: LOAD RAM**

The kernal routine LOAD (\$ffd5) is vectored here. If a relocated load is desired, then the start address is set in MEMUSS. The load/verify flag is set, and the I/O status word is reset. A test is done on the device number, less than 3 results in illegal device number.

```

.f49e   stx $c3          ; MEMUSS, relocated load address
        sty $c4
        jmp ($0330)      ; ILOAD vector. Points to $f4a5
.f4a5   sta $93          ; VRECK, load/verify flag
        lda #$00
        sta $90          ; clear STATUS, I/O status
        lda $ba          ; get FA, current device
        bne $f4b2        ; keyboard
.f4af   jmp $f713        ; I/O error #9, illegal device
.f4b2   cmp #$03         ; screen?
        beq $f4af        ; yes, illegal device

```

#### **F4B8 LOAD FROM SERIAL BUS**

A filename is assumed by the routine, and if not present, a jump is made to a new JiffyDSO routine that sets filename to ':\*'. The message 'SEARCHING' is printed and the filename is sent with the TALK command and secondary address to the serial bus. If EOI occurs at this point, then ?FILE NOT FOUND is displayed. The message 'LOADING' or 'VERIFYING' is output and a loop is entered, which receives a byte from the serial bus, checks the <STOP> key and either stores the received byte, or compares it to the memory, depending on the state of VERCK. Finally the bus is UNTALKed.

```

.f4b8   bcc $f4af        ; device < 3, eg tape or RS232, illegal device
        ldy $b7          ; FNLEN, length of filename
        bne $f4bf        ; if length not is zero
        jmp $f659        ; fixx filename, JiffyDOS patch
.f4bf   ldx $b9          ; SA, current secondary address
        jsr $f5af        ; print "SEARCHING"
        lda #$60
        sta $b9          ; set SA to $60

```

```

        jsr $f3d5          ; send SA and filename
        lda $ba            ; FA, current devicenumbr
        jsr $ed09          ; send TALK to serial bus
        lda $b9            ; SA
        jsr $edc7          ; send TALK SA
        jsr $ee13          ; receive from serial bus
        sta $ae            ; load address, <EAL
        lda $90            ; check STATUS
        lsr a
        lsr a
        bcs $f530          ; EOI set, file not found
        jsr $f179          ; recieve from serial bus
        sta $af            ; load address, >EAL
        txa                ; retrieve SA and test relocated load
        bne $f4f0          ;
        lda $c3            ; use MEMUSS as load address
        sta $ae            ; store in <EAL
        lda $c4
        sta $af            ; store in >EAL
.f4f0   jmp $fac4          ; jump to JiffyDOS patch
.f4f3   jsr $ffe1          ; scan <STOP>
        bne $f4fb          ; not stopped
        jmp $f633
.f4fb   jsr $fbaa          ; JiffyDOS ACPTR, recrive from serial bus
        lda $90            ; read ST
        and #$fd           ; mask %111111101
        cmp $90
        sta $90
        bne $f4f3          ; EOI set
        ldy #$00
        ldx $a3
        lda $a4            ;
        cpy $93            ; VERIFY eller LOAD
        beq $f51a          ; jump to LOAD
        cmp ($ae),y        ; compare with memory
        beq $f51c          ; veryfied byte OK
        jsr $f19e          ;
        .byte $2c          ; mask next write command
.f51a   sta ($ae),y        ; store in memory
.f51c   stx $a3
        inc $ae            ; increment <EAL, next address
        bne $f524          ; skip MSB
        inc $af            ; increment >EAL
.f524   bit $90            ; test STATUS
        bvc $f4f3          ; get next byte
        jsr $edef          ; send UNTALK to serial bus
        jsr $f642
        bcc $f5a9          ; end routine
.f530   jmp $f704          ; I/O error #4, file not found

```

### **F533 JIFFYDOS @ COMMAND**

The following routine executes the @ command. First it tests if additional parameters are entered.

```

.f533   lda $b7            ; FNLEN, length of current filename
        beq $f546          ; no filename
        lda ($bb),y        ; test filename for

```



```

        cmp #$24          ; $, directory
        beq $f56c         ;
        jmp $fc9a         ; else goto

```

#### **F540 JIFFYDOS LIST ASCII FROM DISK**

This routine lists an ascii file from disk. It reads one block of text from the disk (254 bytes) into the filename area. The text is then output using the 'print filename' routine.

```

.f540  tya                ; (Y) contains the command number
        pha                ; store on stack
        jsr $f8bf         ; open file with current parameters
        pla                ; retrieve
.f546  sta $a6            ; store
.f548  jsr $f911         ; input charaters to buffer (filename area)
        bne $f568         ; exit if errors occured
        lda $a6           ; get command number, should be $0f
        php
        beq $f557
        jsr $e4c6         ; input byte from command channel
        beq $f567         ; if byte =# then exit
.f557  jsr $f79a
        jsr $f5c1         ; print filename, ie. the input buffer
        bit $91           ; STKEY FLAG, test if <STOP> is pressed
        bpl $f567         ; exit
        plp
        bne $f548
        bvc $f548
        .byte $24         ; mask one byte, ie. PLP command
.f567  plp
.f568  rts

```

#### **F569 JIFFYDOS BASIC DISC LIST**

The following routine reads the specified basic-file from disk and displays it to the screen. The entrypoint at \$f56c is used for showing the directory. First, the routine opens the file specified. IERROR vector is changed to \$f739, so a RTS command will be performed when a error occurs. Then the start address is read, and thrown away. A loop is performed that reads one block of bytes from the disk and is output through the basic LIST routine. On exit, the IERROR vector is restored.

```

.f569  ldx #$6c          ; get byte for SA, list basic program
        .byte $2c        ; mask next 2 bytes
.f56c  ldx #$60          ; get byte for SA, list directory
        jsr $f8c1         ; open file with current parameters
        lda #$39         ; setup JiffyDOS IERROR vector to point to
        sta $0300        ; $f739, a RTS-command
        ldy #$fc         ; set up (Y) pointer to 252
        jsr $fca6         ; read two garbage bytes (program start address)
.f57b  ldy #$00         ; set up (Y) pointer to 0
.f57d  jsr $fca6         ; read 254 bytes, store in input buffer
        bvs $f5a3        ; EOI, exit
        cpy #$02         ; if (Y) = 2
        beq $f5a3        ; exit
        cpy #$06
        bcc $f57d
        ldx $bb          ; read FNADR pointer, vector to input buffer

```

```

        stx $5f          ; store in temp vector
        ldx $bc
        stx $60
        ldy #$01
        sta ($5f),y
        jsr $a6c3        ; use part of LIST routine to output text
        jsr $f79a
        jsr $a6d4
        bit $91          ; STKEY FLAG, stop key
        bmi $f57b        ; not pressed, continue
.f5a3   lda #$63          ; restore JiffyDOS IERROR vector to $f763
        sta $0300        ; IERROR VEC
        rts

```

#### **F5A9 LOAD END**

This is the last part of the loader routine which sets the (X/Y) register with the endaddress of the loaded program, clears carry and exit.

```

.f5a9   clc
        ldx $ae
        ldy $af
        rts

```

#### **F5AF PRINT "SEARCHING"**

If MSGFLG indicates program mode then the message is not printed, otherwise the message "SEARCHING" is printed from the KERNAL I/O message table. If the length of filename > 0 then the message "FOR" is printed, and the routine drops through to print the filename.

```

.f5af   lda $9d          ; MSGFLG, direct or program mode?
        bpl $f5d1        ; program mode, don't print, exit
        ldy #$0c
        jsr $f12f        ; print "SEARCHING"
        lda $b7          ; FNLEN, length of current filename
        beq $f5d1        ; no name, exit
        ldy #$17
        jsr $f12f        ; print "FOR"

```

#### **F5C1 PRINT FILENAME**

Filename is pointed to by FNADR, and length in FNLEN. The KERNAL routine CHROUT is used to print filename.

```

.f5c1   ldy $b7          ; FNLEN, length of current filename
        beq $f5d1        ; exit
        ldy #$00
.f5c7   lda ($bb),y      ; get character in filename
        jsr $ffd2        ; output
        iny              ; next character
        cpy $b7          ; ready?
        bne $f5c7
.f5d1   rts              ; back

```

#### **F5D2 PRINT "LOADING/VERIFYING"**

The load/verify flag is checked, and if the message to be output is flagged according to the result. This message is printed from the KERNAL I/O messages table.

```

.f5d2  ldy #$49          ; offset to verify message
      lda $93           ; VERCK, load/verify flag
      beq $f5da         ; verify
      ldy #$59          ; offset to load message
.f5da  jmp $f12b         ; output message flagged by (Y)

```

#### **F5DD SAVE: SAVE RAM**

The KERNAL routine SAVE (\$ffd8) jumps to this routine. On entry, (X/Y) must hold the end address+1 of the area of memory to be saved. (A) holds the pointer to the start address of the block, held in zeropage. The current device number is checked to ensure that it is niether keyboard (0) or screen (3). Both of these result in ?ILLIGAL DEVICE NUMBER.

```

.f5dd  stx $ae          ; EAL , end address of block +1
      sty $af
      tax              ; move start pointer to (X)
      lda $00,x
      sta $c1          ; STAL, start address of block
      lda $01,x
      sta $c2
      jmp ($0332)       ; vector ISAVE, points to $f5ed
.f5ed  lda $ba          ; FA, current device number
      bne $f5f4         ; ok
.f5f1  jmp $f713         ; I/O error #9, illigal device number
.f5f4  cmp #$03         ; screen?
      beq $f5f1         ; yep, output error
      bcc $f5f1         ; less than 3, ie. tape, output error

```

#### **F5FA SAVE TO SERIAL BUS**

A filename is assumed by the routine, or ?MISSING FILENAME error is called. The serial device is commanded to LISTEN, and the filename is sent along with the secondary address. The message 'SAVING' is printed, and a loop sends a byte to the serial bus and checks <STOP> key until the whole specified block of memory has been saved. Note that the first two bytes sent are the start address of the block. Finally the serial bus is UNLISTENed.

```

.f5fa  lda #$61
      sta $b9          ; set SA, secondary address, to #1
      ldy $b7          ; FNLEN, length of current filename
      bne $f605         ; ok
.f602  jmp $f710         ; I/O error #8, missing filename
.f605  jsr $f3d5         ; send SA & filename
      jsr $f68f         ; print 'SAVING' and filename
      lda $ba          ; FA, current device number
      jsr $ed0c         ; send LISTEN
      lda $b9          ; SA
      jsr $edb9         ; send LISTEN SA
      ldy #$00
      jsr $fb8e         ; reset pointer
      lda $ac          ; SAL, holds start address
      jsr $eddd         ; send low byte of start address
      lda $ad
      jsr $eddd         ; send high byte of start address
.f624  jsr $fcd1         ; check read/write pointer
      bcs $f63f
      lda ($ac),y       ; get character from memory
      jsr $eddd         ; send byte to serial device

```

```

        jsr $ffe1          ; test <STOP> key
        bne $f63a          ; not pressed
.f633   jsr $f642          ; exit and unlisten
        lda #$00           ; flag break
        sec
        rts
.f63a   jsr $fcdb          ; bump r/w pointer
        bne $f624          ; save next byte
.f63f   jsr $edfe          ; send UNLISTEN
.f642   bit $b9            ; SA
        bmi $f657
        lda $ba            ; FA
        jsr $ed0c          ; send LISTEN
        lda $b9
        and #$ef
        ora #$e0
        jsr $edb9          ; send UNLISTEN SA
.f654   jsr $edfe          ; send UNLISTEN
.f657   clc
        rts

```

#### **F659 JIFFYDOS DEFAULT FILENAME**

The following routine is executed when a missing filename is detected in the original loader routine. If so, the filename is set to ':\*', wildcard filename. On exit, a jump is made to the original loader with new filename parameters set.

```

.f659   lda $c6            ; NDX, number of characters in keyboard buffer
        beq $f602          ; if zero, output missing filename error
        lda #$02           ; store $02
        sta $b9            ; in SA, default secondary address
        ldx #$74           ; set up filename pointer to $f674
        ldy #$f6           ; ie. ':'
        jsr $ffbd          ; SETNAM
        jmp $f4bf          ; back to loader routine

        ldx #$33           ; offset
        ldy #$04           ; length
        jmp $f932          ; drive command

```

#### **F672 JIFFYDOS FUNKTION KEYS**

The following table contains the strings copied to the keyboard buffer when the funktionkeys are pressed. This table is pointed to by the FNKVEC at \$b0/\$b1. The strings are separated by a zero-byte.

```

.f672   40 24 3a 2a 0d 00 ; F1 = '@$:*'
.f678   2f 00                ; F3 = '/'
.f67a   5e 00                ; F5 = arrow up
.f67c   25 00                ; F7 = '%'
.f67e   40 44 00            ; F2 = '@d'
.f681   40 54 00            ; F4 = '@t'
.f684   5f 00                ; F6 = arrow left
.f686   40 20 20 22 53 3a 00 ; F8 = '@ "S:'

```

```

        clc

```

if68e rts

#### **F68F PRINT 'SAVING'**

MSGFLG is checked, and if direct mode is on, then the message 'SAVING' is flagged and printed from the KERNAL I/O message table.

```
.f68f  lda $9d          ; MSGFLG
      bpl $f68e        ; not in direct mode, exit
      ldy #$51         ; offset to message in table
      jsr $f12f        ; output 'SAVING'
      jmp $f5c1        ; output filename
```

#### **F69B UDTIM: BUMP CLOCK**

The KERNAL routine UDTIM (\$ffea) jumps to this routine. The three byte jiffy clock in RAM is incremented. If it has reached \$4f1a01, then it is reset to zero. this number represents 5184001 jiffies (each jiffy is 1/60 sec) or 24 hours. finally, the next routine is used to log the CIA key reading.

```
.f69b  ldx #$00
      inc $a2          ; low byte of jiffy clock
      bne $f6a7
      inc $a1          ; mid byte of jiffy clock
      bne $f6a7
      inc $a0          ; high byte of jiffy clock
.f6a7  sec
      lda $a2          ; subtract $4f1a01
      sbc #$01
      lda $a1
      sbc #$1a
      lda $a0
      sbc #$4f
      bcc $f6bc        ; and test carry if 24 hours
      stx $a0          ; yepp, reset jiffy clock
      stx $a1
      stx $a2
```

#### **F6BC LOG CIA KEY READING**

This routine tests the keyboard for either <STOP> or <RVS> pressed. If so, the keypress is stored in STKEY.

```
.f6bc  lda $dc01        ; keyboard read register
      cmp $dc01
      bne $f6bc        ; wait for value to settle
      tax
      bmi $f6da
      ldx #$bd
      stx $dc00        ; keyboard write register
.f6cc  ldx $dc01        ; keyboard read register
      cpx $dc01
      bne $f6cc        ; wait for value to settle
      sta $dc00
      inx
      bne $f6dc
.f6da  sta $91          ; STKEY, flag STOP/RVS
.f6dc  rts
```

#### **F6DD RDTIM: GET TIME**

The KERNAL routine RDTIM (\$ffde) jumps to this routine. The three byte jiffy clock is read into (A/X/Y) in the format high/mid/low. The routine exits, setting the time to its existing value in the next routine. The clock resolution is 1/60 second. SEI is included since part of the IRQ routine is to update the clock.

```
.f6dd sei                ; disable interrupt
      lda $a2            ; read TIME
      ldx $a1
      ldy $a0
```

#### **F6E4 SETTIM: SET TIME**

The KERNAL routine SETTIM (\$ffdb) jumps to this routine. On entry, (A/X/Y) must hold the value to be stored in the clock. The format is high/mid/low, and clock resolution is 1/60 second. SEI is included since part of the IRQ routine is to update the clock.

```
.f6e4 sei                ; disable interrupt
      sta $a2            ; write TIME
      stx $a1
      sty $a0
      cli                ; enable interrupts
      rts
```

#### **F6ED STOP: CHECK <STOP> KEY**

The KERNAL routine STOP (\$ffe1) is vectored here. If STKEY = #7f, then <STOP> was pressed and logged whilst the jiffy clock was being updated, so all I/O channels are closed and the keyboard buffer reset.

```
.f6ed lda $91            ; STKEY
      cmp #$7f           ; <STOP> ?
      bne $f6fa          ; nope
      php
      jsr $ffcc          ; CLRCHN, close all I/O channels
      sta $c6            ; NDX, number of characters in keyboard buffer
      plp
.f6fa rts
```

#### **F6FB OUTPUT KERNAL ERROR MESSAGES**

The error message to be output is flagged into (A) depending on the entry point. I/O channels are closed, and then if KERNAL messages are enabled, "I/O ERROR #" is printed along with the error number.

```
.f6fb lda #$01           ; error #1, too many files
      .byte $2c
.f6fe lda #$02           ; error #2, file open
      .byte $2c
.f701 lda #$03           ; error #3, file not open
      .byte $2c
.f704 lda #$04           ; error #4, file not found
      .byte $2c
.f707 lda #$05           ; error #5, device not found
      .byte $2c
.f70a lda #$06           ; error #6, not input file
      .byte $2c
.f70d lda #$07           ; error #7, not output file
      .byte $2c
```

```

.f710  lda #$08          ; error #8, missing filename
      .byte $2c
.f713  lda #$09          ; error #9, illegal device number
      pha
      jsr $ffcc          ; CLRCHN, close all I/O channels
      ldy #$00
      bit $9d            ; test MSGFLAG, KERNAL messages enabled
      bvc $f729          ; no
      jsr $f12f          ; print "I/O ERROR #"
      pla
      pha
      ora #$30           ; convert (A) to ASCII number
      jsr $ffd2          ; use CHROUT to print number in (A)
.f729  pla
      sec
      rts

```

#### **F72C TEST JIFFY COMMAND**

This routine test the character in the current key in the buffer if it is a JiffyDOS command character. Output from this routine is (Y) which contains the value of the selected command. (Y)=\$ff if no command was found.

```

.f72c  ldy #$0c          ; number of characters to test
      jsr $79            ; CHARGOT, read current character in buffer again
.f731  cmp $f7dd,y        ; equal to byte in JiffyDOS command tab
      beq $f739          ; yepp, return
      dey                ; test next
      bpl $f731          ; till (Y)=$ff
.f739  rts                ; back

```

#### **F73A JIFFYDOS SLPARA**

This routine is executed from the original SLPARA. It executes SETLFS to set logical file parameters, as normal. But it also continues through the next routine to find a present device number.

```

.f73a  jsr $ffba          ; SETLFS

```

#### **.F73D JIFFYDOS TEST SERIAL DEVICE**

This routine tests a serial disk device number to see if it is present. The routine uses \$be as a internal counter for device number. A test is performed to make sure that the device number is within its limits, \$08-\$1f. If a device is not present, the routine continues searching for a present device. The second time we reset the counter to \$08 (after reaching \$1f) without finding a device, the routine exits with error #5, device not present.

```

.f73d  clc                ; clear carry
      php                ; store carry
      ldx $be            ; internal counter for devicenumber
      cpx #$08           ; device $8
      bcc $f749          ; less than $8
.f745  cpx #$1f           ; serial device must be less than $1f (31)
      bcc $f750          ; less than $1f
.f749  plp                ; if carry set, this is second time
      bcs $f761          ; do error
      sec                ; set carry to indicate first reset
      php                ; store carry

```

```

        ldx #$08          ; start at $08 again
.f750   stx $be           ; store
        jsr $f2d9         ; test devicenummer (X)
        bcc $f75a         ; OK, device (X) is next present device
        inx               ; next devicenummer
        bne $f745         ; test next
.f75a   pla               ; clean ut stack
.f75b   rts               ; exit

.f75c   jsr $f2db         ; test devicenummer in FA
        bcc $f75b         ; ok
.f761   ldx #$05         ; ERROR, device not present

```

### **F763 IERROR: JIFFYDOS ERROR ROUTINE**

The ERROR vector IERROR (\$0300) points to this routine. On entry (X) holds the error number. A test is done to see if this is a SYNTAX error (\$0b). If not, it jumps to the original IERROR at \$e38b, where errors are taken care of as usual. Else, the routine continues by checking if the error was caused by a JiffyDOS command.

```

.f763   cpx #$0b         ; SYNTAX ERROR
        beq $f76a         ; yes, jump to command test
.f767   jmp $e38b        ; nope, normal error handler

```

### **F76A COMMAND: TEST FOR EXTRA JIFFYDOS COMMANDS**

The following routine tests if a JiffyDOS command has been entered. A subroutine is called to test this, and it leavs the JiffyDOS command number in (Y), if any found. It tests for a present serial device,

```

.f76a   jsr $f72c         ; test JiffyDOS command. On exit, (Y)=command number
        bne $f767         ; no JiffyDOS command
        sty $27           ; temp store
        tax
        bmi $f776
        pla
        pla
.f776   jsr $f73d         ; test serial device, if any present
        jsr $f838         ; command after '@'? Setname and open specified file
        lda $27           ; retrieve temp, command number.
        ldy #$00
        asl a             ; times 2
        tax               ; to (X)
        lda $f7f5,x       ; get low commandvector
        sta $55           ; store
        lda $f7f6,x       ; get high commandvector
        sta $56           ; store
.f78c   jsr $54           ; execute JiffyDOS command
        jsr $a8f8         ; ignore next statement, sort of REM
        jsr $f2cc         ; close all channels, and file 15 if open
        lda $9f           ; JiffyDOS default filenumber
        jsr $ffc3         ; CLOSE
.f79a   jsr $ffcc         ; CLRCHN, close all I/O channels
        ldx $13           ; CHANNL
        beq $f75b         ; screen and keyboard are current I/O device, exit
        .byte $2c         ; else mask next LDX-command, and perform CHKOUT

.f7a2   ldx #$6f         ; command channel

```



```
    jmp $ffc9          ; CHKOUT, open channel for output.
```

#### **F7A7 JIFFYDOS ML-LOAD**

This is the entrypoint for £ and %, which loads machine language

```
.f7a7  tya
       iny
       .byte $2c          ; bit $xxxx, trick to skip 2 commands
```

#### **F7AA JIFFYDOS VERIFY**

This is the entrypoint for ', which verifies a file

```
.f7aa  tya
```

#### **F7AB JIFFYDOS BASIC-LOAD**

This is the entrypoint for / and 'arrow up' which loads a basic program. The LOAD/VERIFY is performed. Depending on what command is executed, various end routines are performed.

```
.f7ab  iny
       sty $b9          ; SA, current secondary address
       ldx $2b          ; TXTTAB, start of basic
       ldy $2c
       jsr $ffd5        ; LOAD
       bcc $f7c0        ; load OK
       jmp $e0f9        ; handle I/O error
.f7ba  jmp $e195        ; load OK?
.f7bd  jmp $e17e        ; verify OK?
.f7c0  lda $27          ; test command number
       cmp #$0b         ; verify command (')
       beq $f7bd        ; output verify OK
       bcs $f78c        ; command number larger than $0b
       cmp #$08         ; load ml (%)
       beq $f75b        ; if so exit
       bcc $f7ba        ; if command number less than 8, test if OK and exit
       stx $2d          ; VARTAB, set start of Basic variables
       sty $2e
       pla              ; remove RTS return address
       pla
       jsr $aad7        ; output CR/LF
       jsr $a533        ; rechain basic lines
       jmp $a871        ; perform RUN
```

#### **F7DD JIFFYDOS COMMAND TAB**

The tab contains the additional JiffyDOS commands. The \$0c first commands can be entered at the prompt, and are tested at \$f72c. The remaining commands must be entered after the @-character. The DOS 5.1 Wedge Commands are not checked here.

```
.f7dd  40              ; @
.f7de  5f              ; <-
.f7df  2a              ; *
.f7e0  ac              ; dot in lower right corner. (Same as *. Possible
                       ; future expansion)
.f7e1  22              ; "
.f7e2  12              ; . (Same as ". Possible future expansion)
.f7e3  2f              ; /
```

.f7e4	ad	; right angle in top right corner. (Same as /. Possible future expansion)
.f7e5	25	; %
.f7e6	5e	; arrow up
.f7e7	ae	; right angle in lower left corner. (Same as 'arrow up'. Possible future expansion)
.f7e8	27	; ´
.f7e9	5c	; £

The following command characters must be entered after the @-character.

.f7ea	44	; D
.f7eb	4c	; L
.f7ec	54	; T
.f7ed	23	; #
.f7ee	42	; B
.f7ef	46	; F
.f7f0	4f	; O
.f7f1	50	; P
.f7f2	51	; Q
.f7f3	58	; X
.f7f4	47	; G

#### **F7F5 JIFFYDOS COMMAND VECTORS**

The following table contains the JiffyDOS command vectors. The vectors are in the same order as the command characters above.

.f7f5	33 f5	; execute @ at \$f533
.f7f7	59 e1	; execute <- at \$e159
.f7f9	39 fa	; execute * at \$fa39
.f7fb	39 fa	; execute XX at \$fa39
.f7fd	2b f7	; execute " at \$f72b
.f7ff	2b f7	; execute . at \$f72b
.f801	ab f7	; execute / at \$f7ab
.f803	ab f7	; execute XX at \$f7ab
.f805	a7 f7	; execute % at \$f7a7
.f807	ab f7	; execute 'arrow up' at \$f7ab
.f809	ab f7	; execute XX at \$f7ab
.f80b	aa f7	; execute ´ at \$f7aa
.f80d	a7 f7	; execute £ at \$f7a7

The following commands are extra JiffyDOS commands and to come after the @-character

.f80f	69 f5	; execute D at \$f569
.f811	d4 f8	; execute L at \$f8d4
.f813	40 f5	; execute T at \$f540
.f815	f1 f1	; execute # at \$f1f1
.f817	2c f9	; execute B at \$f92c
.f819	c2 e4	; execute F at \$e4c2
.f81b	25 f8	; execute O at \$f825
.f81d	97 fa	; execute P at \$fa97
.f81f	bc fc	; execute Q at \$fc2c
.f821	a0 fc	; execute X at \$fca0
.f823	24 f9	; execute G at \$f924

#### **F825 JIFFYDOS OLD**

The following routine performs a basic old after a new or reset. The routine performs a rechain to set up correct pointers etc.

```
.f825  iny
      tya
      sta ($2b),y      ; store XX in $08XX to reinit basic
      jsr $a533        ; LINKPRG, rechain basic lines
      txa
      adc #$02
      tax
      lda $23
      adc #$00          ; (X) and (Y) contains start of variables
      tay
      jmp $ela7         ; set start of variables, and restart basic.
```

### **F838 JIFFYDOS COMMAND PART 2**

This routine is called from the JiffyDOS COMMAND routine and make a test for additional command characters after the '@' character. Only the command number \$0d-\$17 is tested. If text after '@' is not a JiffyDOS command (ie. a normal DOS command', or JiffyDOS command number less than \$10, a filename is expected. Tests are made for colon and quotes, the filename is evaluated, and parts of the OPEN/CLOSE routine is used to SETNAM. A test is made for additional device number after a comma. A free line on the screen is found, and some string-house keeping is done. Finally, the routine continues through to the next routine to open the command channel.

```
.f838  tya
      bne $f853
      sta $b7
.f83d  jsr $73          ; CHRGET, get character from buffer
      beq $f887        ; terminator found, exit
      ldy #$17         ; set pointer for start of command
      jsr $f731        ; test if character is JiffyDOS command
      bne $f858        ; nope, no command
      cpy #$0d         ; only test value $17 to $0d
      bcc $f858        ; if less than $0d, exit
      sty $27         ; temp store
      cpy #$10         ; read command value
      bcs $f887        ; if value larger than $10, filename is not expected
.f853  lda #$01
      jsr $a8fc        ; add TXTPTR by one
.f858  ldy #$ff        ; init pointer
.f85a  iny
      lda ($7a),y      ; read character from keyboard buffer
      beq $f867        ; terminator found
      cmp #$22         ; quotes?
      beq $f872        ; yes
      cmp #$3a         ; colon?
      bne $f85a        ; nope, next character
.f867  bit $9d         ; test MSGFLG, if direct mode
      bpl $f875
      clc
      jsr $aebd
      jmp $f878
.f872  jsr $a8fb        ; add value in (Y) to TXTPTR
.f875  jsr $ad9e        ; evaluate expression in text
```

```

.f878  jsr $e25a          ; use part of OPEN/CLOSE to SETNAM
      jsr $79            ; CHRGET
      cmp #$2c          ; test for comma ','
      bne $f887         ; nope
      jsr $b79b         ; use GTBYTC to read character after comma
.f885  stx $ba           ; store in FA, device number
.f887  ldy #$00
      bit $9d           ; test MSGFLG, if direct mode
      bpl $f89a
.f88d  lda ($d1),y       ; current screen line address, read from screen
      cmp #$20          ; space
      beq $f89a         ; yepp
      lda #$0d          ; carriage return
      jsr $e716         ; output to screen
      bne $f88d
.f89a  jsr $f75c         ; test if device FA is present
      lda #$ff
      jsr $b475
      lda $b7           ; FNLEN
      ldx $bb           ; FNADR, pointer to current filename
      ldy $bc
      jsr $b4c7
      jsr $b6a3         ; do string housekeeping
      stx $bb           ; store in FNADR, pointer to current filename
      sty $bc

```

#### **F8B2 OPEN COMMAND CHANNEL**

The following routine open the command channel. A test is done to see if it is allready open. If so, the command channel is closed before opened.

```

.f8b2  jsr $f2cf        ; close command channel if open
      lda $b7           ; read FNLEN, length of current filename, temp store
      ldx #$00          ; store 0
      stx $b7           ; in FNLEN
      ldx #$6f
      bne $f8c3         ; allways jump
      ldx #$6e
      lda $b7
.f8c3  stx $b9          ; store in SA, current secondary address
      stx $9f           ; store in JiffyDOS default filenamber
.f8c7  pha
      stx $b8           ; store in LA, current logical file number
      jsr $ffcc         ; CLRCHN, close all I/O channels
      jsr $ffco         ; OPEN
      pla
      sta $b7           ; restore FNLEN, length of current filename
.f8d3  rts              ; return

```

#### **F8D4 JIFFYDOS LOCK/UNLOCK FILE**

This routine locks/unlocks specified file. The file is opened, and tests are made to check that everything is OK. If so a bunch of code are transfered to the drive, and executed. The code to be transfered is found at \$f398, after the memory-write command.

```

.f8d4  jsr $f1e8        ; open file and test if all is OK
      bne $f8d3         ; not ok
      ldx #$00          ; setup drivecommand at $f398+0.

```

```

        ldy #$22          ; length of string
        jsr $f8e4         ; execute
        ldy #$05          ; setup drivecommand at $f398+$22, length 5 bytes
        ldx #$22
.f8e4   jsr $f0f4         ; execute direct drivecommand
        jmp $ffcc         ; CLRCHN, close all I/O channels

```

#### **F8EA JIFFYDOS PATCH, SERIAL SEND**

This is a patch to the original Commodore KERNAL to send data on the serial bus.

```

.f8ea   sta $dd00         ; store in serial bus I/O port
        and #$08         ; test ATN, attention
        beq $f910        ; ATN = 1
        lda $95          ; BSOUR
        ror a
        ror a
        cpx #$02         ; bit counter =2
        bne $f910        ; if not, exit
        ldx #$1e
.f8fb   bit $dd00
        bpl $f905
        dex
        bne $f8fb
        beq $f90e
.f905   bit $dd00
        bpl $f905
        ora #$40
        sta $a3
.f90e   ldx #$02
.f910   rts

```

#### **F911 JIFFYDOS DISPLAY ASCII FILE**

The following routine is called by the LIST ASCII from disk. It clears the command channel and calls a routine that reads maximum 254 character from the file. This is repeated until the entire file is displayed.

```

.f911   ldy #$00
        jsr $f0e2         ; CLRCHN and perform CHKIN on (A)
.f916   jsr $fca9         ; read text into buffer
        bvs $f91d        ; finish
        bcc $f916        ; next
.f91d   sty $b7           ; FNLEN, length of current filename
        lda $90          ; STATUS
        and #$82
        rts

```

#### **F924 JIFFYDOS INTERLEAVE**

The following routine sets the interleave gapsize by writing the selected value to drive memory at position \$0069.

```

.f924   jsr $b79b        ; GEBYTC, getbyte from keyboard buffer
        txa              ; transfer gapsize to (A)
        ldx #$2d         ; setup drive command at $f398+2d, M-W 69 00 01
        bne $f930        ; jump always

```

#### **F92C JIFFYDOS BUMP DISABLE**

The following routine disables the 1541 head rattle. This is done by writing the value \$85 to drivememory at position \$006a.

```
.f92c  lda #$85
      ldx #$27          ; setup drive command at $f398+$27, M-W 6a 00 01
.f930  ldy #$06
      pha
      jsr $f0f4         ; execute drive command
      pla
      jmp $ffd2         ; write byte in (A) to drive, and return
```

#### **F93A JIFFYDOS MARK FILE FOR COPY**

This routine toggles the copy flag for one file, or for all selected files depending on the entry point. If entry at \$f93a, the copy flags for all files will be toggled, and if entry at \$f93d only one will be affected.

```
.f93a  ldx #$00          ; toggle flag for all files
      .byte $2c         ; mask LDX-command
.f93d  ldx #$06          ; toggle flag for current file
      jsr $a68e         ; STXPT, reset TXTPTR to start of BASIC
      ldy #$05
      lda ($7a),y       ; test 5:th character
      cmp #$12          ; <RVS ON>?
      bne $f9b0         ; if not, directory not loadad, exit
      pla
      txa               ; store (X), the toggle flag, on stack
      pha
      ldy #$23          ; set offset to $23
.f94f  ldx #$22          ; search for a quote marks (")
      jsr $a917         ; use part of DATAN, to search for character
      dey
      jsr $a8fb         ; add offset in (Y) to TXTPTR
      pla               ; read flag, set at start
      pha
      beq $f96c         ; 'toggle all files' are set
      sta $d3
      ldy #$01
.f960  iny
      jsr $f16a         ; use part of 'input from screen'
      cmp ($7a),y
      bne $f977
      sbc #$22
      bne $f960
.f96c  tay
      lda ($7a),y       ; get character
      eor #$0a          ; toggle between $20 (space) and $2a (*)
      sta ($7a),y       ; store character
      ldy #$04
      sta ($d1),y
.f977  jsr $a8f8         ; DATA, perform data, skip line like REM
      ldy #$05
      sec
      lda ($7a),y
      sbc #$42
      bne $f94f         ; next line
      ldy #$02
      sta ($7a),y
```

```

        pla                ; set flag, read from stack
        beq $f98d          ; if zero, all files were marked/unmarked, do LIST
        lda #$8d
        rts
.f98d   jmp $a6a4          ; perform LIST

```

#### **F990 JIFFYDOS TOGGLE DRIVE COMMANDS**

This routine is continued from JiffyDOS get character. It tests if the keys <CTRL D> are pressed. If so, it increments the internal device counter and tests if it is present. The routine will return the new device number in (X), which will be printed, and the routine exits. If <CTRL D> were not pressed, it continues to test <CTRL A> and <CTRL W>. If not, the routine continues to the funktion key test.

```

.f990   bit $9d            ; test MSGFLG
        bpl $f9b0          ; exit
        tsx
        ldy $0107,x
        cpy #$e1
        bne $f9b0          ; exit
        cmp #$04           ; test code #$04, <CTRL D>, toggle drive
        bne $f9b2          ; if not, jump to next test
        inc $be            ; increment JiffyDOS device counter
        jsr $f73d          ; test device number in $be, output (X)
        lda #$00
        jsr $bdc9          ; print numeric value in (A/X)
        jsr $aad7          ; output CR/LF
        jsr $f79a          ;
.f9b0   pla                ; retrieve (A)
        rts                ; and exit
.f9b2   cmp #$01           ; test code #$01, <CTRL A>, toggle all files for copy
        beq $f93a          ; toggle all files copy
        cmp #$17           ; test code #$01, <CTRL W>, toggle one file for copy
        beq $f93d          ; toggle single file copy

```

#### **F9BA JIFFY DOS FUNKTION KEYS**

This routine test if a shifted, or unshifted funktion key were pressed. If so, it sends a string containing the command to the keyboard buffer. The vector in \$b0 points to the command sting table. The strings are in numerical order, and seperated by a null byte. To find the right string, the routine counts through them all till it reaches the X:th string.

```

.f9ba   ldy $9b            ; must be zero. Some internal JiffyDOS flag
        bne $f9b0          ; exit
        cmp #$8d          ; test keys F1 to F8
        bcs $f9b0          ; larger than F8, exit
        cmp #$85
        bcc $f9b0          ; less than F1, exit
        pla
        sbc #$85           ; subtract #$85
        tax                ; transfer key number to (X)
        beq $f9d5          ; if F1, do right away
.f9cc   iny                ; increment pointer
        lda ($b0),y        ; read and skip string in funktion key table
        bne $f9cc          ; repeat till last byte in string
        dex                ; next string

```

```

        bne $f9cc          ; till (X) strings are skipped
.f9d4   iny
.f9d5   lda ($b0),y        ; read command from corresponding key
        beq $f9e2          ; if final character, exit
        cmp #$0d           ; <return>
        beq $f9e4          ;
        jsr $e716          ; output to screen
        bne $f9d4          ; next character
.f9e2   sta $d4
.f9e4   rts

```

#### **F9E5 JIFFYDOS GET CHARACTER**

This routine is a new JiffyDOS routine to handle extended functions. It is called from \$e5ec, and starts with the original jump. The routine test the F-keys, and if a valid combination of <CTRL xx> is pressed. If quote mode or insert mode is activated, then this routine will exit.

```

.f9e5   jsr $e5b4          ; get character from keyboard buffer
        pha               ; temp store
        ldx $d4           ; test QTSV, if quote mode is activated
        bne $fa37          ; if not zero, quote mode is on - exit
        ldx $d8           ; test INSRT, insert mode
        bne $fa37          ; if not zero, insert mode is on - exit
        cmp #$10          ; test code #$10, <CTRL P>, screen dump
        bne $f990          ; if not pressed, jump and test other keys

```

#### **F9F5 JIFFYDOS SCREEN DUMP**

This routine performs a screen dump when the keys <CTRL P> are pressed. It reads \$d018 to determine if upper or lower character set is used, and sends the proper SA after LISTEN. The routine stores the cursor positions on the stack, and retrieves them, and replaces the cursor on exit. To print a character to the serial bus, the routine uses part of the KERNAL CIOUT routine.

```

.f9f5   lda #$04           ; printer device #4
        jsr $ffb1          ; send LISTEN to device #4
        lda $d018          ; test upper/lower character set
        and #$02
        beq $fa03
        lda #$07           ; set SA=#$67
.f9f5   ora #$60           ; set SA=#$60
        jsr $ff93          ; send SA after LISTEN
        lda $d3            ; PNTR, cursor column
        pha               ; temp store
        lda $d6            ; TBLX, cursor line
        pha               ; temp store
.f9f5   ldy #$00           ; column counter
        sty $d4            ; clear quotes mode, by writing zero into QTSW
        jsr $e50c          ; PLOT, put row and column
        inc $d5            ; increment LNMX, maximum screen line length
.f9f5   jsr $f16a          ; input from screen
        jsr $eddd          ; CIOUT, send data to serial bus (printer)
        cmp #$0d           ; carriage return
        bne $fa17          ; next character
        inx               ; increment (X), line number
        cpx #$19           ; till all 25 are done
        bcs $fa2d          ; exit

```



```

        asl $d5
        bpl $fa0e          ; next line
        inx
        bne $fa0e          ; next line
.fa2d   jsr $ffae          ; UNLISTEN
        pla                ; retrieve (X) and (Y)
        tax
        pla
        tay
        jsr $e50c          ; PLOT, put cursor on same position as on entry
.fa37   pla                ; return to original 'get character' routine with key
.fa38   rts                ; code in (A)

```

### **FA39 JIFFYDOS COPY COMMAND**

The following routine is executed to copy files.

```

.fa39   sty $26            ; (Y) =0, temp store
        jsr $f1e8          ; open command channel and read status
        bne $fa38          ; not OK, exit
        jsr $79            ; CHARGET
        cmp #$52           ; R
        bne $fa5a
.fa47   dec $26
        lda $26
        jsr $f66b
        jsr $e4c6          ; input byte from command channel, and compare to 5
        beq $fa47          ; yepp
        lda #$00
        jsr $f66b
        lda #$4c          ; L
.fa5a   pha
        ldx $bf
        cpx $ba            ; compare to FA, current device number
        beq $fa37          ; exit
        jsr $f885
        ldx #$37           ; setup drive command at $f398+$37
        ldy #$02           ; 2 bytes long
        jsr $f0f4          ; send S:
        jsr $f5c1          ; print filename
        lda #$2c           ; ,
        sta ($bb),y        ; store in filename buffer
        iny
        pla                ; retrieve command
        sta ($bb),y        ; store in filename buffer
        iny
        lda #$2c
        sta ($bb),y        ; ,
        iny
        lda $26
        pha
        bne $fa83
        lda #$57
.fa83   sta ($bb),y        ; W
        iny
        sty $b7            ; update FNLEN, legnth of current filename
        ldy #$0c
.fa8a   jsr $fab2          ; set SA to (Y) and more

```

```

jsr $f73d      ; test for present device
jsr $f8b2      ; open command channel
pla
jsr $f541      ; use list ASCII from disk to perform copy

```

#### **FA97 TOGGLE PRINTER**

The following routine toggles the printer output funktion. It reads the CHANNL to determine if printmode is to be turned on or off.

```

.faa97  lda $13          ; CHANNL, contains 00 if current output is screen
        beq $faa7        ; toggle printer on
        cmp #$7f         ; CHANNL, contains 7f if current output is printer
        bne $fa38        ; jump to RTS
        jsr $abb7        ; CLRCHN, clear all channels, and set CHANNL=0
        lda #$7f
        jmp $ffc3        ; close file $7f

.faa7   ldx #$04          ; devicenumber #4 = printer
        jsr $73           ; CHRGET??
        jsr $e229         ; use part of OPEN routine to open dev#4
        jsr $f75c         ; test device number in FA
.fab2   sty $b9           ; SA, current secondary address
        ldx #$7f
        stx $13          ; CHANNL, current I/O channel
        lda $b7           ; FNLEN, length of current filename
        jmp $f8c7         ; perform CLRCHN and OPEN file (X)

        tax
        bne $fa8a
        lda $b5
        beq $face

```

#### **FAC4 PATCH TO ORIGINAL "LOAD" ROUTINE**

This routine is a patch to the original load routine and tests is the current device is a JiffyDOS device. If not, the routine jumps back to the original loader at \$f4f3. The routine disables the sprites and calculates the timing parameters to \$b1. Some handshaking is done

```

.fac4   jsr $f5d2        ; print "LOADING/VERIFYING"
        tsx              ; test if some return pointer on the stack is $f7
        lda $0102,x
        cmp #$f7
        bne $fad7        ; if not, don't store the $ae/$af parameters
        lda $ae
        sta $55
        lda $af
        sta $56
.fad7   bit $a3          ; ldflg, are we talking to a JiffyDOS device?
        bmi $fade        ; yes
        jmp $f4f3        ; nope, return to the original loadroutine.
.fade   sei              ; no interrupts
        ldy #$03
.fae1   lda $af,y        ; save $b0,$b1,$b2 on the stack
        pha
        dey
        bne $fae1

```

```

        lda $d015          ; any sprites enabled?
        sta $b0            ; store
        jsr $f0d8          ; clear all sprites not to mess up the timing!
.faf0   jsr $f6bc          ; <STOP> key pressed?
        bpl $fb27          ; yes - exit
        lda $d011          ; read finscroll
        and #$07           ; mask bits
        clc
        adc #$2f           ; add $2f - start of the visible screen
        sta $b1            ; store
        lda $dd00          ; read and store the lower three bits in $dd00
        and #$07           ; they contain PA2 and gfxbank pointers
        sta $b2
        sta $dd00          ; clear
        ora #$20           ; %00100000
        tax
.fb0c   bit $dd00          ; bit test
        bvc $fb0c          ; loop if input clk=0
        bpl $fb3e          ; goto LOADER if input data=0
        ldx #$64
.fb15   bit $dd00          ; bit test
        bvc $fb20          ; EOI if input clk=0
        dex
        bne $fb15          ; repeat $64 times
        lda #$42           ; status code $42, EOI & READ TIMEOUT
        .byte $2c
.fb20   lda #$40           ; status code $40, EOI
        jsr $felc          ; set STATUS
        clc                ; clear carry
        .byte $24          ; mask
.fb27   sec                ; set carry
        lda $b0            ; enable sprites
        sta $d015
        pla                ; restore zero page addresses
        sta $b0
        pla
        sta $b1
        pla
        sta $b2
        bcs $fb3b          ; if carry set, exit the normal way
        jmp $f528          ;
.fb3b   jmp $f633          ; exit and unlisten

```

#### **FB3E THE JIFFYDOS XFER ROUTINE FOR LOAD**

```

.fb3e   bit $dd00          ; drive timing
        bpl $fb3e          ; loop if input data=0
        sec
.fb44   lda $d012          ; raster timing
        sbc $b1
        bcc $fb4f
        and #$07
        beq $fb44
.fb4f   lda $b2            ; lower three bits of $dd00
        stx $dd00          ; store %00100xxx in $dd00
        bit $dd00          ; bit test
        bvc $faf0          ; branch is input clk=0

```

```

nop                ; timing
sta $dd00          ; store %00000xxx in $dd00
ora $dd00          ; read two first bits
lsr a              ; move right two times
lsr a
nop                ; timing
ora $dd00          ; read next two bits
lsr a              ; move right two times
lsr a
eor $b2            ; "trixx" to handle the lower three bits of $dd00
eor $dd00
lsr a              ; move right two times
lsr a
eor $b2            ; "trixx" to handle the lower three bits of $dd00
eor $dd00
cpy $93            ; load/verify flag
bne $fb83          ; branch if verify
sta ($ae),y        ; store loaded byte in memory
.fb7a inc $ae        ; next low-byte
bne $fb44          ; fetch next byte
inc $af            ; next high byte
jmp $fb44          ; fetch next byte
.fb83 cmp ($ae),y    ; verify byte
beq $fb7a          ; equal
sec
lda #$10           ; verify error
sta $90            ; store in STATUS
bne $fb7a          ; continue

lda $c2
sta $ad
lda $c1
sta $ac
rts

```

#### **FB97 JIFFYDOS DISABLE SPRITES BEFORE ACPTR**

This routine disables all the sprites on the screen, and continues the loading procedure. Afterwards the sprites are enabled again.

```

.fb97 pha          ; store the $d015 value on the stack
jsr $f0d8          ; disable all the sprites
jsr $fbb4          ; continue the loader below
pla                ; restore
sta $d015          ; and enable sprites again
lda $a4            ;
rts

```

#### **FBA5 JIFFYDOS ACPTR**

This is the JiffyDOS ACPTR routine which fetches a byte from the serial bus. Entry point is \$fbaa where a test is done by checking \$a3 to see if the current device is a JiffyDOS device. Visible sprites are disabled, and raster-timing is done so that no serial access is done when there is a "bad rasterline"

```

.fba5 lda #$00      ; jump back to the normal load routine
      jmp $ee16
.fbaa sei

```

```

        bit $a3          ; test $a3 to see if the device is a JiffyDOS drive
        bvc $fba5        ; nope, back to normal load routine
        lda $d015        ; sprites on screen that can mess up the critical
                        ; timing
        bne $fb97        ; yes, clear sprites before loading
.fbb4   lda $dd00        ; serial bus
        cmp #$40         ; test bit 6
        bcc $fbb4        ; loop
        and #$07         ; mask lower three bits
        pha             ; store
.fbbe   lda $d012        ; current raster line
        sbc $d011        ; subtract fine scroll register
        and #$07         ; mask upper bits
        cmp #$07
        bcs $fbbbe       ; wait a little longer
        pla             ; restore
        sta $dd00        ; write output clk=0 and output data=0
        sta $a4
        ora #$20         ; set bit 5=1
        pha             ; store on stack
        nop             ; timing
        nop
        ora $dd00        ; first two bits
        lsr a            ; rotate right
        lsr a
        nop             ; timing
        ora $dd00        ; next bits
        lsr a            ; rotate right
        lsr a
        eor $a4          ; take care of the lower three bits in $dd00
        eor $dd00        ; next bits
        lsr a            ; rotate right
        lsr a
        eor $a4          ; take care of the lower three bits in $dd00
        eor $dd00        ; next bits
        sta $a4
        pla             ; restore from stack
        bit $dd00        ; bit test
        sta $dd00        ; store
        bvc $fc22
        bpl $fc1d
        lda #$42
        jmp $edb2

```

#### **FBFE PATCH SEND DATA ON SERIAL LINE**

The following routine is used to send a byte to a device on ther serial bus. The routine checks if the device is a JiffyDOS device by reading \$a3. If not a JiffyDOS device, the routine jumps back to the original load routine at \$ed40.

```

.fbfe   sei             ; disable interrupts
        bit $a3         ; ldflg
        bvc $fc14       ; test some more
.fc03   lda $d015        ; any sprites enabled
        beq $fc27       ; nope, continue the send byte routine
        pha             ; store number of sprites on the stack
        jsr $f0d8       ; disable all sprites
        jsr $fc27       ; send-byte routine

```

```

        pla                ; read stack
        sta $d015          ; enable sprites
        rts                ; return
.fc14   lda $a3            ; ldflg
        cmp #$a0
        bcs $fc03          ; go and test sprites
        jmp $ed40          ; original send data on serial bus

.fc1d   lda #$40           ; %01000000 (EOI)
        jsr $felc          ; set I/O status
.fc22   lda $a4
.fc24   cli
        clc
        rts

```

#### **FC27 JIFFYDOS PATCH SEND DATA ON SERIAL LINE**

The bits in BSOUR are sent in the following order %22114334.

```

.fc27   txa                ; store (X) on the stack
        pha
        lda $95            ; BSOUR, the byte to send
        and #$f0           ; upper four bits
        pha                ; on stack
        lda $95            ; BSOUR, the byte to send
        and #$0f           ; lower four bits
        tax                ; to (X)
.fc33   lda $dd00          ; serial bus
        bpl $fc33          ; loop as long as data input=0
        and #$07           ; %00000111, mask lower three bits, PA2 and gfx bank
        sta $95            ; store
        sec
.fc3d   lda $d012          ; time the send routine with the raster
        sbc $d011          ; badlines are not allowed durin xfer
        and #$07
        cmp #$06
        bcs $fc3d         ; wait
        lda $95            ; 00000xxx
        sta $dd00          ; clear serial bus to "clock" the drive
        pla                ; upper four bits to send
        ora $95            ; set PA2 and gfx bank
        sta $dd00          ; send to drive over serial bus
        lsr a              ; next two bits
        lsr a
        and #$f0           ; clear low nybble
        ora $95            ; and set PA2 and gfx bank
        sta $dd00          ; send to drive over serial bus
        lda $fc8a,x        ; use (X) as offset for lownybble-table
        ora $95            ; set PA2 and gfx bank
        sta $dd00          ; send to drive over serial bus
        lsr a              ; next two bits
        lsr a
        and #$f0           ; clear low nybbles
        ora $95            ; set PA2 and gfx bank
        sta $dd00          ; send to drive over serial bus
        and #$0f

```

```

        bit $a3
        bmi $fc76
        ora # $10
.fc76  sta $dd00
        pla                ; restore (X)
        tax
        lda $95            ; PA2 and gfk bank
        ora # $10          ; set send clk=1
        sta $dd00          ; store
        bit $dd00          ; read serial bus
        bpl $fc24          ; branch if input data=0
        jmp $edb0          ; back

```

#### **FCA8 JIFFYDOS SENDTABLE**

A table of bit combinations for the lower nybble of the byte to send to a JiffyDOS device.

```

.fc8a  .byte %00000000    ; $00
        .byte %10000000    ; $80
        .byte %00100000    ; $20
        .byte %10100000    ; $a0
        .byte %01000000    ; $40
        .byte %11000000    ; $c0
        .byte %01100000    ; $60
        .byte %11100000    ; $e0
        .byte %00010000    ; $10
        .byte %10010000    ; $90
        .byte %00110000    ; $30
        .byte %10110000    ; $b0
        .byte %01010000    ; $50
        .byte %11010000    ; $d0
        .byte %01110000    ; $70
        .byte %11110000    ; $f0

        beq $fcbb
        ldx # $f7
        jmp $f5c1

```

#### **FCA0 JIFFYDOS X COMMAND**

The following routine sets the destination devicenum when using the JiffyDOS copyroutine.

```

.fca0  jsr $b79b          ; GTBYTC, get destination device
        stx $bf            ; store in $bf
        rts                ; back

```

#### **FCA6 READ INTO BUFFER**

The following routine is used by the LIST ASCII and LIST BASIC directly from disk. It reads a number of bytes into the filename buffer area.

```

.fca6  jsr $f0e2          ; CLRCHN, and perform CHKIN on (A)
.fca9  jsr $ffcf          ; CHRIN
        sta ($bb),y        ; FNADR POINTER, store in buffer for current filename
        iny                ; next character
        bit $90            ; test STATUS
        bvs $fcbb          ; exit

```

```

        cpy #$fe          ; max length
        bcs $fcbb         ; yepp
        cmp #$01          ; larger than 1
        bcs $fca9         ; yepp, repeat
.fcbb   rts

```

#### **FCBC DISABLE JIFFYDOS COMMANDS**

The following routine is called by the @X command and restores the IERROR, IMAIN and ICRNCH vector.

```

.fcbc   ldx #$05
.fcbe   lda $f1a3,x       ; table with original vectors
        sta $0300,x       ; store in vector table
        dex
.fcc5   bpl $fcbe
        stx $9b           ; (X)=255, JiffyDOS not activated.
        rts

        lda aa5
        ora (p29,x)
        sbc f0185,x
        sec
        lda aac
        sbc aae
        lda aad
        sbc aaf
        rts
        inc aac
        bne ifcel
        inc aad
ifcel   rts

```

#### **FCE2 POWER RESET ENTRY POINT**

The system hardware reset vector (\$FFFC) points here. This is the first routine executed when the computer is switched on. The routine firstly sets the stackpointer to #ff, disables interrupts and clears the decimal flag. It jumps to a routine at \$fd02 which checks for autostart-cartridges. If so, an indirectjump is performed to the cartridge coldstart vector at \$8000. I/O chips are initiated, and system constants are set up. Finally the IRQ is enabled, and an indirect jump is performed to \$a000, the basic cold start vector.

Future implementaions? - A patch to disable the \$8000 autostart if a special key is pressed.

```

.fce2   ldx #$ff
        sei
        txs              ; Set stackpointer to #ff
        cld
.fce7   jsr $fd02         ; Check ROM at $8000
        bne $fcef
        jmp ($8000)       ; Jump to autostartvector
.fcef   stx $d016
        jsr $fda3         ; Init I/O
        jsr $fd50         ; Init system constants
        jsr $fd15         ; KERNAL reset
        jsr $ff5b         ; Setup PAL/NTSC

```



```
cli
jmp ($a000)      ; Basic coldstart
```

#### **FD02 CHECK FOR 8-ROM**

Checks for the ROM autostartparametrar at \$8004-\$8008. It compares data with \$fd10, and if equal, set Z=1.

```
.fd02  ldx #$05          ; 5 bytes to check
.fd04  lda $fd0f,x       ; Identifier at $fd10
        cmp $8003,x      ; Compare with $8004
        bne $fd0f        ; NOT equal!
        dex
        bne $fd04        ; until Z=1
.fd0f  rts
```

#### **FD10 8-ROM IDENTIFIER**

The following 5 bytes contains the 8-ROM identifier, reading "CBM80" with CBM ASCII. It is used with autostartcartridges. See \$fd02.

```
.fd10  c3 c2 cd 38 30    ; CBM80
```

#### **FD15 RESTOR: KERNAL RESET**

The KERNAL routine RESTOR (\$ff8a) jumps to this routine. It restores (copies) the KERNAL vectors at \$fd30 to \$0314-\$0333. Continues through VECTOR.

```
.fd15  ldx #$30
        ldy #$fd         ; $fd30 - table of KERNAL vectors
        clc              ; Clear carry to SET values.
```

#### **FD1A VECTOR: KERNAL MOVE**

The KERNAL routine VECTOR (\$ff8d) jumps to this routine. It reads or sets the vectors at \$0314-\$0333 depending on state of carry. X/Y contains the adress to read/write area, normally \$fd30. See \$fd15.

A problem is that the RAM under the ROM at \$fd30 always gets a copy of the contents in the ROM then you perform the copy.

```
.fd1a  stx $c3           ; MEMUSS - c3/c4 temporary used for adress
        sty $c4
        ldy #$1f         ; Number of bytes to transfer
.fd20  lda $0314,y
        bcs $fd27        ; Read or Write the vectors
        lda ($c3),y
.fd27  sta ($c3),y
        sta $0314,y
        dey
        bpl $fd20        ; Again...
        rts
```

#### **FD30 KERNAL RESET VECTORS**

These are the vectors that is copied to \$0314-\$0333 when RESTOR is called. These vectors are the same in JiffyDOS, as in stock Commodore KERNAL.

```
.fd30  31 ea            ; CINV VECTOR: hardware interrupt ($ea31)
.fd32  66 fe            ; CBINV VECTOR: software interrupt ($fe66)
.fd34  47 fe            ; NMINV VECTOR: hardware nmi interrupt ($fe47)
.fd36  4a f3            ; IOPEN VECTOR: KERNAL open routine ($f3a4)
.fd38  91 f2            ; ICLOSE VECTOR: KERNAL close routine ($f291)
```

```

.f3da 0e f2          ; ICHKIN VECTOR: KERNAL chkin routine ($f20e)
.f3dc 50 f2          ; ICKOUT VECTOR: KERNAL chkout routine ($f250)
.f3de 33 f3          ; ICLRCH VECTOR: KERNAL clrchn routine ($f333)
.f3e0 57 f1          ; IBASIN VECTOR: KERNAL chrin routine ($f157)
.f3e2 ca f1          ; IBSOUT VECTOR: KERNAL chrout routine ($f1ca)
.f3e4 ed f6          ; ISTOP VECTOR: KERNAL stop routine ($f6ed)
.f3e6 3e f1          ; IGETIN VECTOR: KERNAL getin routine ($f13e)
.f3e8 2f f3          ; ICLALL VECTOR: KERNAL clall routine ($f32f)
.f3ea 66 fe          ; USRCMD VECTOR: user defined ($fe66)
.f3ec a5 f4          ; ILOAD VECTOR: KERNAL load routine ($f4a5)
.f3ee ed f5          ; ISAVE VECTOR: KERNAL save routine ($f5ed)

```

#### **FD50 RAMTAS: INIT SYSTEM CONSTANTS**

The KERNAL routine RAMTAS(\$ff87) jumps to this routine. It clears the pages 0,2 and 3 by writing 00 into them. It also sets the start of the cassette buffer - \$033c, and determines how much free RAM-memory there is. (The tapebuffer could probably be removed, since JiffyDOS doesn't use tapes at all.) The memorycheck is performed by writing two different bytes into all memory positions, starting at \$0400, till it reaches the ROM (the byte read is not the same as the one you wrote.) Note that the contents of the memory is restored afterwards. Finally, bottom of the memory, and top of screen-pointers are set.

Future implementations? - Make a faster RAMcheck routine which not reads all bytes from \$0400 and upwards. There can only be ROM at \$8000 to \$a000, so why bother to check elsewhere. Save a few bytes and lots of time!!

```

.f350 lda #$00
    tay
.f353 sta $02,y      ; Fill pages 0,2,3 with zeros
    sta $0200,y
    sta $0300,y
    iny
    bne $f353        ; all 256 bytes
    ldx #$3c
    ldy #$03         ; Set tapebuffer to $033c
    stx $b2          ; Variables TAPE1 is used.
    sty $b3
    tay
    lda #$03
    sta $c2
.f36c inc $c2
.f36e lda ($c1),y    ; Perform memorytest. Starting at $0400 and upwards.
    tax              ; Store temporary in X-reg
    lda #$55
    sta ($c1),y      ; Write #$55 into memory
    cmp ($c1),y      ; and compare.
    bne $f388        ; if not equal... ROM
    rol a
    sta ($c1),y      ; Write $AA into same memory
    cmp ($c1),y      ; and compare again.
    bne $f388        ; if not equal... ROM
    txa
    sta ($c1),y      ; Restore stored value
    iny
    bne $f36e        ; Next memorypos
    beq $f36c        ; New page in memory

```

```
.fd88 tya                ; The memorytest always exits when reaching a ROM
tax
ldy $c2
clc
jsr $fe2d              ; Set top of memory. X and Y holds address.
lda #$08
sta $0282              ; Set pointer to bottom of memory ($0800)
lda #$04
sta $0288              ; Set pointer to bottom of screen ($0400)
rts
```

#### **FD96 TAPE IRQ VECTORS**

This table contains the vectors to the four tape-IRQ routines. The vectors are: \$fc6a - tape write I, \$fc6d - tape write II, \$ea31 - normal IRQ, \$f92c - tape read. This table could probably be removed, to gain another 8 bytes of free ROM for own code.

```
.fd96 6a fc bd fc 31 ea 2c f9
```

#### **FDA3 IOINIT: INIT I/O**

The KERNAL routine IOINIT (\$ff84) jumps to this routine. It sets the init-values for the CIAs (IRQ, DDRA, DRA etc.), the SID-volume, and the processor onboard I/O port.

```
.fda3 lda #$7f
sta $dc0d              ; CIA#1 IRQ control register
sta $dd0d              ; CIA#2 IRQ control register
sta $dc00              ; CIA#1 data port $ (keyboard)
lda #$08
sta $dc0e              ; CIA#1 control register timer A
sta $dd0e              ; CIA#2 control register timer A
sta $dc0f              ; CIA#1 control register timer B
sta $dd0f              ; CIA#2 control register timer B
ldx #$00
stx $dc03              ; CIA#1 DDRB. Port B is input
stx $dd03              ; CIA#2 DDRB. Port B is input
stx $d418              ; No sound from SID
dex
stx $dc02              ; CIA#1 DDRA. Port A is output
lda #$07
; %00000111
sta $dd00              ; CIA#2 dataport A. Set Videobank to $0000-$3fff
lda #$3f
; %00111111
sta $dd02              ; CIA#2 DDRA. Serial bus and videobank
lda #$e7
; 6510 I/O port - %XX100111
sta $01
lda #$2f
; 6510 I/O DDR - %00101111
sta $00
```

#### **FDDD ENABLE TIMER**

This routine inits and starts the CIA#1 timer A according to the PAL/NTSC flag. Different system clocks rates are used in PAL/NTSC systems.

```
.fddd lda $02a6        ; PAL/NTSC flag
beq $fdec              ; NTSC setup
lda #$25
sta $dc04              ; CIA#1 timer A - lowbyte
lda #$40
; PAL-setup #4025
```

```

        jmp $fdf3
.fdec  lda #$95
        sta $dc04          ; CIA#1 timer A - lowbyte
        lda #$42          ; NTSC-setup #4295
.fdf3  sta $dc05          ; CIA#1 timer A - highbyte
        jmp $ff6e          ; start timer

```

#### **FDF9 SETNAM: SAVE FILENAME DATA**

The KERNAL routine SETNAM (\$ffbd) jumps to this routine. On entry, A-reg holds the length of the filename, and X/Y the address in mem to the filename.

```

.fdf9  sta $b7            ; store length of filename in FNLEN
        stx $bb            ; store pointer to filename in FNADDR
        sty $bc
        rts

```

#### **FE00 SETLFS: SAVE FILE DETAILS**

The KERNAL routine SETLFS (\$ffba) jumps to this routine. On entry A-reg holds the logical filename, X the device number, and Y the secondary address.

```

.fe00  sta $b8            ; store logical filename in LA
        stx $ba            ; store devicenum in FA
        sty $b9            ; store secondary address in SA
        rts

```

#### **FE07 READST: READ STATUS**

The KERNAL routine READST (\$ffb7) jumps to this routine. The routine checks if the current devicenum is 2, (ie RS232) then the value of RSSTAT (the ACIA 6551 status) is returned in (A), and RSSTAT is cleared. Else it reads and returns the value of STATUS.

```

.fe07  lda $ba            ; read current device number from FA
        cmp #$02          ; device = RS232?
        bne $fel1a        ; nope, read STATUS
        lda $0297          ; RSSTAT
        pha                ; temp store
        lda #$00
        sta $0297          ; clear RSSTAT
        pla
        rts

```

#### **FE18 SETMSG: FLAG STATUS**

The KERNAL routine SETMSG (\$ff90) jumps to this routine. On entry, the value in (A) is stored in MSGFLG, then the I/O status is placed in (A). If routine is entered at \$felc the contents in (A) will be stored in STATUS.

```

.fe18  sta $9d            ; store MSGFLG
.fel1a  lda $90            ; read STATUS
.felc  ora $90
        sta $90
        rts

```

#### **FE21 SETTMO: SET TIMEOUT**

The KERNAL routine SETTMO (\$ffa2) jumps to this routine. On entry the value in (A) is stored in the IEEE timeout flag. (Who uses IEEE nowadays?)

```

.fe21  sta $0285          ; store in TIMOUT

```

rts

#### **FE25 MEMTOP: READ/SET TOP OF MEMORY**

The KERNAL routine MEMTOP (\$ffa9) jumps to this routine. If carry is set on entry, the top of memory address will be loaded into (X/Y). If carry is clear on entry, the top of memory will be set according to the contents in (X/Y)

```
.fe25  bcc $fe2d          ; carry clear?
        ldx $0283         ; read memtop from MEMSIZ
        ldy $0284
.fe2d  stx $0283         ; store memtop in MEMSIZ
        sty $0284
        rts
```

#### **FE34 MEMBOT: READ/SET BOTTOM OF MEMORY**

The KERNAL routine MEMBOT (\$ff9c) jumps to this routine. If carry is set on entry, the bottom of memory address will be loaded into (X/Y). If carry is clear on entry, the bottom of memory will set according to the contents in (X/Y)

```
.fe34  bcc $fe3c          ; carry clear?
        ldx $0281         ; read membot from MEMSTR
        ldy $0282
.fe3c  stx $0281         ; store membot in MEMSTR
        sty $0282
        rts
```

#### **FE43 NMI ENTRY POINT**

The processor jumps to this routine every time a NMI occurs (see jump vector at \$fffa). On entry all processor registers will be put on the stack. The routine will check the presents of a ROM cartridge at \$8000 with autostart, and warm start it. Otherwise, the following warm start routine is called.

```
.fe43  sei                ; disable interrupts
        jmp ($0318)        ; jump to NMINV, points normally to $fe47
.fe47  pha                ; store (A), (X), (Y) on the stack
        txa
        pha
        tya
        pha
        lda #$7f          ; CIA#2 interrupt control register
        sta $dd0d
        ldy $dd0d
        bmi $fe72         ; NMI caused by RS232? If so - jump
        jsr $fd02         ; check for autostart at $8000
        bne $fe5e
        jmp ($8002)        ; Jump to warm start vector
.fe5e  jsr $f6bc          ; Scan one row in the keymatrix and store value in $91
        jsr $ffe1         ; Check $91 to see if <STOP> was pressed
        bne $fe72         ; <STOP> not pressed, skip part of following routine
```

#### **FE66 WARM START BASIC**

This routine is called from the NMI routine above. If <STOP> was pressed, then KERNAL vectors are restored to default values, I/O vectors initialised and a jump to (\$a002), the Basic warm start vector.

The NMI routine continues at \$fe72 by checking the RS232, if there is anything to send.

```

.fe66  jsr $fd15          ; KERNAL reset
      jsr $fda3          ; init I/O
      jsr ee518          ; init I/O
      jmp ($a002)        ; jump to Basic warm start vector

.fe72  tya              ; Read CIA#2 interrupt control register
      and $02a1          ; mask with ENABL, RS232 enable
      tax              ; temp store in (X)
      and #$01          ; test if sending (%00000001)
      beq $fea3          ; nope, jump to recieve test
      lda $dd00          ; load CIA#1 DRA
      and #$fb          ; mask bit2 (RS232 send)
      ora $b5           ; NXTBIT, next bit to send
      sta $dd00          ; and write to port
      lda $02a1
      sta $dd0d          ; write ENABL to CIA#2 I.C.R
      txa              ; get temp
      and #$12          ; test if recieving (bit1), or waiting for reciever
                        ; edge (bit4) ($12 = %00010010)
      beq $fe9d          ; nope, skip reciever routine
      and #$02          ; test if recieving
      beq $fe9a          ; nope
      jsr $fed6          ; jump to NMI RS232 in
      jmp $fe9d

.fe9a  jsr $ff07          ; jump to NMI RS232 out
.fe9d  jsr $eebb          ; RS232 send byte
      jmp $feb6          ; goto exit

.fea3  txa              ; get temp
      and #$02          ; test bit1
      beq $feae          ; nope
      jsr $fed6          ; NMI RS232 in???
      jmp $feb6          ; goto exit

.feae  txa              ; set temp
      and #$10          ; test bit4
      beq $feb6          ; nope, exit
      jsr $ff07          ; NMI RS232 out
.feb6  lda $02a1          ; ENABL
      sta $dd0d          ; CIA#2 interrupt control register
      pla              ; restore registers (Y),(X),(A)
      tay
      pla
      tax
      pla
      rti              ; back from NMI

```

#### **FEC2 RS232 TIMING TABLE - NTSC**

Timingtable for RS232 NMI for use with NTSC machines. The table containe 10 entries which corresponds to one of the fixed RS232 rates, starting with lowest (50 baud) and finishing with the highest (2400 baud). Since the clock frequency is different between NTSC and PAL systems, there is another table for PAL machines at \$e4ec.

Future implementations? Remove the table if you run a PAL machine, and put some own code here.

```
cmp ($27,x)
```

```

        rol fc51a,x
        ora ($74),y
        $sl $0ced
        eor $06
        beq $fed2
        lsr $01
.fed2   clv
        brk
        $dc ($00),y

```

#### **FED6 NMI RS232 IN**

This routine inputs a bit from the RS232 port and sets the baudrate timing for the next bit. Continues to the RS232 receive routine.

```

.fed6   lda $dd01          ; RS232 I/O port
        and #$01          ; test bit0, received data
        sta $a7           ; store in INBIT
        lda $dd06         ; lowbyte of timer B
        sbc #$1c
        adc $0299         ; <BAUDOF
        sta $dd06         ; store timer B
        lda $dd07         ; highbyte of timer B
        adc $029a         ; >BAUDOF
        sta $dd07         ; store timer B
        lda #$11
        sta $dd0f         ; CIA#2 control register B
        lda $02a1         ; ENABL
        sta $dd0d         ; CIA#2 interrupt control register
        lda #$ff
        sta $dd06
        sta $dd07
        jmp $ef59         ; jump to RS232 receive routine

```

#### **FF07 NMI RS232 OUT**

This routine sets up the baudrate for sending the bits out, and adjusts the number of bits remaining to send.

```

.ff07   lda $0295         ; M51AJB - non standard BPS time
        sta $dd06         ; timer B low
        lda $0296
        sta $dd07         ; timer B high
        lda #$11
        sta $dd0f         ; CIA#2 control register B
        lda #$12
        eor $02a1
        sta $02a1         ; ENABL, RS232 enables
        lda #$ff
        sta $dd06
        sta $dd07         ; timer B
        ldx $0298         ; BITNUM, number of bits still to send in this byte
        stx $a8           ; BITC1, RS232 bitcount
        rts
.ff2f   tax
        lda $0296
        rol
        tay
        txa
        adc #$c8

```

```

sta $0299
tya
adc #$00
sta $029a
rts

```

#### **FF41 FAKE IRQ**

Fake IRQ entry that clears bit4 which is later tested for HW or SW interrupt. This entry will always create a hardware interrupt.

```

nop                ; don't ask me??
nop
php                ; store processor reg.
pla                ; get reg
and #$ef           ; clear bit4
pha                ; store reg

```

#### **FF48 IRQ ENTRY**

This routine is pointed to by the hardware IRQ vector at \$fffe. This routine is able to distinguish between a hardware IRQ, and a software BRK. The two types of interrupts are processed by its own routine.

```

.ff48 pha          ; Store Acc
      txa
      pha          ; Store X-reg
      tya
      pha          ; Store Y-reg
      tsx
      lda $0104,x  ; Read byte on stack written by processor?
      and #$10     ; check bit 4 to determine HW or SW interrupt
      beq $ff58
      jmp ($0316)  ; jump to CBINV. Points to FE66, basic warm start
.ff58 jmp ($0314)  ; jump to CINV. Points to EA31, main IRQ entry point

```

#### **FF5B CINT: INIT SCREEN EDITOR**

The KERNAL routine CINT (\$FF81) jumps to this routine. It sets up VIC for operation. The original CINT is at \$e518, and this patch checks out if this is a PAL or NTSC machine. This is done by setting the raster compare register to 311, which is the number of scanlines in a PAL machine. If no interrupt occurs, then it's a NTSC machine.

```

.ff5b jsr $e518    ; original I/O init
.ff5e lda $d012    ; wait for top of screen
      bne $ff5e    ; at line zero
      lda $d019    ; Check IRQ flag register if interrupt occurred
      and #$01     ; only first bit
      sta $02a6    ; store in PAL/NTSC flag
      jmp $fddd    ; jump to ENABLE TIMER

```

#### **FF6E START TIMER**

This routine starts the CIA#1 timer and jumps into a routine that handles the serial clock.

```

.ff6e lda #$81     ; Enable IRQ when timer B reaches zero
      sta $dc0d    ; CIA#1 interrupt controll register
      lda $dc0e    ; CIA#1 control register A
      and #$80

```



```

ora #$11          ; Force load of timer A values -bit4, and start -bit0
sta $dc0e         ; Action!
jmp $ee8e         ; Continue to 'serial clock off'

```

#### **FF80 KERNAL VERSION ID**

This byte contains the version number of the KERNAL.

```
.ff80 sed $
```

#### **FF81 KERNAL JUMP TABLE**

This table contains jump vectors to the I/O routines. This is a Commodore standard, so no matter what system you are using (VIC20, C64, C128, Plus4 etc) the jump vectors are always located at this position.

```

.ff81 jmp $ff5b          ; CINT, init screen editor
.ff84 jmp $fda3          ; IOINT, init input/output
.ff87 jmp $fd50          ; RAMTAS, init RAM, tape screen
.ff8a jmp $fd15          ; RESTOR, restore default I/O vector
.ff8d jmp $fd1a          ; VECTOR, read/set I/O vector
.ff90 jmp $fe18          ; SETMSG, control KERNAL messages
.ff93 jmp $edb9          ; SECOND, send SA after LISTEN
.ff96 jmp $edc7          ; TKSA, send SA after TALK
.ff99 jmp $fe25          ; MEMTOP, read/set top of memory
.ff9c jmp $fe34          ; MEMBOT, read/set bottom of memory
.ff9f jmp $ea87          ; SCNKEY, scan keyboard
.ffa2 jmp $fe21          ; SETTMO, set IEEE timeout
.ffa5 jmp $fbaa          ; ACPTR, input byte from serial bus. JiffyDOS poits
                        ; to $fbaa, the original to $ee13.
.ffa8 jmp $eddd          ; CIOUT, output byte to serial bus
.ffab jmp $edef          ; UNTALK, command serial bus UNTALK
.ffaе jmp $edfe          ; UNLSN, command serial bus UNLSN
.ffb1 jmp $ed0c          ; LISTEN, command serial bus LISTEN
.ffb4 jmp $ed09          ; TALK, command serial bus TALK
.ffb7 jmp $fe07          ; READST, read I/O status word
.ffba jmp $fe00          ; SETLFS, set logical file parameters
.ffbd jmp $fdf9          ; SETNAM, set filename
.ffc0 jmp ($031a)        ; OPEN, open file
.ffc3 jmp ($031c)        ; CLOSE, close file
.ffc6 jmp ($031e)        ; CHKIN, prepare channel for input
.ffc9 jmp ($0320)        ; CHKOUT, prepare channel for output
.ffcb jmp ($0322)        ; CLRCHN, close all I/O
.ffcf jmp ($0324)        ; CHRIN, inpup byte from channel
.ffd2 jmp ($0326)        ; CHROUT, output byte to channel
.ffd5 jmp $f49e          ; LOAD, load from serial device
.ffd8 jmp $f5dd          ; SAVE, save to serial device
.ffdb jmp $f6e4          ; SETTIM, set realtime clock
.ffde jmp $f6dd          ; RDTIM, read realtime clock
.ffe1 jmp ($0328)        ; STOP, check <STOP> key
.ffe4 jmp ($032a)        ; GETIN, get input from keyboard
.ffe7 jmp ($032c)        ; CLALL, close all files and channels
.ffeа jmp $f69b          ; UDTIM, increment realtime clock
.ffd fed jmp $e505        ; SCREEN, return screen organisation
.fff0 jmp $e50a          ; PLOT, read/set cursor X/Y position
.fff3 jmp $e500          ; IOBASE, return IOBASE address

```

#### **FFF4 SYSTEM HARDWARE VECTORS**

This table contains jumpvectors for system reset, IRQ, and NMI. The IRQ and NMI vectors points to addresses which contains an indirect jump to RAM, to provide user defined routines.

.ffe4

.ffffa 43 fe	; NMI hardware vector
.ffffc e2 fc	; System reset vector
.ffffe 48 ff	; IRQ hardware vector